


# NissanConnect

OWNER'S MANUAL

Thank you for purchasing a NISSAN vehicle.

This user's manual is for the NissanConnect System featuring Apple CarPlay and Android Auto offered in your NISSAN vehicle.

Operation instructions for the following systems are included in this manual.

- Audio
- Hands-free phone
- Apple CarPlay
- Android Auto
- Yandex.Auto
- NissanConnect Services
- Navigation
- Voice recognition
- Information and settings viewable on NissanConnect

Please read this manual carefully to ensure safe operation of the NissanConnect System.

- Because of possible specification changes and optional equipment, some sections of this manual may not apply to your vehicle.
- All information, specifications and illustrations in this manual are those in effect at the time of printing. NISSAN reserves the right to change specifications or design at any time without notice.
- Do not remove this manual from the vehicle when selling this vehicle. The next user of the system may need the manual.

© 2022 NISSAN MOTOR CO., LTD.

# Contents


| | |
|---|---|
| Introduction | 1 |
| Getting started | 2 |
| Audio system | 3 |
| Hands-free phone | 4 |
| Information | 5 |
| Navigation (where fitted) | 6 |
| Voice recognition (where fitted) | 7 |
| Troubleshooting guide | 8 |
| Index | 9 |

# 1 Introduction


How to use this manual ..... 4
For safe operation ..... 4
Reference symbols ..... 4
Screen illustrations ..... 4
Terms displayed on screen ..... 4
Safety information ..... 5
Regulatory information ..... 6
Radio approval number and information ..... 6
Trademarks ..... 9
Legal disclaimer for NISSANCONNECT Services (where fitted for Mexico) ..... 10
Licences ..... 11
Software Licences ..... 11
Software Licences (Clarion Co., Ltd.) ..... 11
Telematics Control unit (TCU) (Where fitted) ..... 11

This manual uses special words, symbols, icons and illustrations organised by function.

Please refer to the following items and familiarise yourself with them.

## FOR SAFE OPERATION

**WARNING**

**This is used to indicate the presence of a hazard that could cause death or serious personal injury. To avoid or reduce the risk, the procedures must be followed precisely.**

**CAUTION**

**This is used to indicate the presence of a hazard that could cause minor or moderate personal injury or damage to your vehicle. To avoid or reduce the risk, the procedures must be followed carefully.**

**NOTE:**

**Indicates items that help you understand and maximise the performance of your vehicle. If ignored, they may lead to a malfunction or poor performance.**

## REFERENCE SYMBOLS

**INFO:**

This indicates information that is necessary for efficient use of your vehicle or accessories.

Reference page:

This indicates the title and page that you should refer to.

**< >**:


This indicates a button/switch on the control panel, the steering wheel, the steering column or the Display Commander.

[ ]:

This indicates a key/item displayed on the screen.

## SCREEN ILLUSTRATIONS

- The illustrations in this manual are representative of various models and may not be identical to the design and specifications of your vehicle.
- Icons and menu items displayed on the screen may be abbreviated or omitted from the screen illustrations when appropriate. The omitted icons and menu items are described as dashed lines as illustrated.




PBH0162XZ

## TERMS DISPLAYED ON SCREEN

In this manual, some menu items may be spelled or termed differently from those displayed on your screen depending on models, markets or software versions.

This system is primarily designed to help you support pleasant driving as outlined in this manual. However, you, the driver, must use the system safely and properly. Information and the availability of services may not always be up to date. The system is not a substitute for safe, proper and legal driving.

Before using the system, please read the following safety information. Always use the system as outlined in this manual.

**WARNING**

- **To operate the system, first park the vehicle in a safe location and set the parking brake. Operating the system while driving can distract the driver and may result in a serious accident.**
- **Exercise extreme caution at all times so full attention may be given to vehicle operation. If the system does not respond immediately, please be patient and keep your eyes on the road. Inattentive driving may lead to a crash resulting in serious injuries or death.**
- **Do not rely on route guidance (where fitted) alone. Always be sure that all driving manoeuvres are legal and safe in order to avoid accidents.**
- **Do not disassemble or modify this system. If you do, it may result in accidents, fire or electrical shock.**
- **If you notice any foreign objects in the system hardware, spill liquid on the system or notice smoke or a smell coming from it, stop using the system immediately and it is recommended you contact a NISSAN dealer or qualified workshop. Ignoring such conditions may lead to accidents, fire or electrical shock.**

**CAUTION**

- **Some jurisdictions may have laws limiting the use of video screens while driving. Use this system only where it is legal to do so.**
- **Extreme temperature conditions (below −20˚C (−4˚F) and above 70˚C (158˚F)) could affect the performance of the system.**
- **The display screen may break if it is hit with a hard or sharp object. If the display screen breaks, do not touch it. Doing so could result in an injury.**

**NOTE:**

**Do not keep the system running with the engine or e-POWER system stopped. Doing so may discharge the vehicle battery (12V battery). When you use the system, always keep the engine or e-POWER system running.**

**Models with NissanConnect Services:**
NissanConnect Services may not be available in some regions. Completing the NissanConnect Services registration is necessary to use NissanConnect Services related functions.

## RADIO APPROVAL NUMBER AND INFORMATION

### For Europe

**Robert Bosch GmbH:**
Hereby, Robert Bosch Car Multimedia GmbH declares that the radio equipment type AIVICMFB0, AIVIP32R0, AIVIH60A0 and AIVIL42P0 are in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

http://cert.bosch-carmultimedia.net

**Frequency Band**

2400 MHz - 2480 MHz

**Radiated Power [EIRP]**

Bluetooth < 10 mW

WLAN < 100 mW

**Hints/Restrictions**

Internal Antenna

Internal antenna not accessible by user. Any change by the user will violate the legal approval of this product.

### For Ukraine

**Robert Bosch GmbH:**

справжнім Robert Bosch Car Multimedia GmbH заявляє, що тип радіообладнання AIVIL42P0; AIVIB12P0; AIVICMFB0 відповідає Технічному регламенту радіообладнання;
повний текст декларації про відповідність доступний на веб-сайті за такою адресою:
https://eu-doc.bosch.com/

PAA0142XZ

PBH0015X

**Frequency Band**

2400 MHz - 2480 MHz

**Radiated Power [EIRP]**

Bluetooth < 10 mW

WLAN < 100 mW

**Hints/Restrictions**

Internal Antenna

Internal antenna not accessible by user. Any change of the user will violate the legal approval of this product.

### For Russia

**Robert Bosch GmbH:**

PBH0160XZ

### For Mexico

**Robert Bosch GmbH:**

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Modelo: AIVIL42P0, AIVIL12F0, AIVIP42M0, AIVIL42N0, AIVICMFB0, AIVIH60A0 y AIVIP32R0

Marca: Bosch

**Clarion Co., Ltd.:**
La operación de este equipo está sujeta a las siguientes dos condiciones:
(1) es posible que este equipo o dispositivo no cause interferencia perjudicial y
(2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

## For Brazil

**Robert Bosch GmbH:**
Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

Para maiores informações, consulte o site da ANATEL.
www.anatel.gov.br

ANATEL

Model: AIVICMFB0 05698-18-06541

Model: AIVIH60A0 04293-18-06541

Model: AIVIL42P0 02038-19-06541

## For Paraguay

**Robert Bosch GmbH:**
Este equipo de Telecomunicaciones cumple con los requerimientos de la CONATEL.

CONATEL
NR: 2018-10-I-000478

PBH0161XZ

## For Thailand

**Robert Bosch GmbH:**

เครื่องโทรคมนาคมและอุปกรณ์นี้
มีความสอดคล้องตามข้อกำหนดของ กทช.

**Clarion Co., Ltd.:**




PBH0159XZ

For Taiwan

**Robert Bosch GmbH**

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

PBH0091XZ

For Korea

**Robert Bosch GmbH:**

해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다

PBH0090XZ

## For Latin America

**Clarion Co., Ltd.:**

**FCC Regulatory information**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**⚠ WARNING**

**Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.**

**CAUTION**

**The device must not be co-located or operating in conjunction with any other antenna or transmitter.**

**FCC RF Radiation Exposure Statement Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20 cm from nearby persons.**

Made for iPhone | iPod

Works with Apple CarPlay

Apple, iPhone, iPod, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. Apple CarPlay is a trademark of Apple Inc. Use of the Apple CarPlay logo means that a vehicle user interface meets Apple performance standards. Apple is not responsible for the operation of this vehicle or its compliance with safety and regulatory standards. Please note that the use of this product with iPhone or iPod may affect wireless performance.

Bluetooth®

Bluetooth® is a trademark owned by Bluetooth SIG, Inc. and licensed to Robert Bosch GmbH and Clarion Co., Ltd.

HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. For patents see http://dts.com/patents. HD Radio, Artist Experience, and the HD, HD Radio, and "ARC" logos are registered trademarks or trademarks of iBiquity Digital Corporation in the United States and/or other countries.

Music recognition technology and related data are provided by Gracenote®. Gracenote is the industry standard in music recognition technology and related content delivery. For more information, visit www.gracenote.com. Music related data from Gracenote, Inc., copyright © 2000 to present Gracenote. Gracenote Software, copyright © 2000 to present Gracenote.

One or more patents owned by Gracenote apply to this product and service. See the Gracenote website for a nonexhaustive list of applicable Gracenote patents. Gracenote, the Gracenote logo and logotype are either a registered trademark or a trademark of Gracenote, Inc. in the United States and/or other countries.

**App Store**

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

**Siri**

Siri is a trademark of Apple Inc., registered in the U.S. and other countries.

**Google/Android/Google Play/Android Auto**

Google, Android, Google Play, Android Auto, and other marks are trademarks of Google LLC.

**Yandex.Auto**

Yandex is a trademark of YANDEX LLC, registered in Russia and other countries. Yandex.Auto logo Яндекс Авто © YANDEX LLC, 2018.

Yandex.Auto projected solution is connected and setting up through Yandex. Navigator application. Use of Yandex.Navigator application shall be under the terms of the license agreement accessible at: yandex.ru/legal/navigator_mobile_ agreement. Alice voice assistant is used for operation of the projected solution. Use of Alice voice assistant shall be under the terms of use accessible at: yandex.ru/legal/alice_termsofuse.

## LEGAL DISCLAIMER FOR NISSANCONNECT SERVICES (where fitted for Mexico)

Feature availability is dependent on vehicle model, trim level, packaging and options. A compatible connected device may be required and feature availability may be dependent on the device's capability. Refer to the connected device's owner's manual for details. Some features may become available at a later time.

**Driving is a serious business and requires your full attention.** Only use features and connected devices when safe and legal to do so. Some features, including automatic crash notification and SOS, are dependent upon the telematics device being in operative condition, its ability to connect to a wireless network, compatible wireless network availability, navigation map data and GNSS signal receptions, the absence of which can limit or prevent the ability to reach Customer Care or receive support. GNSS mapping may not be detailed in all areas or reflect current road status. Never program GNSS while driving.

Only use Remote Engine Start and Remote Horn features in accordance with any laws, rules or ordinances in effect in your vehicle's location.

**Some services and features are provided by independent companies not within NISSAN's control. Should the service provider terminate or restrict services or features, services or features may be suspended or terminated without notice or with no liability to NISSAN or its partners or agents.**

Services and features may require compatible cellular network provided by independent companies not within NISSAN or its partners' or agents' control. Cellular network signal strength may vary and may not be available in all areas or at all times. Services and features may not function if a cellular network is unavailable, restricted, or terminated.

NISSAN and its partners or agents are not responsible for associated costs or other third party changes that may be required for continued operation due to cellular network unavailability, restriction, or termination (including equipment replacements/upgrades, if available, or roaming charges on alternative networks). Technology is evolving, and changes by independent companies are not within NISSAN's or its partners' or agents' control. Enrolment, owner consent, personal identification number (PIN), and subscription agreement may be required to receive the full suite of features and services.

Trial periods (if applicable) begin on the date of vehicle purchase or lease of a new NISSAN. Trial periods may be subject to change at any time and may be subject to early termination without notice. Required subscriptions may be sold separately for each available feature or service after the trial period ends, and may continue until you call the service provider to cancel. Installation costs, a one-time activation fee, other fees and taxes may apply. Fees and programming are subject to change. Features may be subject to age restrictions in some areas. Subscriptions governed by the service provider's subscription agreement, terms and conditions and privacy statements are available at service provider's website.

## SOFTWARE LICENCES

- Open Source Software Licences

  http://oss.bosch-cm.com/nissan.html

- This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a licence from Microsoft.

## SOFTWARE LICENCES (Clarion Co., Ltd.)

- This product uses the source code of T-Kernel under T-License granted by the TRON Forum (www.tron.org).
- This software is based in part on the work of the independent JPEG Group.
- This product includes software developed by the OpenSSL project for use in the OpenSSL Toolkit.
  (http://www.openssl.org/)
  Copyright©1998 - The OpenSSL Project.
  All rights reserved.
- Portions of this software are copyright 1996-2002, 2006.
  The FreeType Project (www.freetype.org).
  All rights reserved.
- This unit includes software modules to be licensed under the GNU General Public License (GPL) or GNU Lesser General Public License (LGPL) and other open source software licenses. You can redistribute and/or modify it under the terms of each open source license.

To get the source code, refer to the following website.

https://www.clarion.com/us/en/opensource/nissan/index.html

## TELEMATICS CONTROL UNIT (TCU) (Where fitted)

http://opensourceautomotive.com/IC/tZ7T3eE6AiV4

MEMO

# 2 Getting started


Control buttons and touch screen display ..... 14
Buttons on control panel ..... 14
Touch screen display ..... 16
Switches on steering wheel ..... 18
Steering column switches (where fitted) ..... 20
Display Commander (where fitted) ..... 22
USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted) ..... 23
Starting the system ..... 24
Start-up screen (where fitted) ..... 24
Basic operation ..... 24
Selecting menu from Launch Bar ..... 24
How to view and operate HOME MENU screen ..... 25
Functions disabled while driving (where fitted) ..... 26
System settings ..... 28
Settings menu ..... 28
Connections settings ..... 30

## BUTTONS ON CONTROL PANEL

The control panel buttons are located at the centre of the instrument panel. Available functions, buttons, etc. may differ depending on the models, specifications and software versions.

| Button | Function |
|---|---|
| **<MENU>** | Push to display the HOME MENU screen.<br>☞ "How to view and operate HOME MENU screen" (page 25) |
| **<☀/☽>** | Push to switch between the day screen (bright) and the night screen (dark) and to adjust the level of screen brightness. Push and hold the button to turn off the display. Push the button again to turn on the display. |
| **<BACK>/< ⮌ >/< ⮌ BACK>** | Depending on the screen, pushing the button will display the previous screen. |
| **<AUDIO>** | Push to display the audio screen. When this button is pushed while the audio screen is displayed, a screen to select an audio source will be displayed.<br>☞ "Selecting the audio source" (page 47) |
| **<VOL/ ⏻ >/<VOLUME/ ⏻ >/<VOL/PUSH ⏻ >/ <VOL/PUSH POWER>** | Push to turn the power of the audio system on/off. Turn to adjust the volume. |
| **< ⏮ >/< ⏭ >** | Use the buttons for audio operations.<br>☞ "Audio operations" (page 46) |
| **<TUNE·SCROLL/SOUND>/ <TUNE·SCROLL/ENTER SOUND>/ <TUNE·SCROLL/PUSH SOUND>/ <TUNE·SCROLL/ENTER SETTING>/ <TUNE·SCROLL/OK>/**<br>**<⊖ ⊕/SOUND>/**<br>**<⊖ ⊕/ENTER SOUND>/**<br>**<⊖ ⊕/OK>/**<br>**<⊖ ⊕/PUSH SOUND>** | Depending on the conditions when a menu screen is displayed, turning the dial can select items on the screen. Push to confirm the selected item or setting.<br>Depending on models, the button can also be used for audio operations.<br>☞ "Audio operations" (page 46)<br>**Models with navigation system:**<br>Depending on the models, turning the dial can adjust the map scale on the navigation screen. |

| Button | Function |
|---|---|
| **<MAP>** | Push to display the current location map.<br>When a split map screen is displayed, push this button to display the full map screen. Voice guidance (where fitted) can be repeated by pushing and holding this button.<br>☞ "Navigation screen" (page 108) |
| **< ⏏ >** | Push to eject a disc.<br>☞ "Audio operations" (page 46) |
| **<📞>** | Push to display the phone screen.<br>☞ "Bluetooth® Hands-Free Phone System" (page 66) |
| **<SETTING>** | Push to display the setting menu screen.<br>☞ "System settings" (page 28) |

**INFO:**

For **<CAMERA>/<CAMERA/ >** (where fitted) operation, refer to the vehicle Owner's Manual. The buttons do not work if the vehicle is not equipped with the functions.

## TOUCH SCREEN DISPLAY

The touch screen display is located at the centre of the instrument panel. Various information and operation menus are displayed on the touch screen display. Touch keys and icons on the screen for operation.

### Liquid crystal display

The touch screen on this unit is a liquid crystal display and should be handled with care.

**⚠ WARNING**

**Never disassemble the display. Some parts utilise extremely high voltage. Touching them may result in serious personal injury.**

**Characteristics of liquid crystal display:**

- If the temperature inside the vehicle is especially low, the display will stay relatively dim or the movement of the images may be slow. These conditions are normal. The display will function normally when the interior of the vehicle has warmed up.
- Some pixels in the display are darker or brighter than others. This condition is an inherent characteristic of liquid crystal displays, and it is not a malfunction.
- A remnant of the previous display image may remain on the screen. This screen burn is inherent in liquid crystal displays, and it is not a malfunction.
- The screen may become distorted by strong magnetic fields.
- Depending on the condition, brightness may be adjusted automatically to prevent the display from screen burning.

**Maintenance of display:**

To clean the display screen, use a dry, soft cloth. If additional cleaning is necessary, use a small amount of neutral detergent with a soft cloth. Never spray the screen with water or detergent. Dampen the cloth first, then wipe the screen.

**CAUTION**

- **Clean the display with the ignition switch or power switch in the OFF position. If the display is cleaned while the ignition switch or power switch is placed in the ON position, unintentional operation may occur.**
- **To clean the display, never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or deteriorate the panel.**
- **Do not splash any liquid, such as water or car fragrance, on the display. Contact with liquid will cause the system to malfunction.**

## SWITCHES ON STEERING WHEEL

Switches on the steering wheel can be used to perform operations such as taking phone calls, changing volume, and conducting voice operations (where fitted). Available functions and switches may differ depending on the models, specifications and software versions.

| Switch | Function |
|---|---|
|  | Push to answer a received call, to end an active call or to read a received text message. Push and hold to reject an incoming call or to ignore a received text message.<br>When no phone call is received or when there is no active phone call while a Bluetooth® phone device is connected, pushing this switch will display the phone screen.<br>Depending on models and conditions, pushing and holding this switch will start a voice recognition session for making a phone call.<br>☞ "Bluetooth® Hands-Free Phone System" (page 66) |
|  (TALK) | If your iPhone is connected to the in-vehicle system via Bluetooth®, Siri Eyes Free (where fitted) can be activated by pushing and holding this switch without having to activate Apple CarPlay (where fitted).<br>☞ "Siri Eyes Free (where fitted)" (page 106)<br>When Apple CarPlay (where fitted) or Android Auto (where fitted) or Yandex.Auto (where fitted) is active, pushing and holding this switch will start a Siri or Google Assistant or voice assistant "Alice" voice control session.<br>☞ "Siri operation" (page 96)<br>☞ "Google Assistant™ operation" (page 101)<br>☞ "Voice assistant "Alice" operation" (page 104)<br>**Models with Voice Recognition System:**<br>Push to use the Voice Recognition System. Push and hold to end the voice recognition session.<br>☞ "Giving voice commands" (page 156) |
|  | Push to answer a received call or to read a received text message.<br>When no phone call is received or when there is no active call while a Bluetooth® phone device is connected, pushing this switch will display the phone screen.<br>☞ "Bluetooth® Hands-Free Phone System" (page 66) |
|  | Push to reject the incoming call, end an active call or to ignore the received text message.<br>☞ "Bluetooth® Hands-Free Phone System" (page 66) |
|  | Push to go back to the previous screen while operating the Voice Recognition System (where fitted).<br>Push and hold to end a voice recognition session. |


| Switch | Function |
|---|---|
| < 🔊 > | Push the + or - side of the switch to adjust the volume. |
| < ▲ / ▼ > | Tilt to select the voice command while operating the Voice Recognition System (where fitted).<br>Depending on models, push to confirm the selected item when voice command operation is conducted.<br>☞ "Voice recognition (where fitted)" (page 156)<br>This switch can also be used for audio operations.<br>☞ "Audio operations" (page 46) |
| < ▲ >/< ▼ >/< ◀ >/< ▶ >/<OK> | Push < ▲ >/< ▼ > to select the voice command while operating the Voice Recognition menu screen (where fitted).<br>Push < ▲ >/< ▼ > to switch to the previous or next page while operating the Voice Recognition menu screen.<br>Push **<OK>** to confirm the selected item while operating the Voice Recognition menu screen.<br>☞ "Voice recognition (where fitted)" (page 156) |
| **<SOURCE>** | Push to change the audio source.<br>☞ "Audio operations" (page 46) |
| < ⏮ >/< ⏭ > | This switch can be used for audio operations.<br>☞ "Audio operations" (page 46)<br>Depending on models and conditions, push to read the previous or next message while received text message is displayed on the touch screen display.<br>☞ "Received message screen" (page 72) |
| < ◀ >/< ▶ > | Depending on the models, push to switch to the previous or next page while operating the Voice Recognition menu screen (where fitted).<br>☞ "Hands-free text messaging assistant (where fitted)" (page 70) |

*: Depending on the countries, the voice operation function is not available and **<** 🎤 **>** may not function.

**INFO:**


Steering wheel switches are mainly for the vehicle information display control and may not be able to operate the touch screen display depending on the conditions. For details of the vehicle information display, refer to the vehicle Owner's Manual.

## STEERING COLUMN SWITCHES (where fitted)




PBA0016XZ

**Front view**




PBA0019XZ

**Back view**

| | | |
|---|---|---|
| ① | **<SOURCE/AUDIO>** | Push to change the audio source. |
| ② | < / > | Push to answer a received call, to read a text-message or to end an active call.<br>When no phone call is received or when there is no active call, pushing this switch will display the phone screen.<br>☞ "Bluetooth® Hands-Free Phone System" (page 66)<br>Push and hold to use the Voice Recognition System (where fitted).<br>☞ "Giving voice commands" (page 156) |
| ③ | < > | Push the + or - side of the switch from behind to adjust the volume. |
| ④ | **<MODE/OK>** | Push to display the HOME MENU screen.<br>☞ "How to view and operate HOME MENU screen" (page 25) |
| ⑤ | Tuning wheel | This tuning wheel can be used for audio control.<br>☞ "Audio operations" (page 46) |

## DISPLAY COMMANDER (where fitted)

The Display Commander is located near the shift lever. With this system, the same operations as those for the control panel are possible using the Display Commander.

| Button | | Function |
|---|---|---|
| **<MAP/VOICE>** | | Push to display the vehicle's current location on the map.<br>Push and hold to hear the current guidance for a programmed route.<br>☞ "Navigation screen" (page 108) |
| **<AUDIO>** | | Push to display the audio screen. When this button is pushed while the audio screen is displayed, a screen to select an audio source will be displayed.<br>☞ "Selecting the audio source" (page 47) |
| **<MENU>** | | Push to display the HOME MENU screen.<br>☞ "How to view and operate HOME MENU screen" (page 25) |
| **< BACK>** | | Pushing the button will display the previous screen. |
| **<OK>** | | Push to enter the selected item.<br>**Models with navigation system:**<br>If this button is pushed while a map is displayed, the map menu is shown on the display.<br>☞ "Map menu screen" (page 121) |
| Center dial/Slide switch | Turning operation | Turn the dial to scroll the highlighted item or to adjust a setting.<br>**Models with navigation system:**<br>While the map screen is displayed, adjust the map scale by turning the dial. |
| | Sliding operation | Depending on the screen, sliding the slide switch can select areas on the screen or scroll the pages.<br>**Models with navigation system:**<br>While the map screen is displayed, scroll the map screen by sliding the switch. |

## USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)

**WARNING**


**Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.**

**CAUTION**

- **Do not force the USB device into the USB connection port. Depending on the USB connection port, inserting the USB device tilted or upside down may damage the port. Make sure that the USB device is connected correctly into the USB connection port.**
- **Do not grab the USB connection port cover (where fitted) when pulling the USB device out of the port. This could damage the port and the cover.**
- **Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the port.**


The vehicle is equipped with a USB connection port and an AUX input jack. When connected, the in-vehicle audio system can play audio contents from the compatible device.

The USB connection port and an AUX input jack are located on the lower part of the instrument panel, on the centre console or inside the centre console box.





5GH0905XZ

**Media hub Type A (example)**




PAB0035XZ

**Media hub Type B (example)**




PBH0177XZ

**Media hub Type C (example)**

① **AUX (Auxiliary) input jack:**

Connect an audio player that accepts a 3.5 mm (1/8 in) TRS connector (such as an MP3 player etc.) to play music.

② **USB connection port(s):**

Connect a compatible device to play media such as an iPod or a USB memory device.

Connect an iPhone or an Android phone to use Apple CarPlay (where fitted), Android Auto (where fitted) or Yandex.Auto (where fitted).

**INFO:**

- Refer to your AUX and USB device manufacturer's owner information regarding the proper use and care of the device.
- Cables made by Apple Inc. should be used to connect electronic devices marketed by Apple Inc.

The system starts when the ignition switch or power switch is placed in the ACC or ON position.

## START-UP SCREEN (where fitted)

The start-up screen is displayed when the ignition switch or power switch is placed in the ACC or ON position.

After an animated start-up screen is displayed, a message screen will be displayed. Touch [OK] after reading and agreeing to the message displayed on the screen. If you do not agree to the message, some of the functions on the system will be disabled.

**NOTE:**


**Do not keep the system running with the engine or e-POWER system stopped. Doing so may discharge the vehicle battery (12V battery). When you use the system, always keep the engine or e-POWER system running.**



The system can be operated with the touch panel as well as the switches on the control panel, the steering wheel and the Display Commander (where fitted).

This manual mainly describes the touch panel operation.

## SELECTING MENU FROM LAUNCH BAR




**Example**

Various system functions can be accessed by touching the items on the Launch Bar ① which is displayed on most of the main menu screens. (The Launch Bar does not appear on some screens such as scrolled map screen, keyboard screen, etc.)

Touch the item on the Launch Bar to display the corresponding screens.

The items on the Launch Bar differ according to which button on the control panel is pushed.

Models with the Display Commander: Sliding the slide switch of the Display Commander backwards will enable the centre dial operation of the Launch Bar. Slide the switch forward to return to operate Shortcuts with the centre dial.

The following menus are available on the Launch Bar. (Displayed items may vary depending on models, specifications and software versions.)

**When pushing <MENU>:**

Shortcuts for various functions are displayed.

Displayed items may vary depending on models and specifications.

- [Phone]*

  ☞ "Phone" (page 68)

- [Info]

  ☞ "Information menu" (page 80)

- [Audio]

  ☞ "Audio operations" (page 46)

- [MENU]

  Touching [MENU] on the Launch Bar will display the centre page of the HOME MENU screen.

- [Map]

  ☞ "Displaying navigation screen" (page 108)

- [Connections]

  "Connections settings" (page 30)

- [Settings]

  "System settings" (page 28)

*: [Phone] will be replaced by [CarPlay] when Apple CarPlay (where fitted) is active, and it will be replaced by [ ] when Android Auto (where fitted) is active.

*: [Phone] will be replaced by [Yandex] when Yandex.Auto (where fitted) is active.

**When pushing <AUDIO>:**

Shortcuts mainly for the audio functions are displayed.

"Launch bar" (page 108)

**When pushing <MAP> (where fitted):**

Shortcuts mainly for the navigation functions are displayed.

"System settings" (page 28)


## HOW TO VIEW AND OPERATE HOME MENU SCREEN

Push **<MENU>/<MODE/OK>** (where fitted) to display the HOME MENU screen.

The HOME MENU consists of 3 pages which can display preferred shortcuts and widgets.

**INFO:**

- Available items may vary depending on models and specifications. Items displayed on the screen may not function depending on various conditions.
- The HOME MENU screen can display up to 8 shortcuts on a page.
- Some widgets, such as [Audio], or [Clock], etc., can be selected from 2 shortcut spot sizes and 4 shortcut spot sizes. All other widgets require 4 shortcut spot sizes to be displayed.




**Example**

① Shortcut icons:

Icons for frequently used menu items can be placed on the HOME MENU screens as shortcuts.


② Widget:

Useful information from primary menu functions can be displayed as widgets. Depending on the contents of the widget, keys may be available for operation of the function.

## Customising HOME MENU screen

The HOME MENU screen can be personalised by selecting which shortcuts and widgets are to be displayed and where to place them on the screen.

**Selecting shortcut or widget:**




5GH0862XZ

**Example**

1. Touch [Customise Home Menu]/[Customize Home Menu] on the setting menu screen.

   "System settings" (page 28)

2. Touch [Shortcuts] or [Widgets].
3. Drag the shortcut or widget icon ① to each page layout ③.

   If a different shortcut or a widget is already located on the page layout ③, a message will be displayed. Touch [Yes] to replace the shortcut/widget. The page layout ③ can be changed by dragging the icons.

   The categories of shortcuts can be changed by touching [Category] ②.

   Dragging an icon into the [🗑] ④ can delete the current shortcut or widget to create a blank spot.

**INFO:**

Touch [🗑] ④, and then a message will appear. While the message is displayed, touching any icon on the page layout ③ and [Delete] can delete the selected icon. To delete all icons, touch [Select All] and then [Delete].

## FUNCTIONS DISABLED WHILE DRIVING (where fitted)

To ensure safe driving, some functions cannot be operated while driving.

The on-screen functions that are not available while driving will be "greyed-out" or muted. In some cases, certain text will not be displayed on the screen.

To use these functions, first park the vehicle in a safe location and then operate the system.

# SYSTEM SETTINGS

The system settings can be changed for personal convenience.

## SETTINGS MENU

Touch [Settings] on the Launch Bar or push <SETTING> (where fitted) on the control panel, and then touch a setting item you wish to adjust.

Available setting items may vary depending on models, specifications and software versions.

**Available setting items**

| Setting item | Result |
|---|---|
| [Connections] | Displays the Bluetooth®, Wi-Fi (where fitted) and USB and apps (where fitted) setting screen.<br>☞ "Connections settings" (page 30) |
| [Phone] | Displays the Phone and text message settings screen.<br>☞ "Phone and text message settings" (page 74) |
| [Navigation] | Displays the navigation settings screen.<br>☞ "Navigation settings" (page 143) |
| [Sound] | Displays the audio settings screen. |
| [Volume & Beeps] | Displays the volume adjustment screen. |
| [Clock] | Displays the clock adjustment screen. |
| [Customise Home Menu]/[Customize Home Menu] | Displays the HOME MENU editing screen. |
| [Customise Audio Sources]/[Customize Audio Sources] | Displays the editing screen for audio source menus on the Launch Bar.<br>☞ "Selecting from Launch Bar" (page 47) |
| [NissanConnect Services] | Displays the NissanConnect Services settings screen.<br>☞ "NissanConnect Services powered by SiriusXM™ (where fitted for Mexico)" (page 86)<br>☞ "NissanConnect Services (where fitted for Europe, Russia and Ukraine)" (page 85) |
| [System Voice] | Displays the system voice settings screen.<br>☞ "System Voice settings" (page 159) |
| [Camera] | Displays the camera settings screen.<br>See the vehicle Owner's Manual for details of the monitor system. |

| Setting item | | Result |
|---|---|---|
| [More Settings] | [Display] | Displays the display settings screen. |
| | [Language] | Displays the language settings screen. |
| | [Units] | Displays the units settings screen. |
| | [Keyboard Type] | Keyboard type can be selected. |
| | [Return All Settings to Default] | This resets all settings to default. |
| [System Update] | [Software Version]/[Version Information] | Displays the version information screen. |
| | [Software Update] | The system software can be updated.<br>☞ "Updating system software (where fitted)" (page 83) |
| | [Map Update] | The map data can be updated.<br>☞ "How to update map data (where fitted)" (page 150) |
| [Apps] | [Apple CarPlay] | Displays the Apple CarPlay settings screen.<br>☞ "Apple CarPlay settings" (page 98) |
| | [Android Auto] | Displays the Android Auto settings screen.<br>☞ "Android Auto settings" (page 102) |
| | Device list | Displays recently connected Apple CarPlay, Android Auto or Yandex.Auto devices.<br>☞ "Apple CarPlay settings" (page 98)<br>☞ "Android Auto settings" (page 102)<br>☞ "Yandex.Auto settings" (page 105) |

**INFO:**

The system software (where fitted) and map (where fitted) update menus can also be accessed from [System Information] on the information screen, even if the menus are not available from the settings screen.

☞ "Information menu" (page 80)

## CONNECTIONS SETTINGS

Changing the settings and viewing information of Bluetooth®, Wi-Fi (where fitted), apps (where fitted) and USB are available on the Connections settings screen.


### Setting Bluetooth®

Your vehicle is equipped with the Bluetooth® Hands-Free Phone System and Bluetooth® audio device support. If you are an owner of a compatible Bluetooth® enabled mobile phone or Bluetooth® audio device, you can set up the wireless connection between your mobile phone and the in-vehicle phone module or Bluetooth® audio device and in-vehicle audio module. With Bluetooth® wireless technology, you can make or receive a telephone call with your mobile phone in your pocket and listen to Bluetooth® audio.

"CD (where fitted), DVD (where fitted), USB memory device, iPod and Bluetooth® audio player" (page 52)

"Bluetooth® Hands-Free Phone System" (page 66)

**Connecting mobile phone/audio device:**




5GH0778XZ

**Example**

To use the Bluetooth® device with the in-vehicle system for the first time, the device connection operation is required.

1. Touch [Connections] on the setting menu screen.

   "System settings" (page 28)

2. Touch [Bluetooth] and touch [Add New]. A message is displayed.
3. Touch [Yes] to connect a mobile phone. Touch [No] to connect an audio device and operate as guided by the system. (Operations may differ depending on the device.)

**NOTE:**

**Some mobile phones or other devices may cause interference or a buzzing noise to come from the audio system speakers. Storing the device in a different location may reduce or eliminate the noise.**

**INFO:**

- The paired phone will be added to the list on the Bluetooth® connection screen.
- Touching the name of the other device on the list will switch the connected device.
- Touching [] will allow the device to be connected via Bluetooth® and be used on the Hands-Free Phone System.
- Depending on the models, specifications and software versions, you can register a favourite phone device. The phone device selected as a favourite will be marked with "★".

  "Bluetooth® settings" (page 31)

- Touching [] will allow the device to be connected via Bluetooth® and be used for Bluetooth® Audio.
- Depending on the models, specifications and software versions, touching [] (where fitted) will enable Bluetooth® tethering.
- Touching [] will display the information of the Bluetooth® device.
- Up to 6 Bluetooth® devices can be registered. If 6 devices are already registered, one of the devices must first be deleted before another device can be registered.

- The pairing procedure of the mobile phone varies according to each mobile phone. See the mobile phone Owner's Manual for the details.
- Consult a NISSAN dealer or qualified workshop for information regarding Bluetooth® device connection to your vehicle.

**Bluetooth® settings:**

The Bluetooth® settings can be changed according to your preference.

1. Touch [Connections] on the setting menu screen.
   ☞ "System settings" (page 28)
2. Touch [Bluetooth].
3. Touch [].

Available setting items may vary depending on models, specifications and software versions.

**Available setting items**

| Setting item | Action |
|---|---|
| [Bluetooth] | Turns the Bluetooth® connection on/off. |
| [Allow 2 Phones Simultaneously] | When turned on, up to 2 Bluetooth® devices can be connected as hands-free phones to the in-vehicle system simultaneously. |
| [Favourite Phone]/[Favorite Phone] | A Bluetooth® device can be registered as a favourite hands-free phone. If the hands-free phone device is within the range with Bluetooth® turned on, the device registered as favourite will automatically be connected to the in-vehicle system with priority upon the system activation. Favourite phone is marked with "★" in the device list. |
| [Favourite Audio]/[Favorite Audio] | A Bluetooth® device can be registered as a favourite audio device. If the Bluetooth® audio device is within the range with Bluetooth® turned on, the device registered as favourite will automatically be connected to the in-vehicle system with priority upon the system activation. Favourite audio device is marked with "★" in the device list. |
| [Device Name] | The device name can be changed. |
| [PIN] | The PIN code can be changed. |

**INFO:**

With [Device Name], the device name that appears on the screen can be changed and be renamed from the name set as default to the preferred name (such as "Steve's Car" for example).

**Deleting mobile phone/audio device:**

Paired devices can be deleted from the list.

1. Touch [Connections] on the setting menu screen.
   "System settings" (page 28)
2. Touch [Bluetooth].
3. Touch [ⓘ] next to the name of the mobile phone you wish to delete.
4. Touch [Delete]. Touch [Yes] when a message appears.

## WI-FI SETTING (where fitted)


A Wi-Fi connection can be made by using an available Wi-Fi network near the vehicle or tethering function of smartphone, etc. Wi-Fi connectivity is useful for updating map data (where fitted) and system software (where fitted), or Premium Traffic (where fitted).

"Updating system software (where fitted)" (page 83)

"How to update map data (where fitted)" (page 150)

"Premium traffic information (where fitted)" (page 132)

**Connecting to a Wi-Fi network:**




5GH0779XZ

**Example**

To use the Wi-Fi connection for the first time, the following connecting procedures are required.

1. Touch [Connections] on the setting menu screen.
   "System settings" (page 28)
2. Touch [Wi-Fi].
3. Touch the name of the device you wish to connect.

| | |
|---|---|
| | Indicates that a password is set. |
| | Indicates the strength of the signal the Wi-Fi device is receiving. |

4. Enter the network password and touch [OK]. The device will be connected.

   If a listed device is in a status capable of making Wi-Fi connection, touching the device name on the list will start the connection.

**INFO:**

- Enter the password correctly, including capitalisation.
- Touching the [ⓘ] will display the network information. Turning [Auto Connect] on will automatically connect the vehicle to the network if the network is available.
- Touch [Vehicle Hotspot]/[Car Hotspot] (where fitted) and turn on the indicator to activate the Wi-Fi hotspot communication. It enables devices such as smartphones to connect to a Wi-Fi network.
- Enabling the Wi-Fi hotspot functionality of your smartphone may incur additional charges from your mobile provider. Consult your mobile provider contract regarding the communication fee.
- The system can only connect to a WPA2 security network (it will not connect to WEP, WPA1 networks).
- Wi-Fi networks that require a web browser cannot be accessed through this unit.

**Wi-Fi settings:**

The Wi-Fi settings can be changed according to your preference.

1. Touch [Connections] on the setting menu screen.
   "System settings" (page 28)
2. Touch [Wi-Fi].

3. Touch [⚙].
4. Touch a preferred item.

Available setting items may vary depending on models, specifications and software versions.

**Available setting items**

| Setting item | Action |
|---|---|
| [Vehicle Hotspot]/ [Car Hotspot] | Turns the vehicle hotspot on/off. |
| [Network Name (SSID)] | Displays the Wi-Fi network name. |
| [Password] | Displays the Wi-Fi network password. |
| [Wi-Fi] | Turns the Wi-Fi connection on/off. |
| [Security] | The used cipher system is displayed. |


**Deleting Wi-Fi network:**

The stored Wi-Fi network can be deleted from the list.

1. Touch [Connections] on the setting menu screen.
   ☞ "System settings" (page 28)
2. Touch [Wi-Fi].
3. Touch [ⓘ] by the name of the network you wish to delete.
4. Touch [Delete]. Touch [Yes] when a message appears.

## Displaying USB device information

The information of the connected USB device can be viewed.





5GH0780XZ

**Example**

1. Touch [Connections] on the setting menu screen.
2. Touch [USB].
3. Touch the name of the device you wish to check. The name and the type of the device are displayed.

## APPS SETTINGS (where fitted)

A list of devices that have been connected recently for Apple CarPlay (where fitted), Android Auto (where fitted) or Yandex.Auto (where fitted) is displayed, and settings for each device can be changed.




PBH0028XZ

**Example**

The apps settings can be changed according to your preference.

① Touch [Connections] on the setting menu screen.
   ☞ "System settings" (page 28)
② Touch [Apps].
③ Touch [ⓘ] or the name of the device you wish to change the setting.
④ Touch a preferred item.

**INFO:**

Displayed items may vary depending on the apps.

☞ "Apple CarPlay settings" (page 98)
☞ "Android Auto settings" (page 102)
☞ "Yandex.Auto settings" (page 105)

MEMO

# 3 Audio system


Audio operation precautions ..... 36
Radio ..... 36
Compact Disc (CD) player (where fitted) ..... 41
Digital Versatile Disc (DVD) player (where fitted) ..... 38
USB (Universal Serial Bus) connection port ..... 41
Compressed Audio Files (MP3/WMA/AAC) ..... 42
Bluetooth® audio ..... 46
Audio operations ..... 46
Audio main operation ..... 46
Radio ..... 48
CD (where fitted), DVD (where fitted), USB memory device, iPod and Bluetooth® audio player ..... 52
Auxiliary (AUX) devices (where fitted) ..... 61
Smartphone audio (where fitted) ..... 61
Audio settings ..... 62
Audio adjustments with audio adjust bar (where fitted) ..... 63
CD/DVD/USB memory device care and cleaning ..... 63
CD/DVD (where fitted) ..... 63
USB memory device ..... 64

**CAUTION**

- **Operate the audio system only when the vehicle engine or e-POWER system is running. Operating the audio system for extended periods of time with the engine or e-POWER system turned off can discharge the vehicle battery (12V battery).**
- **Do not allow the system to get wet. Excessive moisture such as spilled liquids may cause the system to malfunction.**
- **Park the vehicle in a safe location and apply the parking brake to view movies (where fitted) on the touch screen display.**

## RADIO

Place the ignition switch or power switch in the ACC or ON position before turning on the radio. If you listen to the radio with the engine or e-POWER system not running, the ignition switch or power switch should be placed in the ACC position.

Radio reception is affected by station signal strength, distance from radio transmitter, buildings, bridges, mountains and other external influences. Intermittent changes in reception quality normally are caused by these external influences.

**Using a mobile phone in or near the vehicle may influence radio reception quality.**

### Radio reception

Your radio system is equipped with state-of-the-art electronic circuits to enhance radio reception. These circuits are designed to extend reception range, and to enhance the quality of that reception.


However there are some general characteristics of both FM and AM radio signals that can affect radio reception quality in a moving vehicle, even when the finest equipment is used. These characteristics are completely normal in a given reception area, and do not indicate any malfunction in your radio system.

Reception conditions will constantly change because of vehicle movement. Buildings, terrain, signal distance and interference from other vehicles can work against ideal reception. Described below are some of the factors that can affect your radio reception.

Some mobile phones or other devices may cause interference or a buzzing noise to come from the audio system speakers. Storing the device in a different location may reduce or eliminate the noise.

### FM radio reception

MAXIMUM SIGNAL DISTANCES




- FM: 40 to 48 km (25 to 30 miles)
- AM: 97 to 209 km (60 to 130 miles)

Range: FM range is normally limited to 40 to 48 km (25 to 30 miles), with monaural (single station) FM having slightly more range than stereo FM. External influences may sometimes interfere with FM station reception even if the FM station is within 40 km (25 miles). The strength of the FM signal is directly related to the distance between the transmitter and receiver. FM signals follow a line-of-sight path, exhibiting many of the same characteristics as light. For example they will reflect off objects.

Fade and drift: As your vehicle moves away from a station transmitter, the signals will tend to fade and/or drift.

Static and flutter: During signal interference from buildings, large hills or due to antenna position, usually in conjunction with an increased distance from

the station transmitter, static or flutter can be heard. This can be reduced by lowering the treble setting to reduce the treble response.

Multipath reception: Because of the reflective characteristics of FM signals, direct and reflected signals reach the receiver at the same time. The signals may cancel each other, resulting in momentary flutter or loss of sound.

### AM radio reception

AM signals, because of their low frequency, can bend around objects and skip along the ground. In addition, the signals can bounce off the ionosphere and be bent back to earth. Because of these characteristics, AM signals are also subject to interference as they travel from transmitter to receiver.

Fading: Occurs while the vehicle is passing through motorway underpasses or in areas with many tall buildings. It can also occur for several seconds during ionospheric turbulence even in areas where no obstacles exist.

Static: Caused by thunderstorms, electrical power lines, electric signs and even traffic lights.

### Digital Audio Broadcast (DAB) (where fitted)

The supported standards for this system are DAB and DAB+.


### HD Radio Technology reception (where fitted)

HD Radio Technology reception needs to be activated to receive HD Radio broadcasts.

"Radio" (page 48)

This enables you to receive radio broadcasts digitally (where available), providing a better quality sound with clear reception. When this feature is not activated or HD Radio broadcasts are not available, you will receive analog radio (AM/FM) broadcasts.

## COMPACT DISC (CD) PLAYER (where fitted)




SAA0480

- Do not force a CD into the CD slot. This could damage the CD and/or CD player.
- Trying to load a CD with the CD door closed could damage the CD and/or CD player.
- During cold weather or rainy days, the player may malfunction due to the humidity. If this occurs, remove the CD and dehumidify or ventilate the player completely.
- The player may skip while driving on rough roads.
- The CD player sometimes cannot function when the passenger compartment temperature is extremely high. Decrease the temperature before use.
- Only use high quality 12 cm (4.7 in) round discs that have the "COMPACT disc DIGITAL AUDIO" logo on the disc or packaging.
- Do not expose the CD to direct sunlight.
- CDs that are of poor quality, dirty, scratched, covered with fingerprints or that have pin holes may not work properly.
- The following CDs may not work properly:
  - Copy control compact discs (CCCD)
  - Recordable compact discs (CD-R)
  - Rewritable compact discs (CD-RW)
- Do not use the following CDs as they may cause the CD player to malfunction.
  - 8 cm (3.1 in) discs
  - CDs that are not round

- CDs with a paper label
- CDs that are warped, scratched, or have abnormal edges

- This audio system can only play prerecorded CDs. It has no capabilities to record or burn CDs.
- If the CD cannot be played, one of the following messages will be displayed.

**Disc read error:**

Indicates a CLV, Focus, TOC or Access error. Check and reinsert the CD. Make sure that it is inserted correctly.

**Please eject disc:**

Indicates a mechanism error. If the CD can be ejected, eject and reinsert the CD. If the CD cannot be ejected, it is recommended you visit a NISSAN dealer or qualified workshop for service.

**Unplayable file:**

Indicates that a readable file is not found on the inserted CD. Check the data in your CD.

## DIGITAL VERSATILE DISC (DVD) PLAYER (where fitted)

### Copyright and trademark

- Technology protected by the U.S. patent and other intellectual property rights owned by Macrovision Corporation and other right holders is utilised for this system.
- This copyright protected technology cannot be used without permission from Macrovision Corporation. This is limited to personal use, etc., as long as the permission from Macrovision Corporation is not issued.
- Modifying or disassembling is prohibited.
- Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double D mark are trademarks of Dolby Laboratories.
- DTS, DTS and dts together, DTS 2.0 Channel, and the dts 2.0 Channel logo are registered trademarks or trademarks of DTS, Inc. in the United States and/or other countries.

### Parental level (parental control)


DVDs with the parental control setting can be played with this system. Please use your own judgment to set the parental control with the system.

### Disc selection

You can play the following disc formats with the DVD drive:

- DVD-VIDEO
- DVD-VR
- VIDEO-CD
- DTS-CD

A DVD may not play properly depending on the disc or format.




LHA0484

Use DVDs with the region code “ALL” or the code applicable to your DVD player. (The region code Ⓐ is displayed as a small symbol printed on the DVD Ⓑ.) This vehicle-installed DVD player can only play DVDs with the applicable region code.

**Do not use the following DVDs as they may cause the DVD player to malfunction:**

- **8 cm (3.1 in) discs**
- **DVDs with incompatible region code**
- **DVDs that are not round**
- **DVDs with a paper label**
- **DVDs that are warped, scratched, or have unequal edges**

The following DVDs may not work properly:

- Recordable digital video discs (DVD-R)
- Rewritable digital video discs (DVD-RW)

## Specification chart for DVD

**Playable Media:**

The following media can be played on the system.

- DVD+RW
- DVD+R
- DVD+R DL
- DVD-RW (corresponds to CPRM)
- DVD-R (corresponds to CPRM)
- DVD-R DL (corresponds to CPRM)
- DVD-ROM
- Dual DISC (not guaranteed)

**Video codec:**

The following video codecs are supported by the system.

| Video file format | |
|---|---|
| DVD Video | |
| DVD-VR with CPRM | |
| VIDEO CD* | Ver. 1.0 |
| | Ver. 1.1 |
| | Ver. 2.0 |
| DTS CD | |

*Some VIDEO CD functions may not be supported with this system.

**Audio codec:**

The following combinations of audio codecs support video formats.

| Sound format | DVD-Video | DVD-VR | VIDEO-CD | DTS-CD |
|---|---|---|---|---|
| LPCM | Supported | Supported | Not supported | Not supported |
| Dolby Digital | Supported | Supported | Not supported | Not supported |
| Dolby Digital EX | Not supported | Not supported | Not supported | Not supported |
| DTS | Supported | Not supported | Not supported | Supported |
| DTS-ES | Not supported | Not supported | Not supported | Not supported |
| DTS 96/24 | Not supported | Not supported | Not supported | Not supported |
| MPEG1 Layer3 | Supported | Supported | Supported | Not supported |
| MPEG2 Layer3 | Supported with output limitations *1 | Supported with output limitations*1 | Not supported *2 | Not supported |

*1 A back surround channel of DVD-Video and DVD-VR/MPEG2 is assigned to the LS and RS channels and output.

*2 MPEG2 Layer3 of VIDEO CD indicates SVCD. SVCD may play but its performance is not guaranteed. The 2nd output is utilised for the audio output of SVCD.

## USB (Universal Serial Bus) CONNECTION PORT

**⚠ WARNING**

**Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.**

**CAUTION**

- **Do not force the USB device into the USB connection port. Depending on the USB connection port, inserting the USB device tilted or upside down may damage the port. Make sure that the USB device is connected correctly into the USB connection port.**
- **Do not grab the USB connection port cover (where fitted) when pulling the USB device out of the port. This could damage the port and the cover.**
- **Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the port.**

The vehicle is not equipped with a USB device. USB devices should be purchased separately as necessary.

This system cannot be used to format USB devices. To format a USB device, use a personal computer.

This system supports various USB memory devices, USB hard drives and iPod players. Some USB devices may not be supported by this system.

- Partitioned USB devices may not be played correctly.
- Some characters used in other languages (Chinese, Japanese, etc.) may not appear properly on the display. Using English language characters with a USB device is recommended.

**General notes for USB use:**

Refer to your device manufacturer's owner information regarding the proper care of the device.

**Notes for iPod use:**

iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

- Improperly plugging in the iPod may cause a checkmark to be displayed on and off (flickering). Always make sure that the iPod is connected properly.
- Audiobooks may not play in the same order as they appear on an iPod.

### Compatibility

Compatibility may differ depending on the models.

Made for

- iPhone 12 Pro Max
- iPhone 12 Pro
- iPhone 12 mini
- iPhone 12
- iPhone 11 Pro Max
- iPhone 11 Pro
- iPhone 11
- iPhone XR
- iPhone XS Max
- iPhone XS
- iPhone X
- iPhone 8 Plus
- iPhone 8
- iPhone 7 Plus
- iPhone 7
- iPhone 6s Plus
- iPhone 6s
- iPhone SE (2nd generation)
- iPhone SE (1st generation)
- iPod Touch (7th generation)

**INFO:**


- Device compatibility may vary depending on models, specifications and software versions.
- Make sure that the iOS is updated.
- Refer to your device manufacturer's owner information regarding the proper use and care of the device.

## COMPRESSED AUDIO FILES (MP3/WMA/AAC)

### Explanation of terms

- MP3 — MP3 is short for Moving Pictures Experts Group Audio Layer 3. MP3 is the most well-known compressed digital audio file format. This format allows for near "CD quality" sound, but at a fraction of the size of normal audio files. MP3 conversion of an audio track can reduce the file size by approximately a 10:1 ratio (Sampling: 44.1 kHz, Bit rate: 128 kbps) with virtually no perceptible loss in quality. The compression reduces certain parts of sound that seem inaudible to most people.
- WMA — Windows Media Audio (WMA) is a compressed audio format created by Microsoft as an alternative to MP3. The WMA codec offers greater file compression than the MP3 codec, enabling storage of more digital audio tracks in the same amount of space when compared to MP3s at the same level of quality.
- Bit rate — Bit rate denotes the number of bits per second used by a digital music file. The size and quality of a compressed digital audio file is determined by the bit rate used when encoding the file.
- Sampling frequency — Sampling frequency is the rate at which the samples of a signal are converted from analogue to digital (A/D conversion) per second.
- Multisession — Multisession is one of the methods for writing data to media. Writing data once to the media is called a single session, and writing more than once is called a multisession.
- ID3/WMA tag — The ID3/WMA tag is the part of the encoded MP3 or WMA file that contains information about the digital music file such as song title, artist, album title, encoding bit rate, track time duration, etc. ID3 tag information is displayed on the Album/Artist/Track title line on the display.
- AAC — Advanced Audio Coding (AAC) is a compressed audio format. AAC offers greater file compression than MP3 and enables music file creation and storage at the same quality as MP3.

### Playback order




Ⓐ Root folder

Ⓑ Folder

Ⓒ Audio file

- Names of folders not containing compressed audio files are not shown on the display.

- The playback order is the order in which the files were written by the writing software, so the files might not play in the desired order.
- Music playback order of compressed audio files is as illustrated.

## Specification chart for CD (where fitted)

| | | | |
|---|---|---|---|
| Supported media | | | CD, CD-R*5, CD-RW*5 |
| Supported file systems | | | CD, CD-R*5, CD-RW*5 |
| Supported versions*1 | MP3 | Version | MPEG1 Audio Layer3, MPEG2 Audio Layer3 |
| | | Sampling frequency | MPEG1 Audio Layer3: 32kHz, 44.1kHz, 48kHz<br>MPEG2 Audio Layer3: 16kHz, 22.05kHz, 24kHz |
| | | Bit rate | MPEG1 Audio Layer3: 32 kbps - 320 kbps<br>MPEG2 Audio Layer3: 8 kbps - 160 kbps |
| | WMA*2 | Version | WMA7, WMA8, WMA9, WMA9.1, WMA9.2 |
| | | Bit rate/Sampling frequency | Bit rate: Ver. 7, Ver. 8: 32-192kbps, Ver. 9, Ver. 9.1, Ver. 9.2:32-192kbps, VBR<br>Sampling frequency: Ver. 7, Ver. 8:8k/11.025k/16k/22k/32k/44.1k Ver. 9, Ver. 9.1, Ver. 9.2:8k/11.025k/16k/22k/32k/44.1k/48 kHz |
| | AAC*3 | Bit rate/Sampling frequency | Bit rate: 8-256 kbps, VBR<br>Sampling frequency: 11.025-48kHz |
| Tag information (Song title, Artist name and Album name) | | | ID3 tag Ver. 1.0, Ver. 1.1, Ver. 2.2, Ver. 2.3, Ver. 2.4 (MP3 only)<br>WMA tag (WMA only)<br>AAC tag (AAC only) |
| Folder levels | | | CD, CD-R*5, CD-RW*5: Folder levels: 8, Folders: 255 (including root folder), Files: 510 (Max. 255 files for one folder) |
| Displayable character codes*4 | | | 01: SHIFT-JIS, ASCII, ISO-8859-1, UTF-8, UTF-16 BOM, UTF-16 Big Endian, UTF-16 Little Endian, 02: UNICODE, 03: UTF-16 |

*1 Files created with a combination of 48 kHz sampling frequency and 64 kbps bit rate cannot be played.

*2 Protected WMA files (DRM) cannot be played.

*3 Made by iTunes.

*4 Available codes depend on what kind of media, versions and information are going to be displayed.

*5 May not be operated with the Voice Recognition System (where fitted).

☞ "Voice recognition (where fitted)" (page 156)

## Specification chart for USB

| | |
|---|---|
| Supported media | USB2.0 |
| Supported file systems | FAT16, FAT32 |
| Folder levels | Folder levels: 8, Files via folder: 255<br>Folders: 512 or 2500 (including root folder) (depending on the models)<br>Files: 8000 or 32000 (depending on the models) |
| Tag information (Song title, Artist name and Album name) | ID3 tag Ver. 1.0, Ver. 1.1, Ver. 2.2, Ver. 2.3, Ver. 2.4 (MP3 only) |
| | WMA tag (WMA only) |
| | AAC tag (AAC only) |

| **Format** | | | **Sampling frequency** | **Supported bitrate** |
|---|---|---|---|---|
| MP3 *1 | MPEG1 | Layer-3 | 32, 44.1, 48 kHz | 32-320 kbps |
| | MPEG2 | | 16, 22.05, 24 kHz | 8-160 kbps |
| WMA *2 | | | 8, 11.025, 16, 22.05, 32, 44.1, 48 kHz | 12-192 kbps |
| AAC (MPEG4) *3 (Extension “m4a” only) | | | 11.025, 16, 22.05, 32, 44.1, 48 kHz | 8-320 kbps |
| FLAC | | | 8-192 kHz | 128 kbps - 12,288 Mbps |
| WAV | | | 8-192 kHz | 128 kbps - 12,288 Mbps |

*1 MPEG2.5 is not supported.

*2 WMA7, WMA8, WMA9, WMA9.1, WMA9.2 are supported. (WMA9 Professional, Lossless, Voice are not supported.)

*3 Only AAC files encoded by iTunes are supported. HE-AAC (High-Efficiency) is not supported.

## BLUETOOTH® AUDIO

- Some Bluetooth® audio devices may not be recognised by the in-vehicle audio system.
- It is necessary to set up the wireless connection between a compatible Bluetooth® audio device and the in-vehicle Bluetooth® module before using the Bluetooth® audio.
- The Bluetooth® audio may stop playing when
  - receiving a hands-free call.
  - checking the connection to the hands-free phone.
  - connecting the hands-free phone or the audio device.
  - downloading the phonebook memory from the connected mobile phone.
- Do not place a Bluetooth® audio device in an area surrounded by metal or far away from the in-vehicle Bluetooth® module to prevent tone quality degradation and wireless connection disruption.
- While an audio device is connected through a Bluetooth® wireless connection, the battery of the device may discharge quicker than usual.
- This system supports the Bluetooth® Advanced Audio Distribution Profile (A2DP) and Audio/Video Remote Control Profile (AVRCP).
- Wireless LAN (Wi-Fi) and the Bluetooth® functions share the same frequency band (2.4 GHz). Using the Bluetooth® and the wireless LAN functions at the same time may slow down or disconnect the communication and cause undesired noise. It is recommended that you turn off the wireless LAN (Wi-Fi) when using the Bluetooth® functions.

## AUDIO MAIN OPERATION

### Turning the audio system on/off


The ignition switch or power switch must be in the ACC or ON position to turn the audio system on. Push
**<VOL/ ⏻ >/**
**<VOLUME/ ⏻ >/**
**<VOL/PUSH ⏻ >/**
**<VOL/PUSH POWER>** or **<AUDIO>** to turn on the last audio source that was playing immediately before the system was turned off. To turn the audio system off, push **<VOL/ ⏻ >/**
**<VOLUME/ ⏻ >/**
**<VOL/PUSH ⏻ >/**
**<VOL/PUSH POWER>** again.

**INFO:**

The audio system can also be turned on by turning
**<VOL/ ⏻ >/**
**<VOLUME/ ⏻ >/**
**<VOL/PUSH ⏻ >/**
**<VOL/PUSH POWER>** when the system is turned off.

## Selecting the audio source

**Selecting from source menu screen:**




NAVI0004


**Example**

1. Push **<AUDIO>** when the audio screen is displayed.
2. Select an audio source you prefer to play.

**INFO:**

- Touching [Source] on the upper left corner of the audio screen will also display the audio source menu screen.
- When [Rear Display] (where fitted) is selected, audio source will switch to the Rear Entertainment System (RES) (where fitted). However, the image from the HDMI-connected device cannot be displayed on the touch screen display. For details, see the vehicle Owner's Manual.
- Depending on the models, specifications and software versions, the audio source can also be changed by operating the vehicle information display. Refer to the vehicle Owner's Manual for details of the vehicle information display.

**Selecting from Launch Bar:**





5GA0242XZ

**Example**

The source icons are displayed on the Launch Bar. Touch the icon to select the preferred audio source.

**Customising Launch Bar:**

The source icons displayed on the Launch Bar can be customised.




NAVI0006

**Example**


1. Push **<AUDIO>** or touch [Source], while the Audio screen is displayed.
2. Touch [Customise Audio Sources]/[Customize Audio Sources].
3. Drag the preferred source icon to the Launch Bar.
4. Push **<BACK>**/< >/< **BACK>** on the control panel, < **BACK>** on the Display Commander (where fitted) or touch [ ] to confirm the setting.

**Selecting using steering column switch (where fitted):**

For models with **<SOURCE/AUDIO>** on the steering column, the audio source can be changed by pushing the switch.

# RADIO

## Radio operation




PBA0115XZ

**Radio activation and band selection:**

To listen to the radio, turn on the audio system and select a preferred radio band.

"Selecting the audio source" (page 47)

**INFO:**

When the stereo broadcast signal is weak, the radio will automatically change from stereo to monaural reception.

**AM/FM/DAB (where fitted) radio operation:**

General operations of AM, FM, DAB radio are as follows.

Available functions and buttons/switches may vary depending on the models, specifications, software versions and conditions.

| Function | Operation | |
|---|---|---|
| | **Models with fast tuning** | **Models without fast tuning** |
| Manual tuning (AM/FM), selecting service component (DAB) | • Control panel<br>– **<TUNE·SCROLL/SOUND>/<TUNE·SCROLL/ENTER SOUND>/<TUNE·SCROLL/PUSH SOUND>/ <TUNE·SCROLL/ENTER SETTING>/<TUNE SCROLL/OK>**. | • Control panel<br>– Turn **<TUNE SCROLL/SOUND>/<TUNE SCROLL/ENTER SOUND>/<TUNE SCROLL/OK>**.<br>– Push **< ⏮ >/< ⏭ >**. |
| Fast tuning | • Control panel<br>– Push and hold **< ⏮ >/< ⏭ >**. | - |
| Seek tuning | • Control panel<br>– Push **< ⏮ >/< ⏭ >**.<br>• Steering wheel switch<br>– Push and hold **< ⏮ >/< ⏭ >**.<br>– Tilt and hold **< ▲ / ▼ >**. | • Control panel<br>– Push and hold **< ⏮ >/< ⏭ >**.<br>• Steering wheel switch<br>– Push and hold **< ⏮ >/< ⏭ >**.<br>– Tilt and hold **< ▲ / ▼ >**. |
| Presetting stations | • Touch screen display<br>1. Select a radio band.<br>2. Tune to the station you wish to store.<br>3. Touch and hold one of the preset numbers in the preset list on the radio screen.<br>The information such as frequency, etc. will be displayed on the preset list. | |
| Selecting preset stations | • Steering wheel switch<br>– Push **< ⏮ >/< ⏭ >**.<br>– Tilt **< ▲ / ▼ >**.<br>• Touch screen display<br>– Briefly touch a preferred station on the preset list on the radio screen. | |

- To turn on the HD Radio mode (where fitted), touch the HD Radio mode on/off key on the radio screen.
- HD Radio reception needs to be enabled to receive HD Radio broadcasts. This enables you to receive radio broadcasts digitally (where available), providing a better quality sound with clear reception. When this feature is not enabled or HD Radio broadcasts are not available, you will receive analog radio (AM/FM) broadcasts.

## Menu items

Touch [FM Menu], [AM Menu] or [DAB Menu] (where fitted) on each radio screen to display the corresponding menu screen.

Available menu items may vary depending on models, specifications and software versions.

**[FM Menu]:**

| | |
|---|---|
| [TA]* | When this item is turned on, received TA (Traffic Announcement) will interrupt the audio source that is playing. |
| [REG] | When this item is turned on, the system will switch to regional radio programs when detected. |
| [SCAN] | When touched, the stations will be tuned from low to high frequencies and stop at each broadcasting station for several seconds. Touching [SCAN] again during this period of several seconds will stop scan tuning and the radio will remain tuned to that station. |
| [Radio Text] | Displays the radio text information. |
| [Refresh] | Touch to update the station list displayed on the right side of the FM menu screen. |
| Station List | Displays the station list on the right side of the FM menu screen. |

**[AM Menu]:**

| | |
|---|---|
| [TA]* | When this item is turned on, received TA (Traffic Announcement) will interrupt the audio source that is playing. |
| [SCAN] | When touched, the stations will be tuned from low to high frequencies and stop at each broadcasting station for several seconds. Touching [SCAN] again during this period of several seconds will stop scan tuning and the radio will remain tuned to that station. |
| [Radio Text] | Displays the radio text information. |
| [Refresh] | Touch to update the station list displayed on the right side of the AM menu screen. |
| Station List | Displays the station list on the right side of the AM menu screen. |

*: Depending on the models, specifications and software versions, [TA] may be displayed on the main operation screens for some audio sources.

**[DAB Menu] (where fitted):**

| | |
|---|---|
| [TA]* | When this item is turned on, received TA (Traffic Announcement) will interrupt the audio source that is playing. |
| [Radio Text] | Touch to display the radio text information. |
| [Refresh] | Touch to update the station list displayed on the right side of the DAB menu screen. |
| [DAB-FM] | When this item is turned on, the system searches for and tunes to FM stations when DAB reception is poor. |
| Station List | Displays the station list on the right side of the DAB menu screen. |

*: Depending on the models, specifications and software versions, [TA] may be displayed on the main operation screens for some audio sources.

## CD (where fitted), DVD (where fitted), USB memory device, iPod and Bluetooth® audio player

**⚠ WARNING**

**Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.**

**CAUTION**

- **Do not force the USB device into the USB connection port. Depending on the USB connection port, inserting the USB device tilted or upside down may damage the port. Make sure that the USB device is connected correctly into the USB connection port.**
- **Do not grab the USB connection port cover (where fitted) when pulling the USB device out of the port. This could damage the port and the cover.**
- **Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the port.**

### Connection and activation

Activation behaviour varies depending on models, specifications and software versions.

**CD/DVD:**

**Loading**

Insert a disc into the slot with the label side facing up. The disc will be guided automatically into the slot and start playing.

**Activation**

Inserting a disc into the slot will activate the CD/DVD mode. The disc mode can also be selected from the source list with a CD/DVD loaded.

☞ "Selecting the audio source" (page 47)

**USB memory device:**

**Connection**

Connect a compatible USB memory device into the port.

☞ "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23)

Refer to your device manufacturer's owner information regarding the proper use and care of the device.

**Activation**

USB memory device can be played by selecting the source on the audio source menu screen.

☞ "Selecting the audio source" (page 47)

**iPod:**

**Connection**

Connect a compatible iPod to the USB connection port via a USB cable.

☞ "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23)

The battery of the iPod will be charged while the device is connected to the vehicle if the iPod supports charging via a USB connection.

Depending on the device and firmware version of the iPod, the display on the iPod shows a NISSAN or Accessory Attached screen when the connection is completed. When the iPod is connected to the vehicle, the iPod music library can only be operated by the vehicle audio controls.

**Activation**

The iPod can be played by selecting the source on the audio source menu screen.

☞ "Selecting the audio source" (page 47)

**BLUETOOTH® AUDIO:**

Your vehicle is equipped with Bluetooth® Audio.

If you have a compatible Bluetooth® device with streaming audio capability (A2DP profile), you can set up a wireless connection between your Bluetooth® device and the in-vehicle audio system. This connection allows you to listen to the audio from the Bluetooth® device using your vehicle speakers. It also may allow basic control of the device for playing and skipping audio files using the AVRCP Bluetooth® profile. Not all Bluetooth® devices have the same level of controls for AVRCP. Please consult the manual for your Bluetooth® device for more details.

**Connection**

Connect a compatible streaming audio capable Bluetooth® device (A2DP profile) to set up a wireless connection between the Bluetooth® device and the in-vehicle system. Bluetooth® connection can be set up from the Connections screen.

☞ "Setting Bluetooth®" (page 30)

**INFO:**


- Depending on the Bluetooth® audio device that is connected, it may not be possible to perform audio operations or a delay may occur before music is played back.
- Not all Bluetooth® devices have the same level of controls for AVRCP. Consult the manual for your Bluetooth® device for more details.
- Wireless LAN (Wi-Fi) and the Bluetooth® functions share the same frequency band (2.4 GHz). Using the Bluetooth® and the wireless LAN functions at the same time may slow down or disconnect the communication and cause undesired noise. It is recommended that you turn off the wireless LAN (Wi-Fi) when using the Bluetooth® functions.

**Activation**

A Bluetooth® audio device can be played by selecting the source on the audio source menu screen.

☞ "Selecting the audio source" (page 47)

## CD, DVD, USB memory device, iPod and Bluetooth® audio operation




PBA0114XZ

General operations of CD, DVD, USB memory device, iPod and Bluetooth® audio are as follows. Available functions and buttons/switches may vary depending on the models, specifications, software versions and conditions.

| Function | Operation | Applicable source |
|---|---|---|
| Play | • Touch screen display<br>– Touch [ ▶ ]. | CD, DVD, USB, iPod, Bluetooth® audio |
| Pause | • Touch screen display<br>– Touch [ ❚❚ ]. | CD, DVD, USB, iPod, Bluetooth® audio |
| Stop playing | • Touch screen display<br>– Touch [ ■ ]. | DVD |
| Skipping tracks | • Control panel<br>– Push **<** ⏮ **>/<** ⏭ **>**.<br>– Turn **<TUNE·SCROLL/SOUND>/<TUNE·SCROLL/ENTER SOUND>/<TUNE·SCROLL/PUSH SOUND>/<TUNE·SCROLL/ENTER SETTING>/<TUNE SCROLL/OK>***.<br>• Steering wheel switch<br>– Push **<** ⏮ **>/<** ⏭ **>**.<br>– Tilt **<** ▲ / ▼ **>**.<br>• Steering column switch<br>– Scroll the tuning wheel.<br>• Touch screen display<br>– Touch **[** ⏮ **]/[** ⏭ **]**.<br>*: Depending on the models, turning **<TUNE·SCROLL/SOUND>/<TUNE·SCROLL/ENTER/SOUND>/<TUNE·SCROLL/PUSH/SOUND>/<TUNE·SCROLL/OK>** may change folders when available. | CD, USB, iPod, Bluetooth® audio |

| Function | Operation | Applicable source |
|---|---|---|
| Skipping chapters | • Control panel<br>– Push < ⏮ >/< ⏭ >.<br>• Steering wheel switch<br>– Push < ⏮ >/< ⏭ >.<br>– Tilt < ▲ / ▼ >.<br>• Touch screen display<br>– Touch [ ⏮ ]/[ ⏭ ]. | DVD |
| Skipping commercial messages | • Touch screen display<br>– Touch [⏮]/[⏭]. | DVD |
| Skipping titles/groups | • Steering wheel switch<br>– Push and hold < ⏮ >/< ⏭ >. | DVD |
| Rewinding/fast-forwarding | • Control panel<br>– Push and hold < ⏮ >/< ⏭ >.<br>• Steering wheel switch<br>– Push and hold < ⏮ >/< ⏭ >*.<br>– Tilt and hold < ▲ / ▼ >.<br>• Touch screen display<br>– Touch and hold [ ⏮ ]/[ ⏭ ].<br>*: Not available for DVD. | CD, DVD, USB, iPod, Bluetooth® audio |
| Changing play mode | • Touch screen display<br>– Touch [🔁] to change the repeat mode.<br>– Touch [🔀]* to change the random mode.<br>*: Not available for DVD. | CD, DVD, USB, iPod, Bluetooth® audio |
| Ejecting disc | • Control panel<br>– Push < ⏏ > to eject a disc when the ignition switch or power switch is placed in the ACC or ON position. | CD, DVD |

## Menu items

Touch [CD Menu], [DVD Menu], [USB Menu], [iPod Menu] and [BT Menu] on each audio screen to display the corresponding audio menu screen. Available setting items may vary depending on models, specifications, software versions and the connected audio device. Depending on the connected Bluetooth® device, [BT Menu] may not be displayed.

**[CD Menu]:**

| | |
|---|---|
| [TA]* | When this item is turned on, received TA (Traffic Announcement) will interrupt the audio source that is playing. |
| [Now Playing] | Touch to display the CD screen. |
| Folder and track list | The track list for the selected folder is displayed. The name of sub folder is displayed on the top of the list if the sub folder is included in the selected folder.<br>Touch an item on the list to select the folder or track.<br>Touch [ ↩ ] and go back to the previous screen. |

*: Depending on the models, specifications and software versions, [TA] may be displayed on the main operation screens for some audio sources.

**[DVD Menu]:**

| Menu item | Action | |
|---|---|---|
| [TA]* | When this item is turned on, received TA (Traffic Announcement) will interrupt the audio source that is playing. | |
| [Key]/[Control Keys] | Displays the control keys on the screen. Touch < ▲ >< ▼ >< ▶ >< ◀ > to select the items displayed on the screen. Touch <OK> to execute the selected item. Control keys can be moved to the left/right on the screen by touching [Move] in the control key area, and the control keys can be hidden by touching [Hide]. | |
| [Title Menu] | Displays the title menu. | |
| [Title List] | Displays the title list. | |
| [Title Search] | Touch [+] or [-] to select the chapter number you wish to search for. | |
| [Select No.] | Displays the keyboard screen. Enter the list number you wish to play. | |
| [10Key Search] | Displays the keyboard screen. Enter the desired chapter and title number and touch [OK].<br>Touch [<] or [>] to switch the title/chapter. | |
| [Display Settings]/<br>[Display Adjustment] | [Brightness] | Adjusts the brightness. |
| | [Contrast] | Adjusts the contrast. |
| | [Colour]/[Color] | Adjusts the colour. |
| | [Black Level] | Adjusts the black level. |
| [Display Mode] | Touch to select a display mode from [Normal], [Cinema] and [Full]. | |
| [Voice] | Touch [+] or [-] to select a preferred language. | |
| [Subtitle]/[Subtitles] | Touch [+] or [-] to select a subtitle setting from the available options. | |
| [Angle] | Touch [+] and [-] to adjust the angle. | |
| [Angle Mark] | Turns on/off the angle mark displayed on the screen. | |
| [Menu Skip] | Turns on/off the menu skip mode. | |
| [CM Skip] | Touch [+] or [-] to set the length of the CM skip duration. | |
| [Dynamic Range Control] | Touch [+] or [-] to change the Dynamic Range Control setting. Dynamic Range Control tunes the dynamic range of sound recorded in the Dolby Digital format. | |
| [DVD Language] | Touch [+] or [-] to change the DVD menu language. | |

| Menu item | Action |
|---|---|
| PG/PL Mode | Touch [ ▶ ] or [ ◀ ] to switch the PG/PL mode. |

*: Depending on the models, specifications and software versions, [TA] may be displayed on the main operation screens for some audio sources.

**[USB Menu]:**

| | |
|---|---|
| [TA]* | When this item is turned on, received TA (Traffic Announcement) will interrupt the audio source that is playing. |
| [Now Playing] | Touch to display the USB screen. |
| [Folder List] | Touch to display the folder list. Touch an item on the list to select the folder.<br>The sub-folder or track list will be displayed. Select a sub-folder or track from the list. |
| [Album Artwork] | Touch to turn on/off the album artwork display on the USB screen. |
| [Playlists] | Touch to display the list according to the selected item. |
| [Artists] | |
| [Albums] | |
| [Songs] | |
| [Genres] | |
| [Composers] | |

*: Depending on the models, specifications and software versions, [TA] may be displayed on the main operation screens for some audio sources.

**[iPod Menu]:**

| | |
|---|---|
| [TA]* | When this item is turned on, received TA (Traffic Announcement) will interrupt the audio source that is playing. |
| [Now Playing] | Touch to display the iPod screen. |
| [Current List] | Touch to display the current list. A list of tracks in the currently selected category is displayed. |
| [Album Artwork] | Touch to turn on/off the album artwork display on the iPod screen. |
| [Playlists] | Touch to display the list according to the selected item. |
| [Artists] | |
| [Albums] | |
| [Songs] | |
| [Genres] | |
| [Composers] | |
| [Audiobooks] | |
| [Podcasts] | |

**[BT Menu]:**

| | |
|---|---|
| [TA]* | When this item is turned on, received TA (Traffic Announcement) will interrupt the audio source that is playing. |
| [Now Playing] | Touch to display the Bluetooth® audio screen. |
| [Album Artwork] | Touch to turn on/off the album artwork display on the Bluetooth® audio screen. |
| [Current List] | Touch to display the current list. A list of tracks in the currently selected folder is displayed. |
| [Connections] | Touch to display the Connections screen.<br>☞ "Connections settings" (page 30) |
| Folder list | Touch to display the folder list. Touch an item on the list to select the folder. |

*: Depending on the models, specifications and software versions, [TA] may be displayed on the main operation screens for some audio sources.

## AUXILIARY (AUX) DEVICES (where fitted)

### Connection and activation

**Connection:**

Connect an AUX device to the AUX input jack via an AUX cable.

AUX input jack location:

☞ "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23)

The AUX input jack accepts any standard analogue audio input such as from a portable cassette player, CD player or MP3 player.

**INFO:**

Insert a 3.5 mm (1/8 in) stereo mini plug in the audio input jack. If a cable with a mono plug is used, the audio output may not function normally.

**Activation:**

Turn on an AUX device and connect the device to the AUX input jack. Select the AUX mode from the audio source menu screen.

☞ "Selecting the audio source" (page 47)

**Changing volume:**

On the AUX screen, touch one of the volume setting menus to select the sound output gain.

## SMARTPHONE AUDIO (where fitted)

You can also listen to music from your compatible smartphone using Apple CarPlay or Android Auto.

☞ "Apple CarPlay (where fitted)" (page 95)

☞ "Android Auto™ (where fitted)" (page 100)

### Connecting smartphone

Connect the iPhone or Android phone to the USB connection port.

☞ "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23)

Depending on the models, iPhone devices can also be connected wireless for Apple CarPlay.

☞ "Apple CarPlay (where fitted)" (page 95)

### Smartphone audio operation

1. Connect the iPhone or Android phone to the USB connection port and activate Apple CarPlay or Android Auto.

   ☞ "Apple CarPlay operation" (page 95)

   ☞ "Android Auto™ (where fitted)" (page 100)

2. Connect the iPhone or Android phone and activate Apple CarPlay or Android Auto.
3. Push **<AUDIO>**.
4. Touch [Source].
5. Touch [Apple CarPlay] or [Android Auto] in the audio source menu screen, and the smartphone audio starts activating.

   ☞ "Selecting the audio source" (page 47)

# AUDIO SETTINGS

Audio settings can be adjusted or audio related functions can be turned on/off with the following procedure.


Touch [Sound] on the setting menu screen.

☞ "System settings" (page 28)

Available setting items may vary depending on models, specifications and software versions.

| **Setting items** | **Action** |
|---|---|
| [Bass] | Adjust the speaker tone quality and sound balance by touching [-]/[+], [L]/[R] or [R]/[F]. |
| [Mid]/[Middle] | |
| [Treble] | |
| [Balance] | |
| [Fader]/[Fade] | |
| [Bass Enhancer] | When this item is turned on, the system enhances bass sound. |
| [Speed-Sensitive Volume]/ [Speed Sensitive Volume] | Automatically adjusts the volume depending on the vehicle speed. Touch [-]/[+] to change the sensitivity level. |
| [PersonalSpace] | Adjust the audio settings to best optimise the sound for the driver's listening position. |
| [Bose Centerpoint] | When this item is turned on, surround sound playback is generated from a traditional stereo recording. Turn on this item to activate Bose Centerpoint and to change its effect level with [Surround Volume]. |
| [Surround Volume] | Touch [+]/[-] to adjust the Surround Volume level if Bose Centerpoint is turned on. |

## AUDIO ADJUSTMENTS WITH AUDIO ADJUST BAR (where fitted)




5GA0198XZ

**Example**

Sound quality can be adjusted with the following buttons.

- **<TUNE·SCROLL/SOUND>***
- **<TUNE·SCROLL/ENTER SOUND>***
- **<TUNE·SCROLL/PUSH SOUND>***
- **<TUNE·SCROLL/ENTER SETTING>***
- **<TUNE·SCROLL/OK>***
- **</ENTER SOUND>***
- **</SOUND>***
- **</OK>***

*: where fitted

When the list screen is not displayed, pushing any of the buttons listed above will display the audio adjustment bar. Each time the button is pushed, the menu will shift to the available setting items.

- **Type A:**

  [Bass] → [Mid] → [Treble] → [Balance] → [Fade]

- **Type B:**

  [Bass] → [Treble] → [Space] (PersonalSpace)

- **Type C:**

  [Bass] → [Treble] → [Balance] → [Fade]


Turn the button to adjust the level of the selected setting item.

**INFO:**

This function may not be available when a menu is highlighted on the screen.

## CD/DVD/USB MEMORY DEVICE CARE AND CLEANING

### CD/DVD (where fitted)



SAA0451Z

- Handle a disc by its edges. Never touch the surface of the disc. Do not bend the disc.
- Always place the discs in the storage case when they are not being used.
- To clean a disc, wipe the surface from the centre to the outer edge using a clean, soft cloth. Do not wipe the disc using a circular motion.

  Do not use a conventional record cleaner or alcohol intended for industrial use.
- A new disc may be rough on the inner and outer edges. Remove the rough edges by rubbing the inner and outer edges with the side of a pen or pencil as illustrated.

## USB MEMORY DEVICE

- Never touch the terminal portion of the USB memory device.
- Do not place heavy objects on the USB memory device.
- Do not store the USB memory device in highly humid locations.
- Do not expose the USB memory device to direct sunlight.
- Do not spill any liquids on the USB memory device.

Refer to the USB memory device Owner's Manual for the details.

# 4 Hands-free phone


Bluetooth® Hands-Free Phone System ..... 66
Phone screen ..... 67
Indicators ..... 67
Phone ..... 68
Hands-free text messaging assistant (where fitted) ..... 70
Phone and text message settings ..... 74

**⚠ WARNING**

- **Use a phone after stopping your vehicle in a safe location. If you have to use a phone while driving, exercise extreme caution at all times so full attention may be given to vehicle operation.**
- **If you find yourself unable to devote full attention to vehicle operation while talking on the phone, pull off the road to a safe location and stop your vehicle before doing so.**

**CAUTION**

**To avoid draining the vehicle battery (12V battery), use a phone only after starting the engine or e-POWER system.**

Your vehicle is equipped with Bluetooth® Hands-Free Phone System. If you are an owner of a compatible Bluetooth® enabled mobile phone, you can set up the wireless connection between your mobile phone and the in-vehicle phone module. With Bluetooth® wireless technology, you can make or receive a phone call with your mobile phone in your pocket.

Once a mobile phone is connected to the in-vehicle phone module, the procedure for connecting the phone does not need to be performed again. Your phone is automatically selected with the in-vehicle phone module when the ignition switch or power switch is placed in the ACC or ON position with the selected mobile phone turned on and carried in the vehicle.

You can register up to 6 different Bluetooth® devices in the in-vehicle phone module. However, you can talk on only one mobile phone at a time.

The Voice Recognition System (where fitted) supports phone commands, so dialling a phone number using your voice is possible.

☞ "Voice recognition (where fitted)" (page 156)

Before using the Bluetooth® Hands-Free Phone System, refer to the following notes.

- Wireless LAN (Wi-Fi) and the Bluetooth® functions share the same frequency band (2.4 GHz). Using the Bluetooth® and the wireless LAN functions at the same time may slow down or disconnect the communication and cause undesired noise. It is recommended that you turn off the wireless LAN (Wi-Fi) when using the Bluetooth® functions.
- Set up the wireless connection between a compatible mobile phone and the in-vehicle phone module before using the Bluetooth® Hands-Free Phone System.
- Some Bluetooth® enabled mobile phones may not be recognised by the in-vehicle phone module.

  Consult a NISSAN dealer or qualified workshop for phone compatibility.
- You will not be able to use a hands-free phone under the following conditions:
  - Your vehicle is outside of the phone service area.
  - Your vehicle is in an area where it is difficult to receive radio waves; such as in a tunnel, in an underground parking garage, behind a tall building or in a mountainous area.
  - Your mobile phone is locked in order to prevent dialling.
- When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
- Immediately after the ignition switch or power switch is placed in the ACC or ON position, it may be impossible to receive a call for a short period of time.
- Do not place the mobile phone in an area surrounded by metal or far away from the in-vehicle phone module to prevent tone quality degradation and wireless connection disruption.
- While a mobile phone is connected through the Bluetooth® wireless connection, the battery power of the mobile phone may discharge quicker than usual.
- Consult a NISSAN dealer or qualified workshop if the Bluetooth® Hands-Free Phone System seems to be malfunctioning.
- Some mobile phones or other devices may cause interference or a buzzing noise to come from the audio system speakers. Storing the device in a different location may reduce or eliminate the noise.

- Refer to the mobile phone Owner's Manual regarding the phone pairing procedure specific to your phone, battery charging, mobile phone antenna, etc.
- The antenna display on the screen may not coincide with the antenna display of some mobile phones.
- The battery display on the screen may not coincide with the battery display of some mobile phones.
- The microphone is located near the map light.
- Keep the interior of the vehicle as quiet as possible to hear the caller's voice clearly as well as to minimise its echoes.
- If reception between callers is unclear, adjusting the outgoing call volume may improve the clarity.

## PHONE SCREEN

The phone screen can be displayed by following the operations.

- Push < > on the control panel*
- Push < >/< > on the steering wheel*
- Push < /> on the steering column*
- Touch [Phone] on the Launch Bar

*:where fitted

**Available items**


Available items may vary depending on models, specifications and software versions. Items displayed on the screen may not function depending on various conditions.

| Menu item | Action |
|---|---|
| [Quick Dial] | Displays the Quick Dial screen. ☞ "Making a call" (page 68) |
| [Phone Book]/ [Phonebook] | Displays the phone book screen. ☞ "Making a call" (page 68) |
| [Call History] | Displays the call history screen. ☞ "Making a call" (page 68) |
| [Dial Number] | Displays the phone number entry screen. ☞ "Making a call" (page 68) |
| [Text Message] | Displays the received message list screen. ☞ "Displaying received message list" (page 71) |
| [Connections] | Displays the connections screen. ☞ "Setting Bluetooth®" (page 30) |
| [Volume] | Displays the volume adjustment screen. ☞ "Volume settings" (page 76) |

**INFO:**

Depending on the connected device, some functions cannot be used.

## INDICATORS




5GF0120XZ

**Example**

When a mobile phone is connected through the Bluetooth® wireless connection, indicators ① for phone and text messaging (where fitted) are displayed on the top of the screen.

Available indicators may vary depending on models, specifications and software versions.

| | |
|---|---|
| 1 | Indicates the number of unread received messages. |
| 1 | Indicates the Bluetooth® device that is currently connected. |
| | Indicates that Bluetooth® device(s) are connected. |
| | Indicates the strength of the signal the Bluetooth® device is receiving. |
| | Indicates the amount of remaining Bluetooth® device battery. |

# PHONE

## Connecting Bluetooth® Hands-Free Phone

A mobile phone device must be connected to the Bluetooth® Hands-Free Phone System before operation. Up to 6 Bluetooth® devices can be registered to the system.

"Setting Bluetooth®" (page 30)

**INFO:**

When connected to Apple CarPlay or Android Auto (where fitted), Bluetooth® cannot be used.

## Phone selection

Follow the instructions below to select a connected device for use with the Bluetooth® Hands-Free Phone System:

1. Touch [Phone] on the Launch Bar.
2. Touch [Connections] and touch [Bluetooth]. A list of the connected mobile phones is displayed.
3. Touch one of the connected mobile phones from the list.

   When the connection is successful, "Connected" is displayed under the device name.

   If [] is displayed in grey, touch [].

**INFO:**

To select a phone, the Bluetooth® of the mobile phone needs to be turned on.

## Making a call

1. Touch [Phone] on the Launch Bar.
2. Select one of the following methods to make a call.


| | |
|---|---|
| [Quick Dial] | Select a phone number registered as a Quick Dial number.<br>"Quick Dial" (page 76) |
| [Phone Book]/ [Phonebook] | Select a person and the phone number you wish to call from the phonebook.<br>Depending on the device, the phonebook will be downloaded from the mobile phone automatically when it is connected. If the automatic download does not take place, the phone number must be transferred to the hands-free phone system from the mobile phone prior to using this method.<br>"Phone settings" (page 74) |
| [Call History] | Select a phone number from recent incoming, outgoing or missed calls. |
| [Dial Number] | Enter the phone number manually using the keypad displayed on the screen. |

**INFO:**

With models capable of connecting with two hands-free phones simultaneously via Bluetooth®, either of the connected phone devices can be selected for dialling operation when [Allow 2 Phones Simultaneously] is turned on.

"Bluetooth® settings" (page 31)

## Receiving a call




5GF0098XZ

When you receive a phone call, the display switches to the Incoming Call screen and the ringtone is played through the vehicle's audio system.

**Taking a call:**

To answer the call, take one of the following actions.

- Push < >/< > (where fitted) on the steering wheel.
- Push < > (where fitted) on the steering column.
- Touch [Answer].

**Rejecting a call:**

To reject the call, take one of the following actions.

- Push and hold **<** **>** (where fitted) on the steering wheel.
- Push **<** **>**. (where fitted) on the steering wheel.
- Touch [Decline].

**Holding a call:**

To hold the call, touch [Hold Call].

**INFO:**

With models capable of connecting with two hands-free phones simultaneously via Bluetooth®, if [Allow 2 Phones Simultaneously] is turned on, two hands-free phone devices can be connected at the same time. If one of the connected devices receives an incoming call while the other device is already online, a pop-up message will appear to inform that answering the call will hang up the line of the other connected device. Touch [Answer] to answer the call and hang up the line on the other device. Touch [Decline] to continue the conversation on the other device.

## During a call




5GF0117XZ

**Example**

The Call in Progress screen will appear during a call.

To hang up the phone, touch [Hang Up]/[Hang up].

**Operations during a call:**

There are some options available other than hanging up a call or answering/rejecting incoming calls.

Touch one of the following displayed keys on the screen to take action.


| Available item | Action |
|---|---|
| [Use Handset] | Transfer the call to the mobile phone. |
| [Mute] | When muted, your voice will not be heard by the person on the other end of the line. |
| [Dial Number] | Using the touch tone, send digits to the connected party for using services such as voicemail. |
| [Switch Call]* | Answer another incoming call. The person you are talking to will be placed on hold. Touch once more to speak to the person on hold again. |

*: Available when a call is received while on the line with another person. The availability of this function depends on the mobile phone.

**INFO:**

To adjust the person's voice to be louder or quieter, push **<** **>** (where fitted) on the steering wheel, push **<** **>** (where fitted) on the steering column from behind, or turn
**<VOL/ >/**
**<VOLUME/ >/**
**<VOL/PUSH >/**
**<VOL/PUSH POWER>** on the control panel while talking on the phone.

**Call from a second person:**




5GF0100XZ

When another phone call is received during a call, the Call Waiting screen will appear.

**Answering call from a second person:**

To answer the call from the second person and place the first caller on hold, take one of the following actions.

- Push < >/< > (where fitted) on the steering wheel.
- Push < / / > (where fitted) on the steering column.
- Touch [Answer].

**Rejecting call from a second person:**

To reject a call from the second person and continue the conversation with the first caller, touch [Decline].

**During a call with a second person:**




5GF0118XZ

**Example**

To hang up the phone and return to the conversation with the first caller, touch [Hang Up]/[Hang up].

To switch between two calls on line, touch [Switch Call].

## HANDS-FREE TEXT MESSAGING ASSISTANT (where fitted)

**⚠ WARNING**

- **Use the text messaging feature after parking your vehicle in a safe location. If you have to use the feature while driving, exercise extreme caution at all times so full attention may be given to vehicle operation.**
- **Laws in some jurisdictions may restrict the use of "Text-to-Speech." Check local regulations before using this feature.**
- **Laws in some jurisdictions may restrict the use of some of the applications and features, such as social networking and texting. Check local regulations for any requirements.**
- **If you are unable to devote full attention to vehicle operation while using the text messaging feature, pull off the road to a safe location and stop your vehicle.**


**CAUTION**

**This feature is disabled if the connected device does not support it. See the phone's Owner's Manual for details and instructions.**

The system allows for the sending and receiving of text messages through the vehicle interface.

The availability of the text message function may vary depending on the mobile phone.

## Receiving a message




5GF0102XZ

When the mobile phone connected to the vehicle receives a text message, a notification will appear on the touch screen display and on the vehicle information display with a tone (depending on the model, the notification will also appear on the vehicle information display).

To check the message, touch [Read]. Touch [Ignore] to save the message to be checked later.

If you want to respond using a predefined message, touch the message for auto reply ①.


The text message for auto reply can be edited.

"Phone settings" (page 74)

**INFO:**

- Depending on the mobile phone, the notification display setting may need to be activated on the mobile phone.
- The received messages can also be read/ignored (where fitted) with the following switch operations.
  **Models with < > on the steering wheel:**
  Push < > to read the message. To ignore the message, push and hold < >.
  **Models with < > on the steering wheel:**
  Push < > to read the message. To ignore the message, push <>.
- **Models with < / / > on the steering column:**
  Push < / / > to read the message.

## Displaying received message list




5GF0121XZ

1. Touch [Phone] on the Launch Bar.
2. Touch [Text Message].
3. Touch an item on the list to read or reply to the message.

**INFO:**

- Up to 100 messages can be stored in the message list.
- With models capable of connecting with two hands-free phones simultaneously via Bluetooth®, either of the connected phone devices can be selected for text message viewing operation when [Allow 2 Phones Simultaneously] is turned on.

"Bluetooth® settings" (page 31)

## Received message screen




5GF0122XZ

Touching [Read] on the new message notification screen or selecting a message from the message list will show the details of the received message on the display.

**Available actions:**

- [Prev.]:

  Touch to read the previous message.

- [Next]:

  Touch to read the next message.

- [Play]/[Stop]:

  Touch [Play] to have the hands-free phone system read out the received message. Touch [Stop] to stop reading.

- [Call]:

  If the sender of the message is registered in the phonebook, touch this icon to make a call to the sender.

- [Reply]:

  A reply message can be selected from the template.


  "Sending a text message" (page 72)

**INFO:**

- Depending on the models, push **< ⏮ >/< ⏭ >** (where fitted) on the steering wheel to read the previous or next message.
- Depending on the models, the text message can also be viewed and be operated on the vehicle information display. Refer to the vehicle Owner's Manual for details of the vehicle information display.
- Depending on the language setting, the "Text-to-Speech" function may not be available.
- Available keys may vary depending on the situations and models.
- If the sender's name and phone number are registered in the phonebook, the name of the sender is displayed when a message is received.
- To adjust the message reading voice volume, push **<** 🔊 **>** (where fitted) on the steering wheel, push **<** 🔊 **>** (where fitted) on the steering column from behind or turn
  **<VOL/** ⏻ **>/**
  **<VOLUME/** ⏻ **>/**
  **<VOL/PUSH** ⏻ **>/**
  **<VOL/PUSH POWER>** on the control panel.

## Sending a text message

This function may not be supported depending on the mobile phone.




5GF0109XZ

1. Touch [Phone] on the Launch Bar.
2. Touch [Text Message].
3. Touch [Create Message].

**INFO:**

With models capable of connecting with two hands-free phones simultaneously via Bluetooth®, either of the connected phone devices can be selected for text message viewing operation when [Allow 2 Phones Simultaneously] is turned on.

"Bluetooth® settings" (page 31)

The following items are available.

| Available item | | Action |
|---|---|---|
| [To] | [Enter Number with Keypad]/ [Enter Number by Keypad] | Enter the phone number of the recipient using the keypad. Touch [OK] to confirm. |
| | [Quick Dial] | Select a recipient from the Quick Dial list. |
| | [Phone Book]/[Phonebook] | Select a recipient from the phonebook. |
| | [Call History] | Select a recipient/phone number from call history. |
| [Select Text] | [Fixed] | Touch to display a list of fixed text messages. |
| | [Customised]/[Customized] | Touch to display a list of custom text message templates.<br>Custom text can be created or edited from the setting menu.<br>☞ "Phone and text message settings" (page 74) |
| [Send] | | Touch to send the message. |

# PHONE AND TEXT MESSAGE SETTINGS

## Phone settings

Bluetooth® Hands-Free Phone System settings can be changed according to the user's preference.

Touch [Phone] on the setting menu screen.

☞ "System settings" (page 28)

Available setting items may vary depending on models, specifications and software versions.

**Available setting items**

| **Setting item** | | **Action** |
|---|---|---|
| [Connections] | | Displays the Connections screen. Phone connection, selection, deletion and other features are available.<br>☞ "Connections settings" (page 30) |
| [Quick Dial] | [Edit] | Entries in the Quick Dial can be edited. Touch [Add New] to register a new entry.<br>☞ "Quick Dial" (page 76) |
| | [Delete All] | Deletes all of the phone numbers in the Quick Dial. |
| [Phone Book]/[Phonebook] | [Download Entire Phone Book]/ [Download Entire Phonebook] | All of the phone numbers that are stored in a phonebook of a mobile phone that is connected to the vehicle are downloaded at once. |
| | [Auto Download]/ [Auto Downloaded] | Turns on/off automatic downloading of the phonebook from the connected mobile phone. |
| | [Sort Phone Book by]/ [Sort Phonebook by] | Changes the sorted order of contacts in the phonebook. |

| | | |
|---|---|---|
| [Text Message] | [Text Message] | Turns the text messaging function on/off. |
| | [Text Message Ringtone] | Turns the incoming message sound on/off. |
| | [Signature] | Turns the signature setting for the outgoing text message on/off. |
| | [Auto Reply] | Turns the automatic text message reply function on/off. |
| | [Auto Reply Text Message] | Selects the text message to be used for the automatic reply function. |
| | [Edit Custom Text] | Creates or edits a customised text message reply. |
| [Notifications] | [Driver Only] | When this item is turned on, incoming call notification is displayed only in the vehicle information display. |
| | [Vehicle Ringtone] | Turns the vehicle ringtone on/off. |
| [Automatic Hold] | | When this item is turned on, an incoming phone call will be put on hold automatically. |

**INFO:**

The setting of [Driver Only] is unavailable while Apple CarPlay (where fitted), Android Auto (where fitted) or Yandex.Auto (where fitted) is active.

## Volume settings

Volume settings can be adjusted.

1. Touch [Phone] on the Launch Bar.
2. Touch [Volume].

The following volume setting items are available.


| Setting items | Action |
|---|---|
| [Ringtone] | Adjusts the volume level of the ringtone of incoming calls. |
| [Outgoing Call] | Adjusts the volume level of the outgoing calls. |

**INFO:**

The volume settings can also be accessed from the setting menu screen.

"System settings" (page 28)

## Quick Dial




5GF0107XZ

Up to 20 Quick Dial entries can be registered.

Quick Dial entries can be used to quickly make a call or send text messages.

**Registration:**

1. Touch [Phone] on the Launch Bar.
2. Touch [Quick Dial].
3. Touch [Edit].
4. Touch [Add New] to register a phone number to the Quick Dial list.
5. Select a method for registration.

   **Available methods:**

   - [Copy from Call History]:

     A phone number can be selected from [All], [Incoming], [Outgoing], or [Missed] call history lists.

   - [Copy from Phone Book]/[Copy from Phonebook]:

     A phone number can be selected from the phonebook.

   - [Enter Number with Keypad]/[Enter Number by Keypad]:

     A phone number can be entered manually using the keypad.

**INFO:**

Available methods may vary depending on mobile phone support.

6. When a phone number has been selected, the registration screen is displayed. Enter the phone number and edit the entry information as necessary.
7. Touch [OK] to save the entry.

**INFO:**

- Quick Dial entries can also be registered from [Phone] on the setting menu screen.


  "Phone settings" (page 74)

- With models capable of connecting with two hands-free phones simultaneously via Bluetooth®, either of the connected phone devices can be selected for dialling operation when [Allow 2 Phones Simultaneously] is turned on.

  "Bluetooth® settings" (page 31)

**Voice Tag (where fitted):**

A voice tag can be recorded for each of the registered Quick Dial numbers and can be used to dial the number by speaking it.




5GF0119XZ

On the Quick Dial registration screen, select [Relationship/Voice Tag].

- Select a preferred relationship from the list.
- Touch [Customise]/[Customize] and touch [Record] to register your original voice tag.

**INFO:**

- Touch [Play] to play the recorded voice tag.
- Touch [Delete] to delete the voice tag.

MEMO

# 5 Information


Information menu ..... 80
Updating system software (where fitted) ..... 83
NissanConnect Services (where fitted for Europe, Russia and Ukraine) ..... 85
Privacy policy NissanConnect Services ..... 85
NissanConnect Menus ..... 85
NissanConnect settings ..... 86
NissanConnect Services powered by SiriusXM™ (where fitted for Mexico) ..... 86
Subscription to NissanConnect Services ..... 86
Important information regarding access to NissanConnect Services ..... 86
NissanConnect Services features ..... 88
NissanConnect Services menus ..... 91
Emergency support (where fitted) ..... 92
NissanConnect Services settings ..... 94
Apple CarPlay (where fitted) ..... 95
Compatibility ..... 95
Apple CarPlay operation ..... 95
Apple CarPlay settings ..... 98
Apple CarPlay system limitations ..... 100
Android Auto™ (where fitted) ..... 100
Compatibility ..... 100
Initial Android Auto settings ..... 101
Android Auto operation ..... 101
Android Auto settings ..... 102
Android Auto system limitations ..... 103
Yandex.Auto powered by Bosch (where fitted) ..... 103
Compatibility ..... 103
Initial Yandex.Auto settings ..... 103
Yandex.Auto operation ..... 104
Yandex.Auto settings ..... 105
Yandex.Auto system limitations ..... 106
Siri Eyes Free (where fitted) ..... 106
Requirements ..... 106
Siri Eyes Free activation ..... 106
Operating Siri Eyes Free ..... 106

The information screen sets or displays various information.

Push <MENU>/<MODE/OK> (where fitted) and then touch [Info] on the Launch Bar to display the Information menu.

Available items may vary depending on models, specifications and software versions. Items displayed on the screen may not function depending on various conditions.

**Models with navigation system:**

| **Menu item** | | **Action** |
|---|---|---|
| [Vehicle] | [Energy Flow] | Displays energy information. Touch [History] to display the Fuel Economy History screen.<br>For details of the Energy Flow, refer to the vehicle Owner's Manual. |
| | [ECO Drive Report] | Displays the Eco Drive Report screen.<br>Your driving score will be displayed in real time, with 100 points designated as the score for ideal eco-driving.<br>Touch [History] to view the drive report history. Touch [Reset] to clear the past records.<br>To improve your score:<br>• When starting off, depress the accelerator gently.<br>• When cruising, accelerate and decelerate as little as possible.<br>• When decelerating, release the accelerator early. |
| [NissanConnect Services] | | Displays the NissanConnect Services menu screen.<br>☞ "NissanConnect Services (where fitted for Europe, Russia and Ukraine)" (page 85)<br>☞ "NissanConnect Services powered by SiriusXM™ (where fitted for Mexico)" (page 86) |
| [Traffic Information]/[Premium Traffic] | | Displays the Traffic Information screen.<br>☞ "Viewing traffic information (where fitted)" (page 132) |
| [Where Am I?] | | The name and distance of the next/previous street, and other information that indicates the current vehicle location are displayed. Latitude and longitude of the current vehicle location are shown on the bottom right. |

| Menu item | | Action |
|---|---|---|
| [Weather] | [Current Conditions] | Current, hourly or 5-day weather information is displayed. |
| | [Hourly Weather Forecast] | Weather information for nearby location, near the destination and your preferred city set as a Favourite City can be confirmed. |
| | [5-Day Weather Forecast] | Current, hourly or 5-day weather information can be changed by touching [Current], [Hourly] or [5-Day].<br>Nearby location, near the destination and your preferred city can be changed by touching [Nearby], [Near Dest.] or [Favourite City]/[Favorite City].<br>Favourite city can be changed by touching [Change City]. |
| | [Communication Settings] | Turns the TomTom weather data transmission on/off. |
| [System Information] | [Software Version]/ [Version Information] | Displays the version information screen. |
| | [Software Update] | The system software can be updated.<br>☞ "Updating system software (where fitted)" (page 83) |
| | [Map Update] | The map data can be updated.<br>☞ "How to update map data (where fitted)" (page 150) |
| | [Licence Information (OSS)]/[License Information (OSS)]/ [Licence Information]/ [License Information] | Displays the Open Source Software (OSS) licences information. |
| [GPS Position] | | Displays Global Navigation Satellite System (GNSS) information, such as number of satellites, latitude/ longitude, and approximate altitude, etc. |
| [Vehicle Data Transmission] | | When [OK] is touched, data transmission to NISSAN is enabled. Touching [Decline] disables some functions such as Premium Traffic. |
| [Apps]/[Smartphone Connection] | [Apple CarPlay] | Displays the Apple CarPlay screen.<br>☞ "Apple CarPlay (where fitted)" (page 95) |
| | [Android Auto] | Displays the Android Auto screen.<br>☞ "Android Auto™ (where fitted)" (page 100) |
| | [Yandex.Auto] | Displays the Yandex.Auto screen.<br>☞ "Yandex.Auto powered by Bosch (where fitted)" (page 103) |

**Models without navigation system:**

| Menu item | | Action |
|---|---|---|
| [Vehicle] | [Energy Flow] | Displays energy information. Touch [History] to display the Fuel Economy History screen.<br>For details of the Energy Flow, refer to the vehicle Owner's Manual. |
| | [ECO Drive Report] | Displays the Eco Drive Report screen.<br>Your driving score will be displayed in real time, with 100 points designated as the score for ideal eco-driving.<br>Touch [History] to view the drive report history. Touch [Reset] to clear the past records.<br>To improve your score:<br>• When starting off, depress the accelerator gently.<br>• When cruising, accelerate and decelerate as little as possible.<br>• When decelerating, release the accelerator early. |
| [NissanConnect Services] | | Displays the NissanConnect Services menu screen.<br>"NissanConnect Services (where fitted for Europe, Russia and Ukraine)" (page 85)<br>"NissanConnect Services powered by SiriusXM™ (where fitted for Mexico)" (page 86) |
| [System Information] | [Software Version]/[Version Information] | Displays the version information screen. |
| | [Software Update] | The system software can be updated.<br>"Updating system software (where fitted)" (page 83) |
| | [Licence Information (OSS)]/ [License Information (OSS)]/ [Licence Information]/ [License Information] | Displays the Open Source Software (OSS) licences information. |
| [Vehicle Data Transmission] | | When [OK] is touched, data transmission to NISSAN is enabled. Touching [Decline] disables some functions such as Premium Traffic. |
| [Apps]/ [Smartphone Connection] | [Apple CarPlay] | Displays the Apple CarPlay screen.<br>"Apple CarPlay (where fitted)" (page 95) |
| | [Android Auto] | Displays the Android Auto screen.<br>"Android Auto™ (where fitted)" (page 100) |
| | [Yandex.Auto] | Displays the Yandex.Auto screen.<br>"Yandex.Auto powered by Bosch (where fitted)" (page 103) |

## UPDATING SYSTEM SOFTWARE (where fitted)

**⚠ WARNING**

**TO AVOID RISK OF DEATH OR SERIOUS PERSONAL INJURY WHEN UPDATING THE SYSTEM SOFTWARE:**

**If you choose to park the vehicle within range of a Wi-Fi connection (where fitted), park the vehicle in a secure, safe, well-ventilated location that is open to the air. During the update process, if you choose to park your vehicle, it should be kept in a well ventilated area to avoid exposure to carbon monoxide. Do not breathe exhaust gases; they contain colourless and odourless carbon monoxide. Carbon monoxide is dangerous. It can cause unconsciousness or death.**

1. **Apply the parking brake.**
2. **Remain with the vehicle while the update is in process.**
3. **Do not allow children, pets or people who may need assistance to remain in the vehicle while the software is updating.**

**NOTE:**

**The vehicle is not required to be parked during the software update process. If the vehicle disconnects from the Wi-Fi connection (where fitted), it will resume when the vehicle reconnects to a known Wi-Fi connection.**

**INFO:**

- The system prioritises Wi-Fi connection (where fitted) over TCU (Telematics Control Unit) (where fitted) when Wi-Fi network connection is available.
- You will be charged separately when the network communication is made via smartphones.
- The download data size of software updates can vary between 80 MB and 300 MB. If you use your smartphone as a Wi-Fi connection, you may incur data charges from your phone carrier. Please connect to a secure WPA2 Wi-Fi network to avoid potential phone carrier data charges.

### How to update from the pop-up screen

When both of the following conditions are met, the system informs the driver with a pop-up on the screen when system software update is available.

- [Auto] is selected under [Update Method].

  "How to update from the system menu" (page 84)

- Wi-Fi (where fitted) or TCU (Telematics Control Unit) (where fitted) network connection is available.

  "Wi-Fi Setting (where fitted)" (page 32)

1. When the pop-up appears and prompts the driver to perform the system software update, operate the system according to the guides shown on the screen to download the updates. Another pop-up will appear when downloading is complete.
2. After the system software update is complete, place the ignition switch or power switch in the OFF position and leave the system for 20 minutes without operating the switches on the control panel and the steering wheel. Place the ignition switch or power switch in the ON position and the updated software will be available.

**INFO:**

- The update may not be reflected if the ignition switch or power switch is placed back in the ON position before the 20-minute period has passed.
- In some cases, updates can only be performed via TCU (Telematics Control Unit) (where fitted).
- In some cases, the pop-up message may appear even when [Manual] (where fitted) is selected under [Update Method].

## How to update from the system menu

**WARNING**


**To operate the system for software update, first park the vehicle in a safe location.**

System software updates can be downloaded manually via Wi-Fi (where fitted) or TCU (Telematics Control Unit) (where fitted) from the system menu.

1. Connect to network via Wi-Fi (where fitted) if you wish to perform the software update via Wi-Fi connection.

   "Wi-Fi Setting (where fitted)" (page 32)

2. Push **<MENU>/<MODE/OK>** (where fitted).
3. Touch [Info] on the Launch Bar and then touch [System Information].
4. Touch [Software Update].




5GH0781XZ

**Example**

5. Touch [Start Software Update]. The current software version and date of last check are displayed.

**INFO:**

- When [Update Method] is set to [Auto], a notification is made in case that software can be updated.
- Touch [Check for an Update] (where fitted) to check available updates manually. A message is displayed when update availability is confirmed.

6. Touch [Download] to start downloading and updating the system software.
7. After the system software download is complete, place the ignition switch or power switch in the OFF position and leave the system for 20 minutes without operating the switches on the control panel and the steering wheel. Place the ignition switch or power switch in the ON position and the updated software will be available.

**INFO:**

- The update may not be reflected if the ignition switch or power switch is placed back in the ON position before the 20-minute period has passed.
- The following indicators are displayed on the top of the screen while the software is being downloaded or updated.

  : Downloading

  : Updating

- If software update is unnecessary, touch [OK] to return to the previous screen.
- You will be charged separately when the internet communication is made via smartphones. Consult your communication companies regarding the communication fee.
- The download data size of software updates can vary between 80 MB to 300 MB. If you use your smartphone as a Wi-Fi connection, you may incur data charges from your phone carrier. Please connect to a secure WPA2 Wi-Fi network to avoid potential phone carrier data charges.
- [Save Version Information to USB Device] is not available on this system.
- Depending on the models, specifications and software versions, the same operation can be performed from [System Update] on the setting menu screen.

  "System settings" (page 28)

# NISSANCONNECT SERVICES (where fitted for Europe, Russia and Ukraine)

This vehicle incorporates a communication device that is called TCU (Telematics Control Unit). The communication connection between this unit and the Nissan Data Center allows for various services.

For Europe:
For details, refer to the NissanConnect Services app and YOU+Nissan Owners' Portal.

For Russia:
NissanConnect Services are not available on all versions. The operating speed and functioning depend on the Internet connection speed and smartphone model. Remote access functions, Map update and Monitoring function are free for 3 years since activation date of Nissan Connected Services. Trip history function, Nissan Assistance support service are free for 7 years since activation date of Nissan Connected Services.

The Services are fully available only on the territory of Russian Federation. The services' operation might be affected by the providers' operations – suppliers of additional services and mobile network, ERA-GLONASS activation, atmospheric and topographic conditions, car's location and obstacles (e.g. bridges and buildings). The Services functioning might be affected by the force majeure circumstances, technical and other measures, related to incorrect operations of the providers - suppliers of additional services. The mentioned circumstances are not a shortage of the Services. In case of cease of the car ownership or its regular use for any reasons it is necessary to cancel the pairing of your account with the car and delete the car from your account. Please read the full rules of the Services usage in the Operation manual. In case of buying a car on the after-market we kindly ask you to refer to the authorized Nissan dealer in order to close an agreement on processing the personal data, for a full functionality of the services.

For details, refer to the NissanConnect Services app and https://www.nissan.ru

For Ukraine:
For details, contact a NISSAN dealer.

## PRIVACY POLICY NISSANCONNECT SERVICES

The transferred personal data will be stored only for a period necessary for the processing, and will be then deleted or anonymized.

For Europe:
For any further information in relation to the retention period and the protection of your personal data, please refer to the Terms and Conditions available in the NissanConnect Services app and YOU+Nissan Owners' Portal.

For Russia:
For any further information in relation to the retention period and the protection of your personal data, please refer to the Terms and Conditions available in the NissanConnect Services app and https://www.nissan.ru.

For Ukraine:
For any further information in relation to the retention period and the protection of your personal data, please contact a NISSAN dealer.

## NISSANCONNECT MENUS

With NissanConnect Services, various information can be received and displayed on the screen. The information can also be announced by the system.

## NISSANCONNECT SETTINGS

NissanConnect settings can be changed.

1. Touch [Info] on the Launch Bar.
2. Touch [NissanConnect Services].
3. Touch [NissanConnect Services Settings].

Available setting items may vary depending on models, specifications and software versions.

**INFO:**

[NissanConnect Services] can also be accessed from [Settings] on the Launch Bar.

| Setting items | Action |
|---|---|
| [Information Channel Setting] | Displays the Information Channel Setting screen. |
| [Unit ID Information] | Displays the Unit ID Information screen. |
| [Reset all NissanConnect Svcs. Settings to Default] | All NissanConnect Services settings are returned to default. |
| [Privacy Mode Setting] | Allows you to accept or decline the Privacy Mode setting. |

**INFO:**

**What happens when Privacy Mode is ON?**

When Privacy Mode is ON (by declining NissanConnect Services while switching on your vehicle or via the NissanConnect Services settings), your data will not be processed for purposes relating to NissanConnect Services. They might however be processed for the purpose of services other than NissanConnect Services which are (i) either mandatory (such as eCall in Europe, or Glonass in Russia), (ii) that you might have activated independently and manually (such as bCall, concierge service, co-pilot button), or (iii) relating to services that you have subscribed to and remains activated for your safety (SVT, theft/burglar notification).

# NISSANCONNECT SERVICES POWERED BY SIRIUSXM™ (where fitted for Mexico)

## SUBSCRIPTION TO NISSANCONNECT SERVICES

Subscription is required to use the NissanConnect Services. For the details about the subscription, visit the Nissan Owner Portal or contact a Nissan Mexicana dealer.

NissanConnect Services are offered by SiriusXM™ or other third party vendors in accordance with the terms and conditions and the privacy policies outlined in a Subscription Agreement.

## IMPORTANT INFORMATION REGARDING ACCESS TO NISSANCONNECT SERVICES

Feature availability is dependent on vehicle model, trim level, packaging and options. A compatible connected device may be required and feature availability may be dependent on the device's capability. Refer to connected device's owner's manual for details. Late availability for some features.

**Driving is a serious business and requires your full attention.** Only use features and connected devices when safe and legal to do so. Some features, including automatic crash notification and SOS, are dependent upon the telematics device being in operative condition, its ability to connect to a wireless network, compatible wireless network availability, navigation map data and GNSS signal receptions, the absence of which can limit or prevent the ability to reach Customer Care or receive support. GNSS mapping may not be detailed in all areas or reflect current road status. Never program GNSS while driving. Only use Remote Engine Start

and Remote Horn features in accordance with any laws, rules or ordinances in effect in your vehicle's location.

**Some services and features are provided by independent companies not within NISSAN's control. Should the service provider terminate or restrict services or features, services or features may be suspended or terminated without notice or with no liability to NISSAN or its partners or agents.** Services and features may require a compatible cellular network provided by independent companies not within NISSAN or its partners' or agents' control. Cellular network signal strength may vary and may not be available in all areas or at all times. Services and features may not function if a cellular network is unavailable, restricted, or terminated. NISSAN and its partners or agents are not responsible for associated costs or other third party changes that may be required for continued operation due to cellular network unavailability, restriction, or termination (including equipment replacements/upgrades, if available, or roaming charges on alternative networks). Technology is evolving, and changes by independent companies are not within NISSAN's or its partners' or agents' control.

Enrolment, owner consent, personal identification number (PIN), and subscription agreement may be required to receive the full suite of features and services. Trial periods (if applicable) begin on the date of vehicle purchase or lease of a new NISSAN. Trial periods may be subject to change at any time and may be subject to early termination without notice. Required subscriptions may be sold separately for each available feature or service after the trial period ends, and may continue until you call the service provider to cancel. Installation costs, a one-time activation fee, other fees and taxes may apply. Fees and programming are subject to change. Features may be subject to age restrictions in some areas. Subscriptions governed by the service provider's subscription agreement, terms and conditions and privacy statements are available at service provider's website.

NissanConnect Services is a collection of security and convenience services that add innovation to your daily drive.

Where fitted, your vehicle may include NissanConnect connected features and services such as Emergency SOS calling, Automatic Collision Notification, Wi-Fi, Remote Services, Navigation, Bluetooth® and more. For complete information about your NissanConnect features and services, please consult your vehicle's NissanConnect Owner's Manual at www. nissan.com.mx/nissan-connect.

For frequently asked questions, please visit www.nissan.com.mx/nissan-connect.

For full details on NissanConnect Services or to enroll your vehicle, please visit www. nissan.com.mx/nissan-connect.

You can enroll your NissanConnect Services with you dealer or on the Customer Web Portal "https://www.nissanconnectservices.mx/nissan-owners/" by creating an account with your Vehicle Identification Number (VIN) and your personal data. Follow the prompts to enroll in NissanConnect Services.

Some of the available NissanConnect Services include:

- **Automatic Collision Notification (where fitted):**

  A service that generates an automatic connection between the vehicle and a live response specialist when the vehicle has been involved in an accident that was severe enough to deploy the air bags.

- **Emergency Call (where fitted):**

  Connects you to a live response specialist who will assist in the dispatch of emergency services to the vehicle location. To use this feature, push the Emergency Call (SOS) button on the overhead console. The Emergency Call (SOS) button should only be used in emergency situations or in conjunction with the Roadside Assistance feature (where fitted), if warranted.

- **Wi-Fi Hotspot (where fitted):**

  Enables you to connect up to seven devices to the vehicle and access the Internet when a service provider's subscription is active.

## NISSANCONNECT SERVICES FEATURES

NissanConnect Services provides various types of information and services by connecting your vehicle to the NissanConnect Services Data Center and NissanConnect Services Response Center using the TCU (Telematics Control Unit) installed in your vehicle.

Where fitted, your vehicle may include NissanConnect connected features and services such as Emergency SOS calling, Automatic Collision Notification, Remote Services, Navigation, Wi-Fi, Bluetooth® and more. For complete information about your NissanConnect features, enrollment and services, please visit www.nissan.com.mx/connect.

**WARNING**

- **Please note that the Automatic Collision Notification service (where fitted) and Emergency Call function (where fitted) cannot be used in the following conditions:**
  - **Emergency functions and services will not be available without a paid subscription to NissanConnect Services.**
  - **The NissanConnect Services network system is disabled.**
  - **The vehicle moves outside the service area where the TCU (Telematics Control Unit) is connected to the system.**
  - **The vehicle is outside the area where the cellular network service is receivable.**
  - **The vehicle is in a location with poor signal reception such as tunnels, underground parking garages, behind buildings or in mountainous areas.**
  - **The line is busy.**
  - **The TCU (Telematics Control Unit) or other systems of your vehicle are not working properly.**
  - **It may not be possible to make an emergency call depending on the severity of a collision and/or emergency.**
- **Radio waves could adversely affect electric medical equipment. Individuals who use a pacemaker should contact the device manufacturer regarding any possible effects before using the system.**
- **The TCU (Telematics Control Unit) antenna is installed inside the upper central part of the instrument panel. An occupant should not get any closer to the antenna than specified by the pacemaker manufacturer. The radio waves from the TCU antenna may adversely affect the operation of the pacemaker while using the NissanConnect Services.**

**INFO:**

- NissanConnect Services features are dependent upon subscription enrolment and the telematics device being in operative condition, cellular connectivity, navigation map data and GNSS signal reception. Terms and conditions of the NissanConnect Services Subscription Agreement apply.
- Enrolment is required in order to use NissanConnect Services. The services that can be received vary depending on the plan in which you are enrolled.
- All services are complimentary for the trial period.
- After the trial period, use of the service will no longer be complimentary.
- Laws in some jurisdictions may restrict the use of "Text-to-Speech." Check local regulations before using this feature.

Where fitted, your vehicle may include NissanConnect Services features such as Emergency SOS calling, Automatic Collision Notification, Wi-Fi, Remote Services, Navigation, Bluetooth® and more. NissanConnect Services may be updated. The latest detailed information is available on the following website or from the support line.

**NissanConnect Services website:**
www.nissan.com.mx/nissan-connect

**NissanConnect customer support line:**
800 9647726

- **Automatic Collision Notification (where fitted):**

  The TCU (Telematics Control Unit) generates a signal automatically to the NissanConnect Services Response Center in the case of an accident severe enough to trigger one of the vehicle's air bags. Upon the signal, a Response Specialist receives the vehicle location and customer information and notifies the proper authorities in accordance with established policies and procedures.

- **Emergency Call (where fitted):**

  The Emergency Call feature provides emergency assistance by connecting to a Response Specialist. In the event of an emergency, by pushing the in-vehicle Emergency Call SOS button to use this feature. The Response Specialist provides various assistance depending on the situation.

  "Emergency support (where fitted)" (page 92)

- **Connection to Roadside Assistance (where fitted):**

  Roadside Assistance allows you to receive assistance from the Roadside Response Specialist for a non-emergency incident that requires a towing or third-party response service. The service can be accessed by touching [Call Nissan Assistance] or [] (where fitted) on the screen.

  "Connecting to Interactive Voice Menu" (page 91)

  Roadside Assistance may also be used in conjunction with the Emergency Assistance service, if warranted.

  "Emergency support (where fitted)" (page 92)

## Notice to Bluetooth® Hands-Free Phone users

The Bluetooth® Hands-Free Phone System will be disabled and not be able to take phone calls while the vehicle is connected to the NissanConnect Services Response Specialists or the emergency support staff at the NISSAN Response Center.

This is to avoid NissanConnect Services Response Specialists and NissanConnect Services emergency support staff from being interrupted by incoming calls. Incoming phone calls received while the vehicle is connected to the Service Center will not be listed in the call history of the Bluetooth® Hands-Free Phone System. However those incoming calls may be listed in the call history of your mobile phone, depending on its capabilities. After disconnecting communication with the NissanConnect Services Response Specialist or NissanConnect Services emergency support staff, check the incoming call history on your mobile phone when it is safe to do so.

## Service subscription

A separately purchased NissanConnect Services subscription is required. For detailed information, contact a NISSAN dealer or refer to the following NissanConnect Services website:
www.nissan.com.mx/nissan-connect

**INFO:**

If the vehicle is owned by another person and is resold, the subscription for this service must be cancelled and all data stored on the device must be deleted.

## Operating tips

**⚠ WARNING**

- **Use the NissanConnect Services after stopping your vehicle in a safe location. If you have to use the NissanConnect Services while driving, exercise extreme caution at all times so full attention may be given to vehicle operation.**
- **If you are unable to devote full attention to vehicle operation while talking with the NissanConnect Services, pull off the road to a safe location and stop your vehicle.**
- **Do not use the NissanConnect Services with the engine or e-POWER system stopped. Doing so may discharge the vehicle battery (12V battery).**
- **The NissanConnect Services cannot be used under the following conditions:**
  - **The NissanConnect Services subscription has expired.**
  - **The vehicle is outside the area where the cellular network service is receivable.**
  - **The vehicle is in a location with poor signal reception such as tunnels, underground parking garages, behind buildings or in mountainous areas.**
  - **The line is busy.**
  - **The TCU (Telematics Control Unit) or other systems of your vehicle are not working properly.**
  - **The NissanConnect Services network system is disabled.**
- **Communication with the NissanConnect Services Data Center is related to the data communication mode and may cause occasional difficulty in receiving signals, and the signal receivable area may be limited compared to regular mobile phones.**
- **You may hear clicks or experience interruptions while speaking with the NissanConnect Services Response Specialists. This is due to a shift in the connection zone and is not a malfunction.**
- **Depending on the line used, the sound volume may decrease. Adjust the volume as necessary.**
- **Received sounds may be distorted or ambient noise may sound like voices of a crowd. This is due to the use of the digital line and is not a malfunction.**
- **You may hear your own voice from the speaker when talking with the NissanConnect Services Response Specialists due to a network disturbance. When this occurs, reconnect the line after a few minutes or at a different location.**
- **This vehicle incorporates a communication device that is called a TCU (Telematics Control Unit). The communication connection between this unit and the NissanConnect Services Data Center allows for various services. When the system connects to the NissanConnect Services Data Center, an antenna icon will appear on the screen. Use the service in a location where the symbol representing good signal reception appears on the screen.**

  
  **: When the signal reception is good**

  
  **: When the signal reception is bad**
- **The NissanConnect Services use the TCU (Telematics Control Unit) for communications. Even if the signal strength bar of the in-vehicle data communication module indicates good reception, connection to the NissanConnect Services Data Center may be disabled. This does not indicate a malfunction. Operate the system again after a few minutes.**

## NISSANCONNECT SERVICES MENUS

With NissanConnect Services, various information can be received and displayed on the screen. The information can also be announced by the system.

1. Push **<MENU>** and then touch [Info].
2. Touch [NissanConnect Services].
3. Select an item from the NissanConnect Services menu screens.

Available items may vary depending on models, specifications and software versions. Items displayed on the screen may not function depending on various conditions.

| Available items | Content |
|---|---|
| [Call Nissan Assistance] | The system connects to the Nissan- Connect Services center. Various services to support your driving are available by answering the Interactive Voice Menu. "Connecting to Interactive Voice Menu" (page 91) |
| [History] | Accesses the messages sent to the vehicle from the NissanConnect Services Data Center. "History" (page 91) |
| [NissanConnect Services Settings] | NissanConnect Services settings can be changed. "NissanConnect Services settings" (page 94) |

### Connecting to Interactive Voice Menu


Various services to support your driving are available by using the Interactive Voice Menu. For more details, refer to the NissanConnect Services website or contact the NissanConnect customer support line.

**NissanConnect Services website:**
www.nissan.com.mx/nissan-connect
**NissanConnect customer support line:**
800 9647726

1. Push **<MENU>** and then touch [Info] on the Launch Bar.
2. Touch [NissanConnect Services].
3. Touch [Call Nissan Assistance].
4. The system connects to the NissanConnect Services centre and menu options will be announced. Speak your preferred option.

**INFO:**

- After selecting [Call Nissan Assistance], it may take some time until the system initiates connection, depending on the technical environment and whether the TCU (Telematics Control Unit) is being used by other services.
- To avoid disconnecting the line, do not turn off the engine or e-POWER system.
- You can also connect to the Nissan- Connect Services Interactive Voice Menu by touching [ ] ① (where fitted) on the map.




5GB0697XZ

### History

Messages received from the NissanConnect Services Data Center are displayed.

1. Push **<MENU>** and then touch [Info].
2. Touch [NissanConnect Services].
3. Touch [History].
4. A message list is displayed. Touch preferred message from the list.

**INFO:**

- Touch [Stop] during communication with the NissanConnect Services Data Center to cancel the connection.
- A message is displayed when the communication is disconnected while downloading information due to a poor communication status. Select [Yes] to restart the download.

- Laws in some jurisdictions may restrict the use of "Text-to-Speech". Check local regulations before using this feature.
- Some terminology such as personal names, place names, special terms, symbols, etc. may not be announced correctly. This is not a malfunction.
- The system will pause announcements when interrupted by the voice guidance given by the navigation system (where fitted). When the voice guidance finishes, the system will restart the announcement.
- When the system is making announcements, the volume can be adjusted by turning **<VOL/ ⏻ >/** **<VOLUME/ ⏻ >/** **<VOL/PUSH ⏻ >/** **<VOL/PUSH POWER>**.
- The selected content is read out while the vehicle is being driven, or if parked, you can read the content on the display.
- Content settings can be made using the NissanConnect Services website.

  For more details, refer to the NissanConnect Services website or contact the NissanConnect customer support line.

  **NissanConnect Services website:**
  www.nissan.com.mx/nissan-connect
  **NissanConnect customer support line:**
  800 9647726

## EMERGENCY SUPPORT (where fitted)

NissanConnect Services provides various services to support dealing with emergencies of the subscribed vehicle and the driver.

For example, in case of an illness or serious injury, you can seek support by pushing the in-vehicle Emergency Call (SOS) button and connecting to the NissanConnect Services Response Center. The NissanConnect Services Response Center can specify the location of the vehicle via GNSS, and the information will be sent to the police or other agencies as needed.

For information about other NissanConnect Services emergency support related services, refer to the NissanConnect Services website or contact the NissanConnect customer support line.

**NissanConnect Services website:**
www.nissan.com.mx/nissan-connect
**NissanConnect customer support line:**
800 9647726

**⚠ WARNING**

- **Please note that the Automatic Collision Notification service (where fitted) and Emergency Call function cannot be used in the following conditions:**
  - **Emergency functions and services will not be available without a paid subscription to NissanConnect Services.**
  - **The NissanConnect Services network system is disabled.**
  - **The vehicle moves outside the service area where the TCU (Telematics Control Unit) is connected to the system.**
  - **The vehicle is outside the area where the cellular network service is receivable.**
  - **The vehicle is in a location with poor signal reception such as tunnels, underground parking garages, behind buildings or in mountainous areas.**
  - **The line is busy.**
  - **The TCU (Telematics Control Unit) or other systems of your vehicle are not working properly.**
  - **It may not be possible to make an emergency call depending on the severity of a collision and/or emergency.**

- **Park the vehicle in a safe location and set the parking brake before operating the Emergency Call (SOS) button.**
- **Only use this service in case of an emergency. There may be a penalty for inappropriate use of the service.**
- **Radio waves could adversely affect electric medical equipment. Individuals who use a pacemaker should contact the device manufacturer regarding any possible effects before using the system.**
- **The TCU (Telematics Control Unit) antenna is installed inside the upper central part of the instrument panel. An occupant should not get any closer to the antenna than specified by the pacemaker manufacturer. The radio waves from the TCU antenna may adversely affect the operation of the pacemaker while using the NissanConnect Services.**

## Making an emergency call




PBH0130XZ

**Type A**




PBH0138X

**Type B**

The Emergency Call (SOS) button is located near the map light.

1. Push the Emergency Call (SOS) button.
2. When the line is connected, speak to the Response Specialist.

If you want to cancel the emergency call, push and hold the Emergency Call (SOS) button for a few seconds.

**INFO:**

- If there is a cover on the Emergency Call (SOS) button, open the cover first.
- After the Emergency Call (SOS) button is pushed, it may take some time until the system initiates connection, depending on the technical environment and whether the TCU (Telematics Control Unit) is being used by other services.
- An indicator light above the Emergency Call (SOS) button shows the readiness of the emergency support system. If the indicator light is illuminated in red, pushing the Emergency Call (SOS) button does not connect your vehicle to the Response Specialist.

  The indicator light blinks while connected to the NissanConnect Services Response Center.
- Even when the indicator light is illuminated, connection to the NissanConnect Services Response Center may not be possible. If this occurs in an emergency situation, contact the authorities by other means.
- To avoid disconnecting the line, do not turn off the engine or e-POWER system.

## NISSANCONNECT SERVICES SETTINGS

The NissanConnect Services setting can be changed. Available menus may vary depending on models, specifications and software versions. Menus displayed on the screen may not function depending on various conditions.

1. Push **<MENU>**.
2. Touch [Info] on the Launch Bar.
3. Touch [NissanConnect Services].
4. Touch [NissanConnect Services Settings].

**INFO:**

[NissanConnect Services Settings] can also be accessed from [NissanConnect Services] on the settings screen.

"Settings menu" (page 28)

| Menu | | Action |
|---|---|---|
| [Delete All Information Feed History] | | Deletes contents of information feeds. |
| [Vehicle Data Sharing] | [Share Vehicle Information] | Turns the vehicle information sharing function on/off. |
| | [Delete Shared Vehicle Data] | Deletes the shared vehicle information. |
| [Unit ID Information] | | Displays the Unit ID, TCU (Telematics Control Unit) ID, SIM ID and VIN Information necessary for user registration. |
| [Reset all NissanConnect Svcs. Settings to Default] | | All NissanConnect Services settings are returned to default. |
| [Vehicle Data Transmission Setting] | | When [OK] is touched, data transmission to the NissanConnect Services Data Center is enabled. Touch [Decline] to disable the NissanConnect Services, Premium Traffic, etc. |

**WARNING**

- **Stop your vehicle in a safe location and apply the parking brake before connecting your iPhone to the vehicle or operating your connected iPhone for setup.**
- **If you are unable to devote full attention to vehicle operation while using Apple CarPlay, pull off the road to a safe location and stop your vehicle.**

You can use Apple CarPlay by connecting a compatible iPhone to your vehicle via a USB cable.

To connect your iPhone with the in-vehicle system, it is recommended to use the Apple Lightning cable (MFi certified) that was provided with your iPhone.

With Apple CarPlay, your in-vehicle system can be used as a display and a controller for some of the iPhone functions. Apple CarPlay features Siri which enables operations via voice controls. Visit apple-.com for information about the functions that are available and details about Apple's privacy policy.

Certain vehicle information (e.g. location and speed) may be shared with your device while Apple CarPlay is in use. Carrier charges may apply to use Apple CarPlay.

## COMPATIBILITY

Refer to the following Apple website for compatible devices.
https://www.apple.com/ios/carplay/

**INFO:**

- In some countries, iPhone in the market may not be supported by Apple CarPlay. Refer to the following website.
  https://www.apple.com/ios/feature-availability/
- For best results, always update your device to the latest software version.
- Apple CarPlay will take the place of your Bluetooth® audio and Bluetooth® hands-free phone functionality.
- Phone menu and access to the connected phone through Voice Recognition System (where fitted) will be disabled while Apple CarPlay is connected. To access your phone, use the Siri function or select the phone icon in the Apple CarPlay top menu screen.

## APPLE CARPLAY OPERATION

1. Connect the iPhone to the USB connection port.

   "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23)

2. Depending on the setting, a Startup Information screen will appear. Touch [Yes]/[Apple CarPlay] to use Apple CarPlay.

   **INFO:**

   If you do not wish to display the Startup Information screen each time you activate Apple CarPlay, turn on [Don't Ask Any More]/[Don't Ask Anymore] on the Startup Information screen. The Startup Information screen will not be displayed from the next Apple CarPlay activation. The Startup Information screen can be set to appear again in the Apple CarPlay setting menu.

   "Apple CarPlay settings" (page 98)

3. The Apple CarPlay screen will appear. The iPhone functions displayed on the screen should now be operable using the in-vehicle system.
4. To exit the Apple CarPlay screen, push the buttons such as **<MENU>** on the control panel or **<MODE/OK>** (where fitted) on the steering column and display the corresponding screen.

   **INFO:**

   Touching [Nissan] (where fitted) on the Apple CarPlay screen can also exit from the Apple CarPlay screen.

5. To return to the Apple CarPlay screen, take one of the following actions.
   - Touch [CarPlay] on the Launch Bar.
   - Touch [Apps]/[Smartphone Connection] on the information screen, and then touch [Apple CarPlay].

**INFO:**

When your iPhone is locked, Apple CarPlay can still be activated by operating the iPhone and allowing Apple CarPlay activation when asked.

## Siri operation

With Siri, some of the functions in your iPhone can be voice controlled.

Make sure that Siri on your iPhone is turned on.

**Activation:**

Push and hold **<** **>** (where fitted) on the steering wheel to start a Siri session.

**INFO:**

- Push **<** **>** (where fitted) to end Siri operation.
- Keep the interior of the vehicle as quiet as possible. Close the windows to eliminate the surrounding noises (traffic noises, vibration sounds, etc.), which may prevent the system from recognising the voice commands correctly.
- For functions that can be used with Siri, please refer to the Apple website.

## Phone operation

If you wish to use the phone with Apple CarPlay, follow the procedure below:

1. Touch [Phone] on the Apple CarPlay top menu.
2. Operate the screen displayed to make a call, etc.

## APPLE CARPLAY SETTINGS

1. Touch [Apps] on the setting menu screen.

   "System settings" (page 28)

2. **Type A:**

   Touch [Apple CarPlay].

   **Type B:**

   A list of devices is displayed.

   Touch [ⓘ] or the name of the Apple CarPlay device you wish to change the setting for.

**Available items:**

Available setting items may vary depending on models, specifications and software versions.

| Setting item 1 | Setting item 2 | Action |
|---|---|---|
| [Select Service] | [Apple CarPlay] | Activates Apple CarPlay when an iPhone is connected to the in-vehicle system. |
| | [Yandex.Auto] | Activates Yandex.Auto (where fitted) when a smartphone is connected to the in-vehicle system. |
| | [No service] | Apple CarPlay and Yandex.Auto (where fitted) will not activate even if a smartphone is connected to the in-vehicle system. |
| [Enable after USB Connection:] | [Always] | Activates Apple CarPlay or Yandex.Auto (where fitted) automatically when an iPhone is connected to the in-vehicle system. |
| | [Ask] | Displays the Apple CarPlay or Yandex.Auto (where fitted) Startup Information screen when an iPhone is connected to the in-vehicle system. |
| [Nissan's Help for Apple CarPlay] | | Displays helpful tips for Apple CarPlay operation. |
| [Delete] | | Deletes registered iPhone from the list. |

**INFO:**

- Access to songs on your iPod via in-vehicle voice recognition system (where fitted) will not be available when connected to Apple CarPlay. To access to your iPod music, use the Siri function or select the music icon in the Apple CarPlay top menu screen.
- Depending on the models, specifications and software versions, Apple CarPlay settings can also be accessed from the Connections screen.

"Apps settings (where fitted)" (page 33)

## APPLE CARPLAY SYSTEM LIMITATIONS

For all features of Apple CarPlay to operate correctly, it is necessary to have a compatible iPhone, a network connection and a data plan.

When Apple CarPlay is operating, system performance is affected by the strength of the network connection or performance of the phone itself. If performance of the system decreases:

- Disconnect and reconnect your phone
- Cycle phone power off/on to restart

Functionality of Apple CarPlay may decrease or be lost if there are changes to operating systems, hardware, software or other technologies central to supporting the system that are outside of NISSAN's control. Changing government regulations may also affect operation of Apple CarPlay.

**⚠ WARNING**

- **Stop your vehicle in a safe location and apply the parking brake before connecting your Android™ phone to the vehicle or operating your connected Android phone for setup.**
- **If you are unable to devote full attention to vehicle operation while using Android Auto, pull off the road to a safe location and stop your vehicle.**

You can use Android Auto by connecting a compatible Android phone to your vehicle via a USB cable. It is also recommended to use the Android phone OEM cable that was provided with your phone.

With Android Auto, your in-vehicle system can be used as a display and a controller for some of the Android phone functions. Voice control of some of the Android phone functions is also possible with Android Auto. Visit www.android.com/auto for information about the functions that are available and details about Google's privacy policy.

Certain vehicle information (e.g. location and speed) may be shared with your device while Android Auto is in use. Carrier charges may apply to use Android Auto.

## COMPATIBILITY

Refer to the following Android Auto website for compatible devices and market information.
https://www.android.com/auto/

**INFO:**

- In some countries, Android phones in the market may not be supported by Android Auto.
- Download the Android Auto App from Google Play™ to an Android phone in advance.
- For the best results, always update your device to the latest Android software and Android Auto App version. When you connect the Android phone to the in-vehicle system, it will automatically update the Android software and Android Auto App version.
- Android Auto will take the place of your Bluetooth® audio and Bluetooth® hands-free phone functionality.
- When setting a route with the navigation system (where fitted), if you set a destination with Android Auto, the route setting of the navigation system will be cancelled.
- The Phone menu and access to the connected phone through the Voice Recognition System (where fitted) will be disabled while Android Auto is connected. To access your phone, talk to your Google Assistant or select the phone icon in the Android Auto top menu screen.

## INITIAL ANDROID AUTO SETTINGS

Before using Android Auto, download the Android Auto app from the Google Play store on your Android phone.

It may be necessary to operate the Android phone when connected first.

Depending on the selection, such as approval, some of the features of Android Auto are not available.

## ANDROID AUTO OPERATION

Unlock your phone's screen before connecting your Android phone.

1. Connect your Android phone to the USB connection port.

   "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23)

2. Depending on the setting, a Startup Information screen will appear. Touch [Yes]/[Android Auto] to use Android Auto.

**INFO:**

- If you do not wish to display the Startup Information screen each time you activate Android Auto, turn on [Don't Ask Any More]/[Don't Ask Anymore] on the Startup Information screen. The Startup Information screen will not be displayed from the next Android Auto activation. The Startup Information screen can be set to appear again in the Android Auto setting menu.

  "Android Auto settings" (page 102)

- Your phone's Bluetooth® will be turned on automatically when Android Auto is activated. Keep the Bluetooth® turned on to use the phone functions.
- Some functions of Android Auto are not available if the Bluetooth® is not connected.

3. The Android Auto top menu screen will appear. The Android phone functions displayed on the screen should now be operable using the in-vehicle system.

**INFO:**

- While Android Auto is activated on the Android phone, the phone operations, such as making or receiving calls, can only be done with Android Auto.
- Depending on the device, an Android phone requires MTP mode to be selected in the USB transfer setting.
- After exiting the Android Auto screen, return to the Android Auto screen by taking one of the following actions.

– Touch [ ] on the Launch Bar.

– Touch [Apps]/[Smartphone Connection] on the information screen, and then touch [Android Auto].

### Google Assistant™ operation

Some of the functions on your Android phone can be voice controlled when Android Auto is active.

**Activation:**

Push and hold **< >** (where fitted) on the steering wheel to start a Google Assistant session.

**INFO:**

- Push **< >** (where fitted) to end voice operation.
- Keep the interior of the vehicle as quiet as possible. Close the windows to eliminate the surrounding noises (traffic noises, vibration sounds, etc.), which may prevent the system from recognising the voice commands correctly.
- For functions that can be used with the voice operation, refer to www.android.com/auto.

### Phone operation

If you wish to use your phone while Android Auto is activated, follow the procedure below:

1. Touch [ ] on the Android Auto screen.
2. Operate the screen displayed to make a call, etc.

## ANDROID AUTO SETTINGS

1. Touch [Apps] on the setting menu screen.

   "System settings" (page 28)

2. **Type A:**

   Touch [Android Auto].

   **Type B:**

   A list of devices is displayed.

   Touch [ⓘ] or the name of the Android Auto device you wish to change the setting for.

**Available items:**

Available setting items may vary depending on models, specifications and software versions.

| Setting item 1 | Setting item 2 | Action |
|---|---|---|
| [Select Service] | [Android Auto] | Activates Android Auto when an Android phone is connected to the in-vehicle system. |
| | [Yandex.Auto] | Activates Yandex.Auto (where fitted) when a smartphone is connected to the in-vehicle system. |
| | [No service] | Android Auto and Yandex.Auto (where fitted) will not activate even if a smartphone is connected to the in-vehicle system. |
| [Enable after USB Connection:] | [Always] | Activates Android Auto or Yandex.Auto (where fitted) automatically when an Android phone is connected to the in-vehicle system. |
| | [Ask] | Displays the Android Auto or Yandex.Auto (where fitted) Startup Information screen when an Android phone is connected to the in-vehicle system. |
| [Nissan's Help for Android Auto] | | Displays helpful tips for Android Auto operation. |
| [Delete] | | Deletes registered Android phone from the list. |

**INFO:**

Depending on the models, specifications and software versions, Android Auto settings can also be accessed from the Connections screen.

"Apps settings (where fitted)" (page 33)

## ANDROID AUTO SYSTEM LIMITATIONS

For all features of Android Auto to operate correctly, it is necessary to have a compatible Android phone, a network connection and a data plan.

When Android Auto is operating, system performance is affected by the strength of the network connection or performance of the phone itself. If performance of the system decreases:

- Disconnect and reconnect your phone
- Close all apps and restart them
- Cycle phone power off/on to restart

It should also be confirmed that the latest version of both Android OS and the Android Auto App are installed on the mobile phone.

Functionality of Android Auto may decrease or be lost if there are changes to operating systems, hardware, software or other technologies central to supporting the system that are outside of NISSAN's control. Changing government regulations may also affect the operation of Android Auto.

**WARNING**

- **Stop your vehicle in a safe location and apply the parking brake before connecting your smartphone to the vehicle or operating your connected smartphone for setup.**
- **If you are unable to devote full attention to vehicle operation while using Yandex.Auto, pull off the road to a safe location and stop your vehicle.**

You can use Yandex.Auto by connecting a compatible iPhone or Android phone to your vehicle via a USB cable. To connect your iPhone with the in-vehicle system, it is recommended to use the Apple Lightning cable (MFi certified) that was provided with your iPhone. For Android phones, using the OEM cable that was provided with your phone is recommended.

With Yandex.Auto, your in-vehicle system can be used as a display and a controller for some of the smartphone functions. Voice control of some of the smartphone functions is also possible with Yandex.Auto. Visit yandex.com for information about the functions that are available and details about Yandex's privacy policy.

Certain vehicle information (e.g. location and speed) may be shared with your device while Yandex.Auto is in use. Carrier charges may apply to use Yandex.Auto.

## COMPATIBILITY

Refer to the Yandex website for compatible devices.

**INFO:**

- In some countries, smartphones in the market may not be supported by Yandex.Auto.
- For best results, always update your device to the latest software version.

## INITIAL YANDEX.AUTO SETTINGS

Before using Yandex.Auto, the Yandex.Auto (launcher app) and Yandex.Navigator (navigation app) must be downloaded on your smartphone from the Apple store or Google Play store. Operate the smartphone as necessary to enable Yandex.Auto.

## YANDEX.AUTO OPERATION

1. Connect the smartphone to the USB connection port.

   "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23)

2. Depending on the setting, a Startup Information screen will appear. Touch [Yandex.Auto] to use Yandex.Auto.

**INFO:**

- If you do not wish to display the Startup Information screen each time you activate Yandex.Auto, turn on [Don't Ask Any More]/[Don't Ask Anymore] on the Startup Information screen. The Startup Information screen will not be displayed from the next Yandex.Auto activation. The Startup Information screen can be set to appear again in the Yandex.Auto setting menu.

  "Yandex.Auto settings" (page 105)

- Yandex.Auto requires Bluetooth® connection of your phone. Connect your phone's Bluetooth® to use the full functions of Yandex.Auto.

3. The Yandex.Auto screen will appear. The Yandex-.Auto functions displayed on the screen should now be operable using the in-vehicle system.
4. To exit the Yandex.Auto screen, push the buttons such as **<MENU>** on the control panel and display the corresponding screen.
5. To return to the Yandex.Auto screen, take one of the following actions.
   - Touch [Yandex] on the Launch Bar.
   - Touch [Apps]/[Smartphone Connection] on the information screen, and then touch [Yandex.Auto].

**INFO:**

- Please keep your smartphone unlocked when using Yandex.Auto.
- Depending on the device, an Android phone requires MTP mode to be selected in the USB transfer setting.

## Voice assistant "Alice" operation

With voice assistant "Alice", some of the smartphone functions can be voice controlled.

Make sure that voice assistant "Alice" on your smartphone is turned on.

**Activation:**

Push and hold **<**  **>** (where fitted) on the steering wheel to start a voice assistant "Alice" session.

**INFO:**

- Push **<**  **>** (where fitted) to end voice assistant "Alice" operation.
- Keep the interior of the vehicle as quiet as possible. Close the windows to eliminate the surrounding noises (traffic noises, vibration sounds, etc.), which may prevent the system from recognising the voice commands correctly.

## YANDEX.AUTO SETTINGS

1. Touch [Apps] on the setting menu screen.

   "System settings" (page 28)

2. A list of devices is displayed.

   Touch [ ⓘ ] or the name of the Yandex.Auto device you wish to change the setting.

**Available items:**

Available setting items may vary depending on models, specifications and software versions.

| Setting item 1 | Setting item 2 | Action |
|---|---|---|
| [Select Service] | [Apple CarPlay] | Activates Apple CarPlay when an iPhone is connected to the in-vehicle system. |
| | [Yandex.Auto] | Activates Yandex.Auto when an Android phone is connected to the in-vehicle system. |
| | [Yandex.Auto] | Activates Yandex.Auto when a smartphone is connected to the in-vehicle system. |
| | [No service] | Apple CarPlay, Yandex.Auto and Yandex.Auto will not activate even if a smartphone is connected to the in-vehicle system. |
| [Enable after USB Connection:] | [Always] | Activates Yandex.Auto automatically when an smartphone is connected to the in-vehicle system. |
| | [Ask] | Displays the Yandex.Auto Startup Information screen when an smartphone is connected to the in-vehicle system. |
| [Nissan's Help for Yandex.Auto] | | Displays helpful tips for Yandex.Auto operation. |
| [Delete] | | Deletes registered smartphone from the list. |

**INFO:**

Depending on the models, specifications and software versions, Yandex.Auto settings can also be accessed from the Connections screen.

"Apps settings (where fitted)" (page 33)

## YANDEX.AUTO SYSTEM LIMITATIONS

For all features of Yandex.Auto to operate correctly, it is necessary to have a compatible smartphone, a cellular connection and a data plan.

When Yandex.Auto is operating, system performance is affected by the strength of the cellular connection or performance of the phone itself. If performance of the system decreases:

- Disconnect and reconnect your phone
- Cycle phone power off/on to restart

Changing government regulations may also affect operation of Yandex.Auto.

Apple Siri Eyes Free personal assistant can be accessed from the vehicle. Siri Eyes Free can be accessed in Siri Eyes Free mode to reduce user distraction. In this mode, Siri Eyes Free is available for interaction by voice control. After connecting a compatible Apple device via Bluetooth®, Siri Eyes Free can be activated by using **<** **>** (where fitted) on the steering wheel.

Siri is a trademark of Apple Inc., registered in the U.S. and other countries.

**INFO:**

- Depending on the countries, the voice operation is not available and **<** **>** may not function.
- Some Siri Eyes Free functions, such as opening apps, may not be available during driving.
- For best results, always update your device to the latest software version.
- Keep the interior of the vehicle as quiet as possible. Close the windows to eliminate the surrounding noises (traffic noises, vibration sounds, etc.), which may prevent the system from recognising the voice commands correctly.
- For functions that can be used in Siri Eyes Free, please refer to the Apple website.

## REQUIREMENTS

Visit Apple's website for details about device compatibility.

Siri must be enabled on the phone. Please check phone settings.

If the device has a lock screen, Siri must be accessible from the lock screen. Please check phone settings.

## SIRI EYES FREE ACTIVATION

Siri Eyes Free function can be activated using **<** **>** (where fitted) on the steering wheel.

1. Connect a Siri Eyes Free enabled iPhone to the vehicle.

   ☞ "Setting Bluetooth®" (page 30)

2. After the Bluetooth® connection is established, push and hold **<** **>** (where fitted) on the steering wheel to activate the Siri Eyes Free function.

## OPERATING SIRI EYES FREE

1. Push and hold **<** **>** (where fitted) on the steering wheel.
2. Speak your command and then listen to the Siri Eyes Free reply.

After starting Siri Eyes Free, push **<** **>** (where fitted) on the steering wheel again within five seconds of the end of the Siri Eyes Free announcement to extend the session.

# 6 Navigation (where fitted)


Safety information ..... 108
Navigation screen ..... 108
- Displaying navigation screen ..... 108
- Launch bar ..... 108

Map operation ..... 109
- Map types ..... 109
- Road colour ..... 115
- Moving map ..... 115
- Changing scale of map ..... 116
- Map settings ..... 118
- Traffic information on map (where fitted) ..... 121
- Map menu screen ..... 121

Setting destination ..... 121
- Basic operations ..... 121
- Options before starting the route guidance ..... 123

Route guidance ..... 124
- About route guidance ..... 124
- Route menu ..... 124
- Route preference ..... 126
- Recalculating route ..... 128
- Editing route ..... 128
- Guidance settings ..... 131

Viewing traffic information (where fitted) ..... 132
- RDS-TMC feature (where fitted) ..... 132
- Premium traffic information (where fitted) ..... 132
- Viewing available traffic information ..... 132
- Traffic information settings ..... 134

Storing a location/route ..... 134
- Storing location ..... 134
- Storing route ..... 136
- Storing avoid area ..... 136
- Editing stored information ..... 138
- Deleting stored item ..... 142


Navigation settings ..... 143
General information for navigation system ..... 144
- Current vehicle location ..... 144
- Route calculation ..... 148
- Route guidance ..... 149
- How to update map data (where fitted) ..... 150

The navigation system is primarily designed to help you reach your destination. However, you, the driver, must use the system safely and properly. Information concerning road conditions, traffic signs and the availability of services may not always be up to date. The system is not a substitute for safe, proper, and legal driving.

**⚠ WARNING**

**Do not rely on route guidance alone. Always be sure that all driving manoeuvres are legal and safe in order to avoid accidents.**

## DISPLAYING NAVIGATION SCREEN




5GB0760XZ

To display the current location map which can be operated, push **<MENU>** and then touch [Map] on the Launch Bar or push **<MAP>**.


## LAUNCH BAR

The Launch Bar related to operating the navigation system is displayed on the current location map screen. Displayed items vary depending on the route settings.




5GB0762XZ

**Before setting the destination**





5GB0761XZ

**After setting the destination**

| Menu item | Action |
|---|---|
| [Add Home]/ [Go Home] | [Add Home]:<br>When the home location is not stored, a home location can be stored in the system.<br>☞ "Storing home or work location" (page 134)<br>[Go Home]:<br>When the home location is stored, sets the home location as a destination. |
| [POI] | Searches for a Points of Interest to set as a destination. |
| [Destination] | Displays the destination menu.<br>☞ "Setting destination" (page 121) |
| [Zoom Out] | Zoom out the map.<br>☞ "Changing scale of map" (page 116) |
| [Zoom In] | Zoom in the map.<br>☞ "Changing scale of map" (page 116) |
| [Cancel] | Cancels the route guidance. |
| [Route] | Displays the route menu screen.<br>☞ "Route menu" (page 124) |

## MAP TYPES

Two types of map views are available: 2D and 3D.




PBB0120XZ

## 2D map (except for the Middle East)

The 2D map displays the map in a two-dimensional environment similar to a road map.

The location of the displayed icons and information may vary depending on models, specifications and software versions.

**Screen information:**

① Arrow and distance:

Indicates the distance to the next guide point and the turning direction at that guide point.

If the current vehicle position is off the road, an arrow indicating the direction to the nearest road may be displayed instead of displaying the next turn arrow/distance.

② Next street name:

Displays the next street name during the route guidance.

③ 1 Waypoint:

Displays the location of the waypoint that the vehicle will stop by before heading to the final destination. A maximum of 20 waypoints can be set.

④ Destination:

Indicates the location of the final destination.

⑤ Stored location:

Displays the locations that are stored in the Address Book.

☞ "Storing location" (page 134)

The icons can be changed according to your preferences.

⑥ 30 Speed limit indicator (where fitted):

Displays the speed limit of the road which the vehicle is on.

When [Speed Limit Warning] is turned [ON] and the vehicle speed exceeds the limit the indicator flashes and an audible beep should be heard.

When the speed limit indicator is not displayed in the unit selected in the Unit settings screen (where fitted), a speed limit in the selected unit may be displayed below the speed limit indicator.

The settings for the speed limit indicator can be changed.

"Navigation settings" (page 143)

⑦ [] (where fitted):

Touch the icon to connect to the NissanConnect Services Interactive Voice Menu.

"Connecting to Interactive Voice Menu" (page 91)

⑧ []:

Touch to display the Map Menu.

"Map menu screen" (page 121)

⑨ Recommended lane indicator:

When a route is set, the arrow and the recommended driving lane may be displayed depending on the road.

Blue: First recommendation

White: Secondary recommendation

Gray: Not recommended

⑩ Remaining distance to the destination:

Indicates the approximate remaining distance to the destination or the waypoint. This indicator will appear when a destination is set and route guidance is started.

⑪ Remaining time/Time of arrival:

Indicates the remaining time to the destination/waypoint, or it can be set to display the estimated arrival time. This indicator will appear when a destination is set and the route guidance is started.

The remaining time or arrival time display can be selected to your preference.

"Route preference" (page 126)

⑫ Suggested route:

Appears in bold blue during route guidance.

⑬ Street name:

Displays the name of the street that the vehicle is currently driving on.

⑭ Vehicle icon:

Indicates the current vehicle location and the direction that the vehicle is heading.

⑮ Scale indicator:

Indicates the scale of the map.

⑯ Traffic information reception status indicator (where fitted):

This indicator is displayed in a condition where traffic information can be received.

Touch to display the traffic information screen.

"Viewing traffic events from list" (page 132)

[Premium Traffic] (where fitted):

Displayed when Premium Traffic information (where fitted) is active and the traffic information is available.

"Traffic information settings" (page 134)

[TMC] (where fitted):


Displayed when RDS-TMC (where fitted) is active and the traffic information is available.

"Traffic information settings" (page 134)

⑰ []:

Indicates the directional setting of the map.

Touch to change the map view and the map orientation.




PBB0001X

**Example**

## 2D map (for the Middle East)

The 2D map displays the map in a two-dimensional environment similar to a road map.

The location of the displayed icons and information may vary depending on models and specifications.

**Screen information:**

① Arrow and distance:

Indicates the distance to the next guide point and the turning direction at that guide point.

If the current vehicle position is off the road, an arrow indicating the direction to the nearest road may be displayed instead of displaying the next turn arrow/distance.

② Next street name:

Displays the next street name during the route guidance.

③ Waypoint:

Displays the location of the waypoint that the vehicle will stop by before heading to the final destination. A maximum of 20 waypoints can be set.

④ Destination:

Indicates the location of the final destination.

⑤ Stored location:

Displays the locations that are stored in the Address Book.

"Storing location" (page 134)

The icons can be changed according to your preferences.

⑥ Speed limit indicator:

Displays the speed limit of the road which the vehicle is on.

When [Speed Limit Warning] is turned [ON] and the vehicle speed exceeds the limit the indicator flashes and an audible beep should be heard.

The settings for the speed limit indicator can be changed.

☞ "Navigation settings" (page 143)

⑦ [ ]:Touch to display the compass mode display.

☞ "Compass mode display (for the Middle East)" (page 114)

⑧ [ ]:

Touch to display the Map Menu.

☞ "Map menu screen" (page 121)

⑨ Recommended lane indicator:

When a route is set, the arrow and the recommended driving lane may be displayed depending on the road.

Blue: First recommendation

White: Secondary recommendation

Grey: Not recommended

⑩ Remaining distance to the destination:

Indicates the approximate remaining distance to the destination or the waypoint. This indicator will appear when a destination is set and route guidance is started.

⑪ Remaining time/Time of arrival:

Indicates the remaining time to the destination/waypoint, or it can be set to display the estimated arrival time. This indicator will appear when a destination is set and the route guidance is started. The remaining time or arrival time display can be selected to your preference.

☞ "Route preference" (page 126)

⑫ Suggested route:

Appears in bold blue during route guidance.

⑬ Street name:

Displays the name of the street that the vehicle is currently driving on.

⑭ Vehicle icon:

Indicates the current vehicle location and the direction that the vehicle is heading.

⑮ Scale indicator:

Indicates the scale of the map.

⑯ Traffic information reception status indicator:

This indicator is displayed in a condition where traffic information can be received. Touch to display the traffic information screen.

☞ "Viewing traffic events from list" (page 132)

[Premium Traffic] (where fitted):

Displayed when Premium Traffic information (where fitted) is active and the traffic information is available.


☞ "Traffic information settings" (page 134)

⑰ [ ]:

Indicates the directional setting of the map. Touch to change the map view and the map orientation.

## 3D map

The 3D map displays the map from an elevated perspective. In 3D map, it is easy to recognise an image of the route because it provides a panoramic view over a long distance.




5GB0764XZ

**INFO:**

The 3D map always appears with the current forward direction facing up.


## Building graphics

Building graphics are stored in the map data for certain areas, and can be displayed when the map is zoomed in.



5GB0765XZ

**2D building graphics**




5GB0831XZ

**3D building graphics (where fitted)**

**INFO:**

In an area where the building graphics are not stored in the map data, the normal map is displayed even when the map is zoomed in.




PBB0002XZ

## Compass mode display (for the Middle East)

The compass mode can be useful in areas such as deserts where there are no roads or where the area information is not included in the map data. This mode helps the driver to get to the destination by showing the current vehicle location at the centre of the map.

Touch [ ] on the map screen to switch to the compass mode screen.

① Latitude/longitude of current location

② Estimated time of arrival and distance to waypoint/destination

③ Latitude/longitude of waypoint/destination

④ Direction and straight distance to the destination

⑤ Estimated time of arrival at the destination

⑥ Current vehicle location and the direction to waypoint/destination

If no destination has been set, only the latitude and longitude of the current location are displayed.

**INFO:**

- When the compass mode is active, route guidance will not be provided.
- Touch [Delete] to delete the information of waypoint/destination. Once deleted, the deleted information cannot be displayed again.
- Details of this function are subject to change.

## ROAD COLOUR

The road types are differentiated by colour.

**Except for Mexico:**

| Colour | Road type |
|---|---|
| Yellow and red outline | Motorway |
| Red or orange | Main road |
| Yellow or white | Narrow street |

**For Mexico:**

| Colour | Road type |
|---|---|
| Dark red | Freeway |
| Light brown | Major road |
| Light green | Secondary road |
| White | Local road |


**For Taiwan:**

| Colour | Road type |
|---|---|
| Yellow and red outline or Red | Freeway |
| Light brown | Major road |
| White | Narrow street |

## MOVING MAP

The map can be scrolled by the touch panel operations. Map scrolling operations may be limited while driving.

**Touch:**



5GB0707XZ

When a point on the map is touched, the cross pointer is displayed and the position touched is moved to the centre of the screen.

After moving the map, touch [ ⮌ ] on the map screen or push **<MAP>** to display the current location map screen.

**Long touch:**

Touch the direction to move to. The map continues to scroll while the screen is touched.

**Drag:**

Drag the screen to scroll the map.


**Swipe/flick:**

Swipe or flick the screen to scroll the map screen quickly.

**INFO:**

Sliding the slide switch on the Display Commander (where fitted) can also operate the map.

## CHANGING SCALE OF MAP




5GB0767XZ

To change the map scale, touch [Zoom Out] or [Zoom In] on the Launch Bar.

**Other operations:**

- While the cross pointer is displayed, the scale bar can be displayed by touching the scale indicator on the map.

  Touching [⊖] or [⊕] on the scale bar can change the map scale while the scale bar is displayed.

- Turning the centre dial on the Display Commander (where fitted) can also change the map scale.

- Depending on the models, rotating **<TUNE SCROLL/SOUND>/ /<TUNE SCROLL/ENTER SOUND>/ /<TUNE SCROLL/PUSH SOUND>/ /<TUNE SCROLL/ENTER SETTING>/ /<TUNE SCROLL/OK>/ /<⊖ ⊕/ENTER SOUND>/ /<⊖ ⊕/SOUND>/ /<⊖ ⊕/OK>** (where fitted) can also change the map scale.

- While the cross pointer is displayed, pinching in or out with your fingers on the map screen can also change the map scale.

Free Zoom:

Depending on the models and setting, rotating **<TUNE SCROLL/SOUND>/ /<TUNE SCROLL/ENTER SOUND>/ /<TUNE SCROLL/PUSH SOUND>/ /<TUNE SCROLL/OK>/ /<⊖ ⊕/ENTER SOUND>/ /<⊖ ⊕/SOUND>/ /<⊖ ⊕/OK>** (where fitted) to change the map scale may adjust the scale normally, or it may engage the free zoom (finer scale adjustment in smaller steps).

☞ "Map settings" (page 118)

**INFO:**

- While driving, pinch-in and pinch-out operations may be disabled.
- Depending on the map scale, traffic information icons cannot be displayed on the map screen.

☞ "Traffic information on map" (page 133)

## MAP SETTINGS

The setup for the map view is performed from the Map Menu on the touch screen display.

1. Touch [] on the current location map screen.
2. Touch [Map Settings].

Available setting items may vary depending on models, specifications and software versions.

| **Menu item** | | **Action** |
|---|---|---|
| [Dual Map View] | [2D Map] | Displays 2D map. |
| | [3D Map] | Displays 3D map. |
| | [Split: 2D Map] | Displays 2D map on both left and right side of the split screen. You can see the different scale and settings of 2D maps at the same time. |
| | [Split: 3D Map] | Displays 2D map on the left side and 3D map on the right side of the split screen. |
| [Left Side Info] | [Intersection] | Displays the enlarged view of the next intersection on the left side of the screen during route guidance. |
| | [Turn List] | Displays the turn list on the left side of the screen when a route is set. |
| | [Drive Report] | Displays your eco drive report on the left side of the screen. |
| | [Full Map] | Displays full map screen. |
| [Map Icons] | | Select the categories of POI icons to display on the map screen. |

| Menu item | | | Action |
|---|---|---|---|
| [More Settings]/ [Others] | [Map Orientation] | | The map orientation can be selected from [North Up] or [Heading Up]. [Map Orientation] is available only when 2D map is displayed. |
| | [Long Range] | | The position of the vehicle icon is located slightly lower than the centre of the screen to view a wider area in the travelling direction. Long Range is available only when the map view is in [Heading Up] mode. |
| | [Left Split Map Settings] | [Map Orientation] | The map orientation for the left side of split screen can be selected from [North Up] or [Heading Up]. |
| | | [Long Range] | With this item turned on, the vehicle position icon on the left screen will be located slightly lower than the centre of the screen so that a wider area in the travelling direction can be viewed.<br>Long Range Map View is available only when the left side of split screen is in [Heading Up] mode. |
| | | [Map Scale] | Sets the map scale of the left screen. |
| | [Audio Display on Map] | | Turns on/off the audio information displayed at the top of the map screen. |
| | [Map Colour]/[Map Color] | | Sets map colour from [Standard], [Emphasise Roads]/[Emphasize Roads], [Emphasise Text]/[Emphasize Text] and [Emphasise Traffic]/[Emphasize Traffic] (where fitted). |
| | [Map Text Size] | [Large] | Sets the font size of the text displayed on the map screen. |
| | | [Medium] | |
| | | [Small] | |
| | [Select Text to Display on Map] | [Place Names] | Allows place, facility and road names to be displayed on the map screen. |
| | | [Facility Names] | |
| | | [Road Names] | |
| | [Map Scrolling Information] | | Information about the location, on which the centre of the cross pointer is placed by scrolling on the map, can be set to be displayed. |

| Menu item | | | Action |
|---|---|---|---|
| [More Settings]/ [Others] | [Tracking Dots Displayed on Map] | [Record & Show Tracking Dots on Map] | Turns the route tracking dots display on/off. |
| | | [Tracking Dot Distance] | Selects the interval between tracking dots. |
| | | [Delete Track to Current Location] | Deletes the route tracking dots up to the current location. |
| | [Small Step Zoom with Dial] | | Sets the free zoom function on/off. When this setting is on, it is possible to adjust the scale in smaller steps than with normal scale adjustment. |
| | [Show all M-way Exits on Route]/[Show all Freeway Exits on Route] | | Turns on/off the motorway exit information display. |
| | [Auto. Show Turn List on M-way]/[Auto. Show Turn List on Freeway] | | The turn list can be displayed automatically while driving on a motorway. |
| | [North Up when Zoomed Out] | | When this setting is turned on, the orientation of the map is automatically changed to [North Up] when the widest map scale is selected. |
| [Back to Map] | | | Back to the current location map. |

## TRAFFIC INFORMATION ON MAP (where fitted)

Traffic information can be displayed on the map.

"Traffic information on map" (page 133)

## MAP MENU SCREEN

Touch [icon] while the current location map screen or a scrolled map screen is displayed to display the menu corresponding to that screen.


This menu can be used to quickly access helpful functions, such as setting a destination or searching for points of interest nearby.

The system can provide route guidance once a destination is set.

## BASIC OPERATIONS

### Displaying destination setting menu

There are several methods that can be used to set a destination. Select a preferred method for finding and setting a destination.




5GB0807XZ

**Example**

Push **<MAP>** and then touch [Destination] on the Launch Bar.

Availability of the destination setting methods varies depending on the models, specifications and software versions. Items displayed on the screen may not function depending on various conditions.

**Available destination setting methods:**

| Setting item | Action |
|---|---|
| [Enter POI/Address] | Searches for a destination by inputting the address or POI names. |
| [Go Home] | Searches for a route from the current location to the previously stored home location. |
| [Street Address] | Searches for a destination by address. |
| [Points of Interest] | Searches for a destination from various categories. |
| [Previous Destinations] | Searches for the destination from the previous destinations and a previous start point. |
| [Go to Work] | Searches for a route from the current location to the previously stored work location. |
| [Address Book] | Searches for a destination from the vehicle Address Book. |
| [City Centre]/[City Center] | Sets the centre of a city as the destination. |
| [Intersection] | Sets an intersection as a destination. |
| [Phone Number] | Searches for a point of interest by a phone number. |
| [Destinations by Google] | Sets a place searched by Google as a destination. |
| [Saved Routes] | Sets a route from the saved route data. |
| [By Map] | Searches for a destination by map. |
| [SXM Travel Link] | This function cannot be used outside the USA and Canada. |
| [Latitude/Longitude] | Sets a destination from latitude and longitude. |
| [Door to Door Navigation]/[Smartphone Navigation] | Turns on/off Door to Door Navigation. |

**NOTE:**

**Notice for Point of Interest search:**
**Locations and business hours of facilities are subject to change, which may not be reflected in the map data. Double-check this information before you go to an emergency facility to ensure that you can receive the proper support. Otherwise, you may not receive emergency help when you arrive at the destination. A confirmation message also appears on the navigation screen. Follow the displayed instructions and check the items required.**

**INFO:**


- After setting a destination, the location of the destination can be adjusted and the location can be stored in the Address Book, etc.

  "Options before starting the route guidance" (page 123)

- The destinations can be cancelled and edited/added.

## OPTIONS BEFORE STARTING THE ROUTE GUIDANCE

Before starting the route guidance, select menus for route details to modify the route, preview the turn list, or store the route.




PBB0023XZ

- [Start]:

  Starts route guidance to the selected destination.

- [Add to Route]:

  Adds a location to the route previously set.

- [More Routes]:

  Suggests alternative routes.

- [Turn List]:

  Displays a detailed turn list. The map can be displayed and the turn can be avoided by touching a turning point.

- [Move Location]:

  Displays a map screen and allows the location of the destination to be adjusted.

- [More Options...]:
  Options such as viewing place information and saving locations/routes can be selected.

## ABOUT ROUTE GUIDANCE

After setting the route, select [Start] to start the route guidance.

During route guidance, the system navigates you through the guide points using visual and voice guidance.

**WARNING**

- **The navigation system's visual and voice guidance is for reference purposes only. The contents of the guidance may be inappropriate depending on the situation.**
- **Follow all traffic regulations when driving along the suggested route (e.g. one-way traffic).**

**"Route guidance" (page 149)**

### Voice guidance during route guidance

**Basics of voice guidance:**

Voice guidance announces which direction to turn when approaching an intersection for which a turn is necessary.

**INFO:**


- There may be some cases in which voice guidance and actual road conditions do not correspond. This may occur because of discrepancies between the actual road and the information on the map data, or may also be due to the vehicle speed.
- In case voice guidance does not correspond to the actual road conditions, follow the information obtained from traffic signs or notices on the road.
- When approaching a guide point (intersection or corner) or destination/waypoint during route guidance, voice guidance announces the remaining distance and/or turning direction. Push and hold **<MAP>** to repeat voice guidance.

## ROUTE MENU

**WARNING**

**Always stop the vehicle in a safe location before modifying the route conditions. Modifying the route conditions while driving may cause an accident.**

During route guidance, the route conditions can be modified and the route information can be confirmed. Set route conditions according to your personal preference.




5GB0830XZ

**Example**

Push **<MAP>** when a destination is set, and then touch [Route] on the Launch Bar.

The route menu screen is displayed.

**Available settings**

| Menu item | | Result |
|---|---|---|
| [Cancel Route] | | Cancels the current route guidance. |
| [Turn List] | | Displays the details of the suggested route. |
| [Detour] | | A detour of a specified distance can be calculated. |
| [Route Preference] | | Set the route search conditions. |
| [Recalculate] | | Manually search for the route again after changing the search conditions, etc. and have the system calculate a route. |
| [Show Destination] | [Move Location] | Displays a map screen and allows the location of the destination to be adjusted. |
| | [Nearby POIs] | Search for points of interest near the destination, such as restaurants and petrol stations, etc. The location can be set as a destination or a waypoint. |
| | [Save Location] | Save the destination in the Address Book. |
| [Edit/Add to Route] | | A destination or waypoint can be edited/added to a route that has already been set. |
| [Guidance Settings] | | Various guidance settings can be customised. |
| [Save Route] | | The current route (a destination and waypoints) can be saved. A maximum of 10 routes can be saved. The saved routes can easily be recalled for future use. Saved route includes only the location information, not the route itself. Route may vary depending on the traffic information (where fitted) or other conditions. |
| [Map Scroll] | | Displays the current map screen which can be scrolled to confirm the location of the destination, waypoints, route, etc. |
| [Simulation] | | Simulates the route guidance. This function provides a detailed image of the route with voice guidance.<br>The following operations are available:<br>[ ⏸ ]: Pauses the simulation.<br>[ ▶ ]: Resumes the simulation.<br>[ ■ ]: Ends the simulation.<br>[]: Increases the play speed. 4 levels of speed adjustment are available.<br>[]: Decreases the play speed. 4 levels of speed adjustment are available. |

## ROUTE PREFERENCE

It is possible to set the conditions of the route search.

1. Touch [Navigation] on the setting menu screen.
   ☞ "System settings" (page 28)
2. Touch [Route Preference].
3. Touch the item you would like to set.

Available items may vary depending on models, specifications and software versions.

| **Setting Item** | | | **Action** |
|---|---|---|---|
| [Basic Route Type] | [Fastest Route] | | Prioritises the use of fastest route. |
| | [Energy-Saving] | | Prioritises a route which uses less energy. |
| | [Shortest Distance] | | Prioritises the shortest route.<br>The route may not be the shortest because the system prioritises roads that are easy to drive on for safety reasons. |
| [Other Routing Choices] | [Minimise Motorways]/[Minimize Freeway] | | Minimises the use of motorways. |
| | [Minimise Toll Roads]/[Minimize Toll Roads] | | Minimises the use of toll roads. |
| | [Time Restricted Roads] | [Use Restriction Info] | Calculates route taking time restriction information into consideration. |
| | | [Do Not Use Restriction Info] | Calculates route without taking time restriction information into consideration. |
| | | [Avoid] | Calculates route avoiding the use of time restricted roads. |
| | [Seasonal Restricted Roads] | [Use Restriction Info] | Calculates route taking seasonal restriction information into consideration. |
| | | [Do Not Use Restriction Info] | Calculates route without taking seasonal restriction information into consideration. |
| | | [Avoid] | Calculates route avoiding the use of seasonal restricted roads. |
| | [Use Traffic Information] | [Auto] | Calculates the route automatically taking traffic information into consideration. |
| | | [Accept] | If a traffic jam or incident occurs, a confirmation screen will appear before calculation. |
| | | [OFF] | Calculates the route without taking traffic information into consideration. |
| | [Use Avoid Area Settings] | | When enabled, the system avoids the previously defined avoid areas. |
| | [Use Ferries] | | Includes the use of ferries. |
| | [Use Car-Carrying Trains] | | Includes the use of car-carrying trains. |
| | [Use Unpaved Roads] | | Includes the use of unpaved roads. |
| | [Use HOV Lanes] | | This function cannot be used outside the USA and Canada. |
| | [Use Learned Routes] | | Uses the roads that are most frequently travelled with the help of self-learning technology. |

| Setting Item | | Action |
|---|---|---|
| [Customise More Routes]/ [Customize More Routes] | [3 Types]/[3types] | Calculates 3 types of route when confirming other routes. |
| | [1 Type]/[1type] | Calculates routes with a route search condition selected on the [Basic Route Type] setting screen. ☞ "Route preference" (page 126) |
| [Estimated Time] | [Destination] | Displays the estimated time of arrival or remaining time to the destination during route guidance. |
| | [Waypoint] | Displays the estimated time of arrival or remaining time to the waypoint during the route guidance. |
| [Time Shown on Map] | [ETA] | Displays the estimated time of arrival. |
| | [Remaining] | Displays the remaining time to arrival. |

**INFO:**

- [Route Preference] can also be accessed from route menu screen.
- If the vehicle greatly deviates from the suggested route, the system calculates a new route.
- Traffic jam information (where fitted) displayed on the map screen is not statistical traffic information.
- If [Do Not Use Restriction Info] is selected for [Time Restricted Roads] setting, the system calculates a route without any consideration of the regulations concerning the time or day of the week. Therefore, the suggested route may include a road subject to traffic regulations concerning the time or day of the week. When driving along the route, always follow all traffic regulations regardless of whether [Time Restricted Roads] is set to be considered or not.
- In the area where traffic information is not broadcast, [Use Traffic Information] setting is disabled.
- The system calculates to reduce the time required for the entire route from the start to the destination. If there are no appropriate routes, the system may lead to a route where a traffic jam occurs instead of leading to a detour.
- The system may not lead to a detour if the traffic closure or a traffic jam occurs far from the present location.

## RECALCULATING ROUTE

A route can be manually searched again after changing the search conditions, etc.


1. Push **<MAP>** and then touch [Route] on the Launch Bar.
2. Touch [Recalculate]. A message is displayed and the route is recalculated.
3. Touch [Start] or conduct other operations as necessary.

☞ "Options before starting the route guidance" (page 123)

**INFO:**

- When a waypoint has been set on the route, the system will search for only one route, even if route recalculation is performed.
- When the vehicle deviates from the suggested route, the route from the current location to the destination is automatically searched again by the Auto Reroute function.

## EDITING ROUTE




5GB0791XZ

1. Push **<MAP>** and then touch [Route] on the Launch Bar.
2. Touch [Edit/Add to Route].
3. Edit the following settings and touch [Calculate].

**Available settings**

① [Add Destination]:

Touch to add a new destination.

② Current destination:

Touch to edit or delete the destination.

☞ "Editing/deleting destination or waypoint" (page 129)

③ Criteria for calculating a route to the destination/waypoint:

Touch to change the conditions for route calculation.

☞ "Changing route calculation conditions" (page 130)

④ [Add Waypoint]:

Touch to add a waypoint.

☞ "Setting destination or waypoint" (page 129)

⑤ Current waypoint:

Touch to edit or delete the waypoint.

☞ "Editing/deleting destination or waypoint" (page 129)


⑥ [Calculate]:

After editing the route, touch to recalculate a route with new conditions.

## Setting destination or waypoint

A destination or waypoint can be added to a route that has already been set. Up to 20 waypoints besides one destination can be set.

1. Push **<MAP>** and then touch [Route] on the Launch Bar.
2. Touch [Edit/Add to Route].




5GB0781XZ

3. Touch [Add Destination] or [Add Waypoint].

**INFO:**

If [Add Destination] is selected, the current destination changes to a waypoint.

4. Set a destination or waypoint. The method of searching for a waypoint is the same as the one for a destination.

"Setting destination" (page 121)

5. Touch [Add to Route] to add the location to the route.
6. The route information with the selected location added to the route is displayed. Adjust the route calculation conditions as necessary.

"Changing route calculation conditions" (page 130)

7. Touch [Calculate] to confirm the route change. The route will be recalculated.


**INFO:**

The prior route will be deleted automatically.

## Editing/deleting destination or waypoint

A destination or waypoint that has already been set can be modified or deleted.

1. Push **<MAP>** and then touch [Route] on the Launch Bar.
2. Touch [Edit/Add to Route].
3. Touch a destination or waypoint that is already set.




5GB0809XZ

**Example**

4. Touch to edit the following settings:

**Available settings**

- [Delete]:

  A selected destination or waypoint that has already been set can be deleted.

- [Change Order]:

  The order of a destination and waypoints that are already set can be changed.

- [Move Destination]/[Move Dest.]:

  The location of the destination or waypoint can be adjusted by moving the cross pointer across the map on the touch screen display.


5. Touch [Calculate] to apply the change.

**INFO:**

If the destination is deleted, the route guidance will be cancelled.

## Changing route calculation conditions

Each section of the route between waypoints can have different route calculation conditions.




**Example**

1. Push **<MAP>** and then touch [Route] on the Launch Bar.
2. Touch [Edit/Add to Route].
3. Touch the route condition shown on the preferred section of the route to the destination or waypoint.
4. Touch the preferred condition.

   "Route preference" (page 126)


   The conditions are changed and the display returns to the edit route screen.
5. Touch [Calculate] to apply the change.

**INFO:**

The recalculated route may not be the shortest route because the system prioritises roads that are easy to drive on for safety reasons.

## Changing order of destination and waypoints

The order of a destination and waypoints that are already set can be changed.




1. Push **<MAP>** and then touch [Route] on the Launch Bar.
2. Touch [Edit/Add to Route].
3. Touch a destination or waypoint that is already set.
4. Touch [Change Order].
5. Touch a preferred destination or waypoint to replace the previously selected destination or waypoint.
6. Touch [Calculate] to apply the change.

## GUIDANCE SETTINGS

Various settings are available to customise the guidance information provided by the system.

1. Touch [Navigation] on the setting menu screen.
   "System settings" (page 28)
2. Touch [Guidance Settings].
3. Touch an item you would like to set.

Available items may vary depending on models, specifications and software versions.

| Setting item | Action |
|---|---|
| [Guidance Volume] | Adjusts the volume level of voice guidance. |
| [Guidance Voice] | Activates or deactivates voice guidance. |
| [Traffic Announcement] | Activates or deactivates the traffic announcement.<br>When this item is activated, the system provides an announcement of traffic information or events on the route. The indicator illuminates if traffic announcement is activated. |
| [Toll Booth Guide] | Activates or deactivates the function to notify that the vehicle is approaching a toll booth. |

**INFO:**

- [Guidance Settings] can also be accessed from the route menu screen.
  "Route menu" (page 124)
- Even when [Traffic Announcement] is turned on, the traffic information is not announced in the area where traffic information is not broadcast.
- The guidance volume can also be adjusted by turning **<VOL/ >/<VOLUME/ >/<VOL/PUSH >/<VOL/PUSH POWER>**, pushing **<** **>** (where fitted) on the steering wheel or pushing **<** **>** (where fitted) on the steering column from behind while voice guidance is being announced.

# VIEWING TRAFFIC INFORMATION (where fitted)

Two types of traffic information are available on this system, RDS-TMC (Radio Data System - Traffic Message Channel) (where fitted) and Premium Traffic information (where fitted).

To activate RDS-TMC (where fitted), set [Use Premium Traffic] (where fitted) off.

To activate Premium Traffic information, set [Use Premium Traffic] on.

"Traffic information settings" (page 134)

## RDS-TMC FEATURE (where fitted)

The navigation system receives traffic information from the best available sources and enables the RDS-TMC to broadcast this information for the best possible guidance. The RDS-TMC broadcast is fed by a dedicated FM tuner so that you can still listen to the radio while Traffic Information is being broadcast. Traffic information can be displayed only in areas where RDS-TMC is broadcast. Traffic information is not available in some areas.

## PREMIUM TRAFFIC INFORMATION (where fitted)

Real-time traffic information can also be obtained from Premium Traffic information with more street coverage.

The types of events displayed on the screen are the same as RDS-TMC Information (where fitted).

Premium Traffic information is available by turning [Use Premium Traffic] on and connecting a Wi-Fi device (where fitted) or connecting a smartphone through Wi-Fi or through TCU (Telematics Control Unit) (where fitted).

"Traffic information settings" (page 134)

**INFO:**

For models with Door to Door Navigation, you can also use Premium Traffic information when a Door to Door Navigation enabled smartphone is connected to the vehicle.

## VIEWING AVAILABLE TRAFFIC INFORMATION

### Viewing traffic events from list


1. Push **<MENU>** and then touch [Info] on the Launch Bar.
2. Touch [Traffic Information] or [Premium Traffic]. A list of available types of information is displayed.

| Available items | Function |
|---|---|
| [Show Traffic on the Route] | Displays a list of traffic information found on the route from the current vehicle location to the destination. Available only when a route is set. |
| [Nearby Traffic Info] | Displays a list of available traffic information around the current vehicle location. |

**INFO:**

[Traffic Information] or [Premium Traffic] is available only when the traffic information is received.

3. Touch the preferred item. A list of available events are displayed.




5GB0811XZ

**Example**

4. Touch an event from the list to check the detailed information and the map. Touch [Avoid] to search for an alternative route.

### Displaying urgent traffic information

When an urgent event is found around the current vehicle location, a message pops up automatically on the touch screen display with a voice announcement.

The message includes the icon, event type, event information and the direct distance from the current location to the event.

**INFO:**


- When there are multiple urgent events, the event with the shortest direct distance from the current location is displayed.

- If the urgent event is on the recommended route, and if a detour is found, the detour route notification screen is displayed when the vehicle approaches the detour point.

## Traffic information on map

Traffic information is displayed on both 2D and 3D map screens.

**Screen information**




5GB0795XZ

**Example**

① Road conditions:

| | |
|---|---|
| Free Flow | Green |
| Slow traffic | Yellow |
| Heavy traffic | Red |
| Road closed and section affected by serious traffic event | Orange and white stripes |
| Queuing traffic | Orange |

② Traffic information icon:

If a route is not already set, all of the traffic information icons on the map screen are displayed in grey. When a route is already set, the icons on the route are displayed in colour, and the icons outside the route are displayed in grey.

**Except for Mexico:**

| | |
|---|---|
| | Stationary traffic |
| | Slow traffic |
| | Free flowing traffic |
| | Stretch is closed |
| | Accident |
| | Roadworks |
| | Narrow lanes |
| | All other events |

**For Mexico:**

| | |
|---|---|
| | Traffic jam |
| | Slow traffic |
| | Traffic flowing freely |
| | Road closed |
| | Accident |
| | Road work |
| | Narrow lanes |
| | All other events |

③ Remaining distance and time:

Remaining distance and time calculated with consideration of traffic information on route.

Whether to display the remaining time to the destination or estimated arrival time at the destination can be selected.

"Route preference" (page 126)

④ Traffic indicator:

**TMC (where fitted)**

Displayed when there is available RDS-TMC received.

**Premium Traffic (where fitted)**


Displayed when there is available Premium Traffic information received.

**INFO:**

Traffic icons are displayed in the scale level of 15 m (1/64 miles) - 12.5 km (7.5 miles) range. Some traffic icons are displayed only on the map at higher detail levels.

## TRAFFIC INFORMATION SETTINGS

Settings for traffic information related functions can be changed.




5GB0812XZ

**Example**

1. Touch [Navigation] on the setting menu screen.
"System settings" (page 28)
2. Touch [Traffic Info Settings].
3. Touch the preferred setting. The indicator for the selected setting illuminates.

Available setting items may vary depending on models, specifications and software versions.

**Available setting items**

- [Use Premium Traffic]:

  Turns the Premium Traffic information (where fitted) on/off.
- [Filter Traffic Icons]:

  Selects which types of traffic incidents (e.g., accident) will be displayed on the map screen.
- [Premium Traffic Update Settings]:

  Sets the update timing of Premium Traffic information (where fitted).

**INFO:**


- [Use Premium Traffic] functionality may not be available depending on the models, specifications and software versions.
- [Traffic Info Settings] can also be accessed from current location map screen.
- Even when [Traffic Announcement] is set to off, the route guidance will not be affected. Also, the announcement of emergency information will not be turned off.
"Guidance settings" (page 131)

## STORING LOCATION

Often visited locations can be stored in the Address Book. The stored addresses can be easily retrieved to set them as a destination or waypoint. The Address Book can store up to 200 locations.

### Storing home or work location

A home or work location can be stored in the system.



5GB0785XZ

1. Touch [Navigation] on the setting menu screen.
"System settings" (page 28)
2. Touch [Address Book].
3. Touch [Add Home Location] or [Add Work Location].
4. Touch an appropriate method to set a location. Refer to the search methods used for destination setting.
"Setting destination" (page 121)
5. Touch [OK].

6. A message is displayed, and the address of the location is stored in the Address Book.
7. Adjust and edit the contents of the stored item as necessary. Touch [OK] to confirm.


☞ "Editing stored location" (page 138)

**INFO:**

If you touch [Go Home (Save Location)] or [Go to Work (Save Location)] on the destination screen while the home or work location is not stored yet, the system will display a message asking if you wish to store a home or work location. Touch [Yes] to store the home or work location.

## Storing location by searching

It is possible to store a location by searching in various ways.




5GB0792XZ

1. Touch [Navigation] on the setting menu screen.

☞ "System settings" (page 28)

2. Touch [Address Book].
3. Touch [Saved Locations].
4. Touch [Add New].
5. Touch an appropriate method to set a location. Refer to the search methods used for destination setting.

☞ "Setting destination" (page 121)

6. Touch [OK].
7. A message is displayed, and the address of the location is stored in the Address Book.
8. Adjust and edit the contents of the stored item as necessary. Touch [OK] to confirm.


☞ "Editing stored location" (page 138)

**INFO:**

- When the location is stored in the [Saved Locations], [Address Book] can be used to search for the location.
- When 200 locations are already stored, a new location cannot be stored until a currently stored location is deleted.

## Storing location by moving map

1. Move to the preferred location on the map and touch [ ] on the touch screen display.




5GB0745XZ

2. Touch [Save Location]. A message is displayed.
3. The icon representing the stored location is displayed on the map. Push **<MAP>** to return to the current location map screen.

## STORING ROUTE

A maximum of 10 calculated routes can be stored. Stored routes can be easily retrieved and set as the suggested route.

A route requires at least one waypoint in order to be stored.

1. Push **<MAP>** and then touch [Route] on the Launch Bar.
2. Touch [Save Route]. A confirmation message is displayed. If asked, touch [Yes] to store the current route.

**INFO:**

- At least 1 waypoint must be set for the route to be stored.
- A stored route includes only locations (destination and waypoints) and route calculation conditions, not the route itself.
- The route is stored in the first available position number in the stored routes list.
- When 10 routes are already stored in the address book, a new route cannot be stored until a route is deleted.

"Deleting stored item" (page 142)


## STORING AVOID AREA

An Avoid Area can be stored. The Avoid Area is an area that can be excluded from a route, such as a road that is always congested. Once Avoid Areas are stored, the system avoids those areas when calculating a route. Up to 10 Avoid Areas can be stored.

1. Touch [Navigation] on the setting menu screen.

"System settings" (page 28)

2. Touch [Address Book].
3. Touch [Avoid Area].




5GB0746XZ

4. Touch [Add New].

   Touch an appropriate method to search for a location.

"Setting destination" (page 121)

5. Touch [OK].
6. Adjust the information of the Avoid Area as necessary.

"Editing avoid area" (page 141)

7. Touch [OK] to store the avoid area information.

**INFO:**

A maximum of 10 Avoid Areas can be stored. When 10 Avoid Areas are already stored, a new Avoid Area cannot be stored until a currently stored Avoid Area is deleted.

"Deleting stored item" (page 142)

## EDITING STORED INFORMATION

Items stored in the system can be edited.

### Editing stored location

1. Touch [Navigation] on the setting menu screen.

   ☞ "System settings" (page 28)

2. Touch [Address Book].

Available items may vary depending on models, specifications and software versions.

| **Setting item** | | | **Action** |
|---|---|---|---|
| [Home Location]* | [Edit] | [Show Icon on Map] | Displays the home icon on the map. |
| | | [Icon] | Selects a home icon of a preferred design. |
| | | [Sound] | Sets the type of the alarm that sounds when the vehicle approaches home. |
| | | [Direction] | Sets the alarm to sound when approaching from a specific direction. |
| | | [Distance] | Sets the alarm to sound when reaching a specific distance to home. |
| | | [Phone Number]/[Phone No.] | Stores the home phone number. |
| | [Move Location] | | Adjusts the stored home location. |
| | [Delete] | | Deletes the stored home location. |
| | [OK] | | Confirms and saves the edited home information. |

| Setting item | | | Action |
|---|---|---|---|
| [Work Location]* | [Edit] | [Show Icon on Map] | Displays the work icon on the map. |
| | | [Icon] | Selects a work icon of a preferred design. |
| | | [Sound] | Sets the type of the alarm that sounds when the vehicle approaches work. |
| | | [Direction] | Sets the alarm to sound when approaching from a specific direction. |
| | | [Distance] | Sets the alarm to sound when reaching a specific distance to work. |
| | | [Phone Number]/[Phone No.] | Stores the work phone number. |
| | [Move Location] | | Adjusts the stored work location. |
| | [Delete] | | Deletes the stored work location. |
| | [OK] | | Confirms and saves the edited work information. |

| Setting item | | | | Action |
|---|---|---|---|---|
| [Saved Locations] | [Sort] | [Sort by Number] | | Sorts the saved locations. |
| | | [Sort by Name] | | |
| | | [Sort by Icon] | | |
| | | [Sort by Group] | | |
| | [Add New] | | | Adds a new location.<br>☞ "Storing location by searching" (page 135) |
| | Saved Location List | [Edit] | [Show Icon on Map] | Displays the icon of a stored location on the map. |
| | | | [Name] | Registers a name of the entry. |
| | | | [Voice Tag] | Registers a voice tag for the entry which allows the entry to be used with the Voice Recognition System (where fitted). |
| | | | [Icon] | Selects an icon for the entry. |
| | | | [Sound] | Sets the type of the alarm that sounds when the vehicle approaches the location. |
| | | | [Direction] | Sets the alarm to sound when approaching from a specific direction. |
| | | | [Distance] | Sets the alarm to sound when reaching a specific distance to the location. |
| | | | [Phone Number]/ [Phone No.] | Registers a phone number for the location. |
| | | | [Group] | Registers a group of the entry. |
| | | | [Entry Numbers] | Registers an entry number for the location. |
| | | [Move Location] | | Adjusts the stored location information. |
| | | [Delete] | | Deletes the stored location information. |
| | | [OK] | | Confirms and saves the edited stored location information. |

*: When home or work location has not been stored, [Add Home Location] or [Add Work Location] is displayed and a home or work location can be stored from the menu.

## Editing stored route

1. Touch [Navigation] on the setting menu screen.
   ☞ "System settings" (page 28)
2. Touch [Address Book].
3. Touch [Saved Routes].
4. Touch the preferred saved route from the list. The Saved Routes settings screen will be displayed.

| Setting item | Action |
|---|---|
| [Rename] | Changes the saved route name. |
| [Replace] | Overwrites the saved route with the current route. |
| [Delete] | Deletes the saved route. |
| [OK] | Applies the edited settings. |

## Editing avoid area

1. Touch [Navigation] on the setting menu screen.
   ☞ "System settings" (page 28)
2. Touch [Address Book] and then touch [Avoid Area].
3. Touch a preferred Avoid Area from the list. The Avoid Area settings screen will be displayed.

| Setting item | Action |
|---|---|
| [Rename] | Changes the name of an Avoid Area. |
| [Move Location] | Adjusts the Avoid Area location. |
| [Resize Area] | Adjusts the size of the Avoid Area. |
| [Motorway]/ [Freeway] | Sets the Avoid Area to include or not include motorways.<br>The colour of the Avoid Area changes depending on the setting.<br>Motorway ON: Green<br>Motorway OFF: Blue |
| [Delete] | Deletes an Avoid Area. |
| [OK] | Applies the edited setting. |

## DELETING STORED ITEM

The locations and routes in the Address Book can be deleted. Deleting an individual item and deleting all stored items are available.

**INFO:**

Deleted items cannot be restored. Before deleting an item, always make sure that the item is no longer needed.

### Deleting stored item individually

1. Touch [Navigation] on the setting menu screen.

   "System settings" (page 28)


2. Touch [Address Book].
3. Touch [Delete Saved Items].

   Select the preferred item and touch [Yes] to confirm deletion.

| Step 1 | Step 2 | Action |
|---|---|---|
| [Delete Home Location] | | Deletes home location. |
| [Delete Work Location] | | Deletes work location. |
| [Delete Address Book] | [Delete All] | Deletes all stored locations. |
| | [Delete One] | Deletes a selected stored location. |
| [Delete Saved Routes] | [Delete All] | Deletes all stored routes. |
| | [Delete One] | Deletes a selected stored route. |
| [Delete Avoid Areas] | [Delete All] | Deletes all Avoid Areas. |
| | [Delete One] | Deletes a selected Avoid Area. |
| [Delete Previous Destinations] | [Delete All Previous Destinations] | Deletes all of the previous destinations. |
| | [Delete One Previous Destination] | Deletes a selected previous destination. |
| | [Delete Previous Starting Point] | Deletes the previous starting point. |
| [Delete Learned Routes] | | Deletes the learned routes. |

## Deleting individual item on map

1. Align the cross pointer over the stored location to be deleted by moving on the map, and then touch [ ].




5GB0747XZ

2. Touch [Delete].
3. A confirmation message is displayed. Confirm the contents of the message and touch [Yes].

   The stored item is deleted from the Address Book.

The navigation system can be customised according to the user's preference.

1. Touch [Navigation] on the setting menu screen.

   "System settings" (page 28)

2. Touch the item you would like to set.

Available setting items may vary depending on models, specifications and software versions.

**Available items:**

- **[Map Settings]**

  Sets the display method and direction of the map.

  "Map settings" (page 118)

- **[Guidance Settings]**

  Sets the various functions for route guidance.

  "Guidance settings" (page 131)

- **[Route Preference]**

  Changes the routing preferences.

  "Route preference" (page 126)

- **[Traffic Info Settings]**

  Sets the various functions of the Traffic information feature.

  "Traffic information settings" (page 134)

- **[Safety Guide Settings]**

| Setting item | Action |
|---|---|
| [Speed Limit Indication on Map] | When this item is turned on, the speed limit indicator will appear on the right side of the map screen when there is a speed limit on the road the vehicle is driving on.<br>"2D map (except for the Middle East)" (page 110)<br>"2D map (for the Middle East)" (page 112) |
| [Speed Limit Warning] | When this item is turned on, the speed limit indicator will blink and make an audible sound to warn the driver when the vehicle speed exceeds the speed limit.<br>"2D map (except for the Middle East)" (page 110)<br>"2D map (for the Middle East)" (page 112) |
| [Speed Limit Sens.] | Adjusts the speed limit sensitivity for [Speed Limit Warning]. |

- **[Speed Limit Indication on Map]**

  Depending on vehicle specification, when this item is turned on, the speed limit indicator will appear on the right side of the map screen when there is a speed limit on the road the vehicle is driving on.

  "2D map (except for the Middle East)" (page 110)

- **[Speed Limit Warning]**

  When this item is turned on, the speed limit indicator will blink and warn the driver when the vehicle speed exceeds the speed limit.

  ☞ "2D map (except for the Middle East)" (page 110)

- **[Speed Limit Sens.]**

  Adjusts the speed limit sensitivity for [Speed Limit Warning].

- **[Address Book]**

  Stores locations and routes. Stored items can be edited or deleted.

  ☞ "Storing a location/route" (page 134)

- **[Customise POIs]/[Customize POIs]**

  Sets the POI categories to be displayed on the Points of Interest screen.

- **[Adjust Current Location]**

  If the vehicle icon indicating the current vehicle location is not in the correct position, the location of the vehicle icon on the map screen can be adjusted.

- **[Delete Saved Items]**

  Deletes a saved location or route.

  ☞ "Deleting stored item individually" (page 142)

- **[Delete Previous Destinations]**

  Deletes all or one of the previous destinations or the previous start point.

  ☞ "Deleting stored item individually" (page 142)

- **[Sync with Door to Door Navi]/[Sync with Smartphone Navi.]**

  Turns on/off Door to Door Navigation.

- **[Reset All Navigation Settings to Default]**

  This resets various settings (display, volume level, etc.) to the default settings.

## CURRENT VEHICLE LOCATION

### Display of current vehicle location

This navigation system combines the data obtained from the vehicle (by gyro sensor) and from the Global Navigation Satellite System (GNSS) to calculate the current location of the vehicle. This position is then displayed throughout route guidance to a destination.

### What is the Global Navigation Satellite System (GNSS)?


GNSS is a general term for positioning systems that use signals from satellites. This navigation system receives radio signals from three or more different satellites, and detects the position of the vehicle by utilising the principle of triangulation.

**Positioning adjustment:**


When the system judges that the vehicle position is not accurate based on vehicle speed and gyro sensor data calculations, the system will automatically adjust the position of the vehicle icon using GNSS signals.

**Receiving signals from GNSS satellites:**


The reception of GNSS signals can be weak, depending on the environment. Vehicles in the following areas/environments may not receive GNSS signals.


NAI0422

- Inside tunnels or parking garages


NAI0423


- In areas with numerous tall buildings


NAI0424

- Under multi-layered highways


NAI0425

- Areas with numerous tall trees


NAI0713


- In canyons

**INFO:**

The GNSS antenna is located behind the instrument panel inside the vehicle and/or inside the shark fin antenna (where fitted) on the roof. Do not place any objects, especially mobile phones or transceivers, on the instrument panel. Because the strength of the GNSS signal is weak, phones and transceivers will affect or may totally disrupt the signal.


## Incorrect display of vehicle position

The following cases may affect the display accuracy of the vehicle's position or travelling direction. The accuracy will return to normal if the driving conditions return to normal.




NAI0426

- When there is a similar road nearby.




NAI0427

- When the vehicle is travelling in an area with a grid pattern road system.




NAI0428

- When the vehicle is passing through a large Y-shaped intersection/junction.




NAI0429

- When the vehicle is travelling on a continuous, slowly curving road.



NAI0430

- When the vehicle is travelling on a road with repeating S-shaped curves.




NAI0431


- When the vehicle is on a loop bridge.


NAI0432


- When the vehicle is on a snow-covered or unpaved road.


NAI0433


- When repeatedly turning left or right, or driving in zigzags.


NAI0434

- When the vehicle is rotated on a parking lot turntable while the ignition switch or power switch placed in the OFF position.


NAI0435

- When driving on a road not displayed on the map screen or a road that has been changed due to additional construction or other reasons.


NAI0436

- When the GNSS positioning accuracy is low.

**INFO:**

- The vehicle icon may be misaligned when starting the vehicle just after starting the engine or e-POWER system.
- The vehicle icon may also be misaligned if different sized tyres or tyre chains are installed.
- The system has a function that automatically corrects the vehicle icon position when it is misaligned from the actual position.
- Vehicle position correction by GNSS may not function when the vehicle is stopped.
- If the vehicle icon position does not return to normal even after driving for a while, correct the vehicle icon position manually.

## Detailed Map Coverage Areas (MCA) for navigation system

This system is designed to help guiding to the destination, and it also performs other functions as outlined in this manual. However, the system must be used safely and properly. Information concerning road conditions, traffic signs and the availability of services may not always be up-to-date. The system is not a substitute for safe, proper and legal driving.

Map data covers select metropolitan areas.

Map data includes two types of areas: "Detailed coverage areas" providing all detailed road data and other areas showing "Main roads only".

**INFO:**

Detailed map data is not available in many areas and is generally limited to select major metropolitan areas.

**CAUTION**

**Map coverage may vary from region to region and may also be inaccurate or incomplete as road conditions, including traffic restrictions, are beyond the control of the map manufacturer and can change frequently. The map manufacturer is responsible for the breadth of coverage.**

## ROUTE CALCULATION

- The suggested route may not be the shortest, nor are other circumstances such as traffic jams considered.
- Because of the inevitable difference in road conditions and circumstances between the time you use this system and the time the information was produced for the map data, there may be discrepancies in roads and regulations. In such cases, actual road conditions and regulations take precedence over map data information.
- During route calculation, the map will not scroll, however the vehicle icon will move according to the actual vehicle's movement.
- During route calculation, buttons such as **<MAP>** and **<MENU>** will be disabled.
- In some cases, after the calculation is complete, the calculated route may not be immediately displayed.
- Waypoints that have been passed will be disregarded by rerouting calculation.
- If you scroll the map while the suggested route is being drawn, it may take more time to finish drawing.
- Route calculation may not be completed in the following cases.
  - If there is no main road within a range of 2.5 km (1.5 miles) from the vehicle, a message saying so will appear on the screen. Try recalculating when the vehicle is closer to a main road.
  - If there is no main road within a range of 2.5 km (1.5 miles) from the destination or waypoint, a message saying so will appear on the screen. Try setting the location closer to a main road.
  - If the vehicle is too close to the destination or if there are no roads to the destination, a message saying so will appear on the screen.
  - If it is impossible to reach the destination or waypoints because of traffic regulations, etc.
  - If the only route to reach the destination or waypoints is extremely complicated.
- The following may occur when the route is displayed.
  - If you calculate a route on a main road, the starting point of the route may not exactly match the current vehicle location.
  - The endpoint of the route may not exactly match the destination.
  - If you calculate a route on a main road, the system may display a route from another main road. This may be because the position of the vehicle icon is not accurate. In this case, park the vehicle in a safe location and reset the vehicle icon, or continue driving to see if the position of the vehicle icon is automatically adjusted before recalculating the route.

- There are cases in which the system shows an indirect route to reach the destination or waypoints, if you set them from stored or facility information. In order to correct this, you must be careful about the traffic direction, especially when lanes with different travel directions are shown separately, such as interchanges and service areas.
- This system makes no distinction between limited traffic control and total control (blockage). It may show an indirect route even if the road is usable.
- Even if the ferry preference is set to OFF, a route that uses a ferry line may be suggested.

## ROUTE GUIDANCE

**INFO:**

The system will announce street names when the system language is set to English. Depending on the language setting, street names may not be announced.

### Repeating voice guidance

This function is available throughout route guidance, from the time after the route calculation is completed until the vehicle arrives at the destination. Push and hold **<MAP>**. Voice guidance will be repeated.

### Notes on voice guidance

- Voice guidance in this system should be regarded as a supplementary function. When driving the vehicle, check the route on the map and follow the actual roads and traffic regulations.
- Voice guidance is activated only for intersections with certain conditions. There may be cases where the vehicle has to turn, but voice guidance is not provided.
- Voice guidance contents may vary, depending on the direction of the turn and the type of intersection.
- The voice guidance timing will vary depending on the situation.
- When the vehicle has deviated from the suggested route, voice guidance is not available. The system will not announce this. Refer to the map and recalculate the route.

  "Recalculating route" (page 128)
- Voice guidance may not accurately correspond with road numbers and directions at motorway junctions.
- The displayed street names may sometimes differ from the actual names.
- Voice guidance is not available when [Guidance Voice] is turned off.
- Voice guidance will start when the vehicle enters the suggested route. Refer to the map for directions to the starting point of the route.
- When approaching a waypoint, the voice guidance will announce and inform the driver that the vehicle has reached a waypoint. Voice guidance will switch to the next section of the route. When voice guidance is not available, refer to the map for directions.
- In some cases, voice guidance ends before arrival at the destination. Refer to the destination icon on the map to reach the destination.
- Voice guidance may be partially operational or inoperative due to the angle of roads at an intersection.
- Motorway exit information may differ from the information on the actual exit signs.
- Because it is not possible to consider data concerning roads that are seasonally available or unavailable, a route may be displayed that does not match the actual traffic restrictions. Be sure to follow the actual traffic restrictions while driving.

## HOW TO UPDATE MAP DATA (where fitted)

**⚠ WARNING**

**TO AVOID RISK OF DEATH OR SERIOUS PERSONAL INJURY WHEN UPDATING THE MAP SOFTWARE:**

**If you choose to park the vehicle within range of a Wi-Fi connection (where fitted) or a TCU (Telematics Control Unit) (where fitted), park the vehicle in a secure, safe, well-ventilated location that is open to the air. During the update process, if you choose to park your vehicle, it should be kept in a well ventilated area to avoid exposure to carbon monoxide. Do not breathe exhaust gases; they contain colourless and odourless carbon monoxide. Carbon monoxide is dangerous. It can cause unconsciousness or death.**

1. **Apply the parking brake.**
2. **Remain with the vehicle while the update is in process.**
3. **Do not allow children, pets or people who may need assistance to remain in the vehicle while the software is updating.**

**NOTE:**

**The vehicle is not required to be parked during the map update process.**

Map data can be updated via USB (where fitted), Wi-Fi (where fitted) or a TCU (Telematics Control Unit) (where fitted). Depending on the model, the map data cannot be updated via TCU (Telematics Control Unit).

### UPDATING WITH USB MEMORY (where fitted)

The navigation map data can be updated with the latest information by downloading a new map database to a USB memory device and installing it in the vehicle.

For detailed instructions of the Map USB update procedure please contact your dealer, Nissan Customer Services or download the Nissan Driver's Guide mobile application from the iTunes App Store or Google Play.

### UPDATING USING WIRELESS LAN (WI-FI) (where fitted)

The map data can be updated using the vehicle Wi-Fi connection. Wi-Fi communications can be made by using a Wi-Fi network, smartphone, etc.

☞ "Wi-Fi Setting (where fitted)" (page 32)

1. Connect the vehicle to an available Wi-Fi network.
2. Push **<MENU>**.
3. Touch [Info] on the Launch Bar and then touch [System Information].
4. Touch [Map Update].
5. Touch [Update via Wi-Fi]/[Update by Wi-Fi]. A confirmation message is displayed.
6. **Type A**

   Select the area to be updated, and Touch [Start].

   **Type B**

   Touch [Select Area], select the area to be updated, and touch [OK]. Touch [Yes] to update the selected area.
7. Touch [OK] after completing the update.

**INFO:**

- When [Cancel] is displayed during the map data update, touching the key can cancel the update.
- The navigation system cannot be operated while the map updates.
- Do not turn off the power source of the smartphone while updating.
- Map data should be updated while the engine or e-POWER system is running to prevent discharge of the vehicle battery (12V battery).
- Touch [Vehicle Hotspot]/[Car Hotspot] (where fitted) and turn on the indicator to activate the Wi-Fi hotspot communication.
- The download data size of map update for one country or one regional zone can vary between 100 MB to 1 GB. Data size in case of updating multiple countries or regional zones can be over 1 GB. Use of Wi-Fi hotspot functionality of your smartphone for map updates may incur additional data charges from your network provider. Please connect to your home Wi-Fi network to avoid additional phone data charges.

- Depending on the models, specifications and software versions, the same operation can be performed from [System Update] on the setting menu screen.

  ☞ "System settings" (page 28)

- Depending on the models, specifications and software versions, the update is done in the background, and the updates are reflected in the map data the next time the system is started.
- When the vehicle power is shutdown, the map update is suspended. When the map update is resumed, select the same region to update the map from [Update via Wi-Fi].

## AUTOMATIC MAP UPDATE (where fitted)

The map data can be updated using the TCU (Telematics Control Unit).

1. Push **<MENU>**.
2. Touch [Info] on the Launch Bar and then touch [System Information].
3. Touch [Map Update].
4. Touch [Map Update Settings].
5. Select an area of the map you wish to update. A confirmation message is displayed. The next time you start the system, a notification message will be displayed if map data update is available.
6. When the new map data is available after the vehicle power is on, a pop-up message informing that a map update is available will appear. Touch [YES] to update the map data.

**INFO:**

If the user selects [No] on the pop-up screen, the automatic map update and software update will not be available forever, and the user always has to update the map and software manually from the next time.
When the vehicle power is shutdown, the map update is suspended. When the map update is resumed, select the same region to update the map from [Update via Wi-Fi].

7. Touch [OK] after completing the update.

**INFO:**

- The same operation can be performed by touching [Settings] on the Launch Bar and then touching [System Update].
- The update is done in the background, and the updates are reflected in the map data the next time the system is started.

## Automotive products End User License Provisions

This End-User License Agreement ("**EULA**") is an agreement between you and TomTom International B.V. ("**TomTom**"). You agree that this EULA is enforceable. This EULA applies to your use of the TomTom Map data, software, Traffic and Travel services or any other TomTom products (together with the "**Services**").

Please read this EULA carefully. By using the Services you agree to all the terms and conditions of this EULA.

1. GRANT OF LICENSE: In consideration of you agreeing to abide by the terms of this EULA, TomTom hereby grants to you a non-exclusive, license to use the Services solely in connection with the vehicle. If upgrades, updates or supplements to the Services are provided the use of such upgrades or updates is governed by this EULA.
2. RESTRICTIONS: You are prohibited from renting, lending, public presentation, performance or broadcasting or any other kind of distribution of the Services. Other than as permitted by applicable legislation, you will not, and you will not allow any person to, copy or modify the Services or any part thereof or to reverse engineer, decompile or disassemble the Services.

3. OWNERSHIP. Copyright and other intellectual, industrial and/or proprietary rights to the Services are owned by TomTom and/or its suppliers. TomTom permits you to use the Services only in accordance with the terms of this EULA. All rights not specifically granted in this EULA are reserved by TomTom. To the extent applicable, you acknowledge that you have no right to have access to the Services in source code or in unlocked coding.
4. THIRD PARTY SOFTWARE LICENSES: The Services may make use of third party software. Notwithstanding Clauses 2 and 3, use of some third party materials included in the Software may be subject to other terms and conditions. The official copyright notices and specific license conditions of these third party software codes and algorithms are to be found via http://www.tomtom.com. You hereby agree to the terms and conditions for such third party software.
5. LIMITED WARRANTY:
   - YOU ACKNOWLEDGE THAT THE SERVICES HAVE NOT BEEN DEVELOPED TO MEET YOUR INDIVIDUAL REQUIREMENTS AND THAT IT IS THEREFORE YOUR RESPONSIBILITY TO ENSURE THAT THE FACILITIES AND FUNCTIONS OF THE SERVICES MEET YOUR REQUIREMENTS. TOMTOM DOES NOT AND CANNOT WARRANT THAT THE SERVICES OPERATE UNINTERRUPTED OR ERROR-FREE. YOU SHOULD BE PARTICULARLY AWARE OF THE FACT THAT CALCULATION ERRORS MAY OCCUR WHEN USING SOFTWARE IN A NAVIGATION SYSTEM FOR INSTANCE CAUSED BY LOCAL ENVIRONMENTAL CONDITIONS AND/OR INCOMPLETE DATA.
   - TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, TOMTOM AND ITS SUPPLIERS PROVIDE THE SERVICES "AS IS", AND HEREBY DISCLAIM ALL OTHER WARRANTIES AND CONDITIONS, WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, ANY (IF ANY) IMPLIED WARRANTIES, DUTIES OR CONDITIONS OF SATISFACTORY QUALITY, OF FITNESS FOR A PARTICULAR PURPOSE, OF RELIABILITY OR AVAILABILITY, OF ACCURACY OR COMPLETENESS OF RESPONSES, OF RESULTS, WITH REGARD TO THE SERVICES, AND THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT OR OTHER SERVICES, INFORMATION, SOFTWARE, AND RELATED CONTENT THROUGH THE SERVICES OR OTHERWISE ARISING OUT OF THE USE OF THE SERVICES.

     **SAFETY: THE SERVICES ARE INTENDED TO BE USED FOR PROVIDING INFORMATION AND NAVIGATION SERVICES RELATED TO YOUR JOURNEY ONLY AND ARE NOT INTENDED TO BE USED AS A SAFETY RELATED TOOL AND CANNOT WARN YOU ABOUT ALL DANGERS AND HAZARDS WITH RESPECT TO THE ROAD YOU ARE DRIVING. THEREFORE, IT REMAINS YOUR DUTY TO DRIVE IN A CAREFUL AND SAFE MANNER (PAYING ALL DUE CARE AND ATTENTION TO THE ROAD) AS WELL AS OBSERVING ALL APPLICABLE TRAFFIC REGULATIONS AND RULES. IT IS YOUR RESPONSIBILITY NOT TO USE THE SERVICES IN A MANNER THAT WOULD DISTRACT YOU FROM DRIVING SAFELY.**
6. LIMITATION OF LIABILITY:

   TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, NEITHER TOMTOM NOR ITS LICENSORS AND SUPPLIERS, OFFICERS, DIRECTORS OR EMPLOYEES SHALL BE LIABLE TO YOU OR TO ANY THIRD PARTY FOR ANY DAMAGES, WHETHER DIRECT, SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL (INCLUDING BUT NOT LIMITED TO, DAMAGES FOR THE INABILITY TO USE OR ACCESS THE SERVICES, LOSS OF DATA, LOSS OF BUSINESS, LOSS OF PROFITS, BUSINESS INTERRUPTION OR THE LIKE) ARISING OUT OF OR RELATED TO THE USE OF, THE INABILITY TO USE OR ACCESS, OR OTHERWISE THE PERFORMANCE OF THE SERVICES, EVEN IF NISSAN HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

   TO THE EXTENT TOMTOM IS NOT PERMITTED UNDER APPLICABLE LAW TO EXCLUDE ITS LIABILITY PURSUANT TO CLAUSE 6.1 ABOVE, TOMTOM'S TOTAL AGGREGATE LIABILITY TO YOU SHALL BE LIMITED TO THE AMOUNT OF US $100.00.

   THE ABOVE LIMITATIONS OF LIABILITY UNDER THIS CLAUSE 6 DO NOT: (I) AFFECT YOUR RIGHTS UNDER ANY APPLICABLE MANDATORY NATIONAL LEGISLATION; (II) EXCLUDE OR LIMIT ANY LIABILITY THAT CANNOT BE EXCLUDED OR LIMITED UNDER APPLICABLE LAW.

7. TERMINATION: Without prejudice to any other rights, TomTom may immediately terminate this EULA if you fail to comply with any of its terms and conditions. The provisions of this Agreement, which by their nature are intended to survive termination, will remain in effect after termination of this EULA.

8. LINKS TO THIRD PARTY SITES: TomTom and other third parties involved in making the Services available to you ("Third Parties") are not responsible for the contents of any third-party sites or services, any links contained in third-party sites or services, or any changes or updates to third-party sites or services which are delivered by the Services or otherwise. TomTom (and, as applicable, each of the Third Parties) is providing these links and access to third-party sites and services to you only as a convenience, and the inclusion of any link or access does not imply an endorsement by TomTom or any Third Parties of the third-party site or service. Any use by you of such links or third party sites and the manner in which you use such third party sites and links shall be your responsibility and at your risk and you shall not use them in any illegal or fraudulent manner.

   Should you have any questions concerning this EULA, or if you desire to contact TomTom for any reason, please visit TomTom's website below: http://www.tomtom.com.

MEMO

# 7 Voice recognition (where fitted)


Voice recognition (where fitted) ..... 156
Using Voice Recognition System ..... 156
Before starting ..... 156
Giving voice commands ..... 156
System Voice settings ..... 159

## USING VOICE RECOGNITION SYSTEM

### Initialisation

When the ignition switch or power switch is in the ACC or ON position, voice recognition is initialised. When the initialisation is complete, the system is ready to accept voice commands. If **<** **>** (where fitted) on the steering wheel or **<** **>** (where fitted) on the steering column is operated before the initialisation completes, the display will show a message to wait until the system is ready.

**INFO:**

Depending on the countries, the voice recognition function is not available and **<** **>** (where fitted) may not function.


## BEFORE STARTING

To get the best recognition performance from voice recognition, observe the following items.

- The interior of the vehicle should be as quiet as possible. Close the windows to eliminate the surrounding noises (traffic noise, vibration sounds, etc.) and turn down the fan speed level of the heater/air conditioner to lower the noise which may prevent the system from correctly recognising the voice commands.
- Wait until the tone sounds before speaking a command.
- Speak in a natural conversational voice without pausing between words.
- The system cannot recognise voice commands spoken from passenger seats.

## GIVING VOICE COMMANDS

1. Push **<** **>** (where fitted) on the steering wheel or push and hold **<** **>** (where fitted) on the steering column.




5GE0063XZ

**Example**

2. A list of commands appears on the screen, and the system provides the voice menu prompt.

   Available category commands are displayed on the left side of the screen. Speak or touch a category command from the category command list.

**INFO:**

- Some of the commands for each category are shown on the right side of the screen and they can also be spoken without selecting a category.
- After executing the category command, only the commands related to the selected category can be recognised.

3. After the tone sounds and the icon on the screen changes from to , speak a command. You can also select a command by directly touching the screen, using **<** **>/<** **>/<** **/** **>** (where fitted) on the steering wheel or using
   **<TUNE • SCROLL/SOUND>/**
   **/<TUNE • SCROLL/ENTER SOUND>/**
   **/<TUNE • SCROLL/PUSH SOUND>/**
   **/<TUNE • SCROLL/ENTER SETTING>/**
   **/<TUNE • SCROLL/OK>/**
   **/<** **/ENTER SOUND>/**
   **/<** **/SOUND>/**
   **/<** **/OK>** (where fitted) on the control panel or using the Display Commander (where fitted).

**INFO:**

The Voice Recognition System will pause its operation when no command is given after a few prompts. To resume the operation, push **<** **>** (where fitted) on the steering wheel or push and hold **<** **>** (where fitted) on the steering column.

4. Continue to follow the voice menu prompts and speak the voice commands after the tone sounds until the preferred operation is executed.

**INFO:**

- To exit the Voice Recognition System, push and hold **<** **>** (where fitted)**/<** **>** (where fitted) on the steering wheel.
- Depending on the language setting, the Voice Recognition System cannot be used.

## Operating tips

- Speak a command after the tone.
- If the command is not recognised, the system will prompt you to speak the command again. Repeat the command in a clear voice.
- Touch [ ] on the touch screen display or push **<** **>** (where fitted) on the steering wheel to return to the previous screen.
- To adjust the volume of the system feedback, push **<** **>** (where fitted) on the steering wheel, push **<** **>** (where fitted) on the steering column from behind or turn
  **<VOL/** **>/**
  **<VOLUME/** **>/**
  **<VOL/PUSH** **>/**
  **<VOL/PUSH POWER>** while the system is making an announcement.

**Voice Prompt Interrupt:**

In most cases, you can interrupt the voice feedback to speak the next command by pushing **<** **>** (where fitted) on the steering wheel or pushing and holding **<** **>** (where fitted) on the steering column. After interrupting the system, wait for a tone before speaking your command.


**One Shot Call (where fitted):**

To use the system faster when making a call, you may speak the second level command skipping speaking the first level command. For example, push **<** **>** (where fitted) on the steering wheel or push and hold **<** **>** (where fitted) on the steering column and say "Redial" after the tone without first saying "Phone".

## How to see voice command screen

1. Push **<** **>** (where fitted) on the steering wheel or push and hold **<** **>** (where fitted) on the steering column to display the first screen of the voice command list.
2. Speak a command or select an item on the voice command list. The second screen is displayed.
3. Speak a command or select an item on the voice command list. The command is executed or the next screen for further command is displayed.
4. Follow the prompts to complete the commands.

**Voice command screens:**




**Example**

① Shows a list of available categories. Speak a category command or touch the key of the corresponding category.


② Touch [Settings] or say "Settings" to display the system voice settings.

③ Shows a list of available commands for the selected category. Speak a preferred command.

④ Touch [Help] or say "Help" to hear help announcements on how to use the system.

**INFO:**

Push **<** **>** (where fitted) on the steering wheel or push and hold **<** **>** (where fitted) on the steering column to stop the help announcements.




5GE0072XZ

**Example**


⑤ Previously selected command

⑥ Command list

You can speak a command from the list or touch the corresponding key. Preferred words can be spoken for the part of the command enclosed in < >.

⑦ [Previous], [Next]

Say as a command or touch to go to the previous/next screen.




5GE0064XZ

⑧ Speak a number from 1 to 5 or touch an item on the list screen to select the item.

## How to speak numbers

The Voice Recognition System requires the user to speak numbers in a certain way when giving voice commands.

**General rule:**

Only single digits “0” (zero) to “9” can be used. (For example, for the number “600”, speaking “six zero zero” can be recognised by the system, but “six hundred” cannot be recognised.)

**INFO:**

For the best recognition, speak “zero” for the number “0”, and “oh” for the letter “o”.

## SYSTEM VOICE SETTINGS

The system voice settings can be changed.

1. Touch [System Voice] on the setting menu screen.

   ☞ "System settings" (page 28)

2. Touch the item you would like to set.

Available setting items may vary depending on models, specifications and software versions.

| **Available item** | | **Action** |
|---|---|---|
| [Initial Voice Prompt] | | When this item is turned on, voice prompts are announced. |
| [Short Voice Prompts] | | When this item is turned on, short and minimised voice feedback will be provided. |
| [Best Match Lists] | [Phonebook] | When these items are turned on, the voice recognition results are displayed on the list in the order of reliable recognition. |
| | [Music Commands] | |
| [Voice Preference] | | Guidance voice setting can be selected from a male or female voice.<br>Depending on the language setting, the guidance voice setting cannot be changed. |
| [Speech Rate] | | Adjusts the speech rate of prompt. |
| [Audio Device Setting | | Select an audio device to be operated via the Voice Recognition System from the audio devices connected to the USB connection ports. A device with an indicator light illuminated can be operated with the Voice Recognition System. |

MEMO

# 8 Troubleshooting guide


System unit ..... 162
Liquid crystal display ..... 162
Wi-Fi Connection (where fitted) ..... 163
Wi-Fi Hotspot (where fitted) ..... 163
Audio system ..... 164
AM radio ..... 164
DAB radio (where fitted) ..... 164
HD Radio technology (where fitted) ..... 166
Compact Disc (CD) player (where fitted) ..... 168
Digital versatile disc (DVD) player (where fitted) ..... 170
iPod player ..... 172
USB memory device ..... 173
Bluetooth® audio ..... 174
Bluetooth® Hands-Free Phone System ..... 176
NissanConnect Services (where fitted) ..... 179
Apple CarPlay (where fitted) ..... 180
Android Auto (where fitted) ..... 181
Yandex.Auto (where fitted) ..... 182
Siri Eyes Free (where fitted) ..... 183
Navigation (where fitted) ..... 184
Basic operations ..... 184
Map screen ..... 184
Route calculation and visual guidance ..... 186
Voice guidance ..... 188
Traffic information (where fitted) ..... 189
Voice recognition (where fitted) ..... 190

## LIQUID CRYSTAL DISPLAY

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The screen is too dark. | The cabin temperature is too low. | Wait until the cabin temperature becomes moderate. |
| | Screen brightness is set to the maximum darkness. | Adjust the brightness setting of the screen. |
| The screen is too bright. | Screen brightness is set to the maximum brightness. | Adjust the brightness setting of the screen. |
| A small black spot or a small bright spot appears on the screen. | This is a typical phenomenon for liquid crystal displays. | This is not a malfunction. |
| A dot or stripe pattern appears on the screen. | Electromagnetic waves that are generated from neon billboards, high voltage electric power cables, ham radios or other radio devices equipped to other vehicles may adversely affect the screen. | This is not a malfunction. |
| Image lag appears on the screen. | This is a typical phenomenon for liquid crystal displays. | This is not a malfunction. |
| Image motion displayed on the screen is slow. | The cabin temperature is less than 10°C (50°F). | Wait until the cabin temperature rises to within 10°C (50°F) and 50°C (122°F). |
| When looking at the screen from an angle, the screen lightens or darkens. | This is a typical phenomenon for liquid crystal displays. | Adjust the brightness setting of the screen. |
| The screen turns blue or an error message is displayed on the touch screen display. | A system malfunction has occurred. | It is recommended that you contact a NISSAN dealer or qualified workshop for an inspection. |

## WI-FI CONNECTION (where fitted)

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The name of the device which you wish to connect is not displayed on the Connections screen. | The device is turned off. | Check that the device is turned on. |
| | The device does not support a WPA2 security network. | Check that the security network is supported by the device. |
| The in-vehicle system cannot connect to the Wi-Fi network. | The device is turned off. | Check that the device is turned on. |
| | The network password is incorrect. | Check that the network password is correct. |
| | | Check the entered password is correct. |

## WI-FI HOTSPOT (where fitted)

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The device cannot connect to the vehicle Wi-Fi hotspot. | 7 devices already connected. | Delete a connected device. |
| | The password is incorrect. | Check that the network password is correct. |
| | | Check the entered password is correct. |
| The device cannot access the Internet. | The service provider's subscription is not active. | Check the service provider's subscription. |
| | The vehicle is out of the service area of the provider. | Move to a service supported area. |
| Slow connectivity to the network. | Another wireless connection interferes. | Turn off the other wireless devices. |

## AM RADIO

| Symptom | Possible cause | Possible solution |
|---|---|---|
| AM reception deteriorates at night. | AM stations are required to lower their power at night. | This is not a malfunction. |

## DAB RADIO (where fitted)

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The sound skips, stutters or echoes. | The radio station has not properly aligned digital and analogue audio. | Verify correct operation on another station. Report the station with poor performance. |
| The volume level is unstable. | Level alignment is inappropriate. | Verify correct operation on another station and check the station availability in the area. Report the station with poor alignment. |
| The sound fades in/out. | Excessive switching between DAB and FM. | Verify transition performance on several stations in the area. Report stations with poor alignment. |
| Excessive switching between DAB and FM. | The vehicle is located near the edge of the DAB coverage area. | Verify the radio station coverage in your area. |
| The sound quality of DAB is no better than that of FM/AM. | Audio processing on the digital audio by the station can potentially decrease digital audio sound quality. | Verify correct operation on another station. Report the station with poor performance. |
| Local stations keep being lost. | Digital coverage is slightly smaller than analogue signal coverage. | Verify correct operation on another station. |
| | Shadowing (Urban/Terrain) can cause reduced digital coverage. | Verify correct operation on another station. |
| Some data fields are blank. | Text information is sent at the broadcaster's discretion. | Verify correct operation on another station. Report the station issue. |
| Text information is truncated. | The display is limited to a fixed number of characters and more data is being sent than can be displayed. | This is not a malfunction. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The DAB-FM setting is turned on but an alternative station does not play and the signal does not appear on the display. | The tuner is waiting for the original signal to recover and is seeking an available alternative signal. | Wait for the signal to return or for the tuner to pick up an alternative signal. |
| A message indicating that service is not available is displayed on the screen. | The selected service or ensemble is not in service. | Select a different service or ensemble. |

**INFO:**

- When station presetting is performed while a secondary service is playing, the parent primary service will be registered.
- Secondary services do not appear on the station list.

## HD RADIO TECHNOLOGY (where fitted)

### Sound

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Delay in digital audio on HD Radio broadcasts. | The radio acquires an analogue station first and blends to a digital signal. | This is not a malfunction. |
| Audio skips, stutters, or echoes. | The radio station has not properly aligned the digital and analogue audio. | Verify correct operation on another station. Report any station with poor performance. |
| Volume changing up/down. | The radio station has not properly aligned digital and analogue audio level. | Verify correct operation on another station and check www.hdradio.com for stations in the area. Report any station with poor performance. |
| Sound fading in and out. | The transition between analogue and digital is taking place (blending). | Verify transition performance on several stations in the area. Report any stations with poor alignment. |
| Excessive blending (transition between analogue and digital). | The vehicle is located near the edge of the digital coverage area. | Refer to www.hdradio.com to verify radio stations in your coverage area. |
| Digital audio is no better than analogue audio. | Audio processing on the digital audio at a station can potentially decrease the digital audio sound quality. | Verify correct operation on another station. Report any station with poor performance. |

Functional

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Keep losing my local stations. | The digital coverage is slightly less than the analogue signal coverage. | Verify correct operation on another station. This is an expected behaviour. |
| | Shadowing (urban/terrain) can cause reduced digital coverage. | Verify correct operation on another station. This is an expected behaviour. |
| Some data fields are blank. | Text information is sent at the broadcaster's discretion. | Verify correct operation on another station. Report station issues. |
| Text information is truncated/there appears to be more available. | The display is limited to a fixed number of characters and more data is being sent than can be shown. | This is an intended behaviour. |
| AM reception changes at night. | AM stations are required to lower their power at night. | This is not a malfunction. |

## COMPACT DISC (CD) PLAYER (where fitted)

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Music cannot be played back. | The disc is inserted upside down. | Insert a CD with the label side facing up. |
| | Moisture condensation occurs inside the unit. | Wait until the moisture evaporates (approximately 1 hour). |
| | The cabin temperature is too high. | Wait until the cabin temperature becomes moderate. |
| | The disc is scratched or dirty. A disc is not always playable if it is scratched. | Wipe off any dirt from the disc. |
| | Depending on the condition in which they are stored, discs may become unreadable due to deterioration (for example, keeping the discs in the passenger compartment, etc.). | Change the disc with a deterioration-free disc. Do not use a deteriorated disc. The label surface of the disc may crack or chip, and the layer of the label surface may eventually peel off. |
| The compressed audio files cannot be played back. | If both music CD files (CD-DA data) and compressed audio files (MP3 data, etc.) are mixed on one disc, the audio compression files cannot be played back. | Prepare a disc that includes compressed audio files only. |
| | The files are not named using characters that are compliant with the specifications. | Use the character codes and the number of characters that are compliant with the specifications for folder names and file names. In addition, always use ".MP3", ".WMA", ".mp3" or ".wma" for file extensions. |
| It takes a long time before the music starts playing. | The disc contains a large amount of data. | Some time may be required to check the files. It is recommended that unnecessary folders or any files other than compressed audio files should not be recorded in a disc. |
| The sound quality is poor. | The disc is dirty. | Wipe off any dirt from the disc. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| No sounds are played though the CD play time is displayed. | The system plays back the first track of the mix mode disc. (Mix mode is a format in which data except music is recorded on the first track and music data is recorded on one other than the first track in a session.) | Play back music data that is recorded on a track other than the first track. |
| Music cuts off or skips. | The combination of writing software and hardware might not match; or the writing speed, writing depth, writing width, etc. might not match the specifications. | Create a disc using different writing speed settings, etc. |
| The system skips the selected track and moves to the next track. | A non-MP3/WMA file is given an extension of ".MP3", ".WMA", ".mp3" or ".wma". | Prepare MP3/WMA files. |
| | The system plays back a file that is prohibited due to copyright protection. | Prepare playable files. |
| The tracks do not play back in the desired order. | The folder locations in the disc are changed by the writing software while the files are written in the disc. | Check the settings of the writing software, and create a new disc. |
| The CD cannot be ejected. | The ignition switch or power switch is not placed in the ACC or ON position. | Place the ignition switch or power switch in the ACC or ON position. |

## DIGITAL VERSATILE DISC (DVD) PLAYER (where fitted)

| Symptom | Possible cause | Possible solution |
|---|---|---|
| No image is displayed. | The vehicle is being driven. | Stop the vehicle in a safe location and apply the parking brake. |
| The system does not behave as operated. | Due to the intentions of the disc maker, there are some DVDs that do not behave as operated. | This is not a malfunction. |
| A DVD does not respond to operation. | The operation performed is not allowed. (A message may not be displayed depending on the disc.) | Wait until an operable screen is displayed. |
| The sound cannot be heard. | The volume level is set to the minimum. | Adjust the volume level of the audio. |
| Playback does not start. | The disc is inserted upside down. | Insert a disc with the label side facing up. |
| | The volume level is set to the minimum. | Check the volume level of the audio. |
| | Moisture condensation occurs inside the unit. | Wait until the moisture evaporates (approximately one hour). |
| | The DVD menu is displayed. | Select the menu item. |
| | A disc with a different region code has been inserted. | Discs with different region codes cannot be played back. Check the disc. |
| | Depending on the DVD, and because the standards of the DVD may not be strictly satisfied, this device may not be able to play back some discs. | This is not a malfunction. |
| Playback skips and the image is distorted. | The disc is scratched. | Depending on the size of the scratch, it may not be possible to correct the error. |
| | The disc is dirty. | Wipe off any dirt or foreign material on the disc. |
| The subtitles are not displayed. | The subtitle display setting is turned off. | Select [Subtitle]/[Subtitles] from the DVD menu screen and set it to on. |
| | The DVD being played back does not have any subtitles recorded on it. | Check the disc. |
| The audio does not play back in the set audio language. | If the set audio language is not recorded in the disc, the audio will play back in the disc's recommended language. | Check the disc. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The subtitles do not play back the set subtitle language. | If the set subtitle language is not recorded in the disc, the subtitles will play back in the disc's recommended language. | Check the disc. |
| The angle cannot be changed. | The software being played back does not have multiple-angle information recorded on it. | Check whether the inserted disc supports multiple angles. |
| The screen display is not normal. | A suitable display mode cannot be selected for the aspect ratio of the DVD. | Change the display mode. |
| The image is distorted. | The image is being fast-forwarded or rewound. | This is not a malfunction. |
| The sound quality is poor. | The disc is dirty. | Wipe off any dirt or foreign material on the disc. |
| The subtitle language and audio language cannot be switched. (The languages for the subtitles and the audio do not switch to the language set in the system.) | The disc being played back does not have subtitles or audio for multiple languages recorded on it. | The number of subtitle and audio languages recorded varies depending on the disc. In addition, there are some discs for which this can be switched in the menu screen. Check the disc. |
| | There are default priority language and default priority settings for the disc. | If there are default priority language and default priority settings for the disc, changes set with this device will not be applied. |
| The menu of the VIDEO CD cannot be used. | The VIDEO CD does not have a playback control feature. | Menu playback is not possible for VIDEO CDs other than those with a playback control feature. Check the disc. |
| The disc playback time is displayed but there is no sound. | The first track of a mixed mode disc (a disc format in which data other than music is recorded in the first track, and music is recorded in the second and subsequent tracks) was played back. | Playback the music data in the second and subsequent tracks. |

## iPod PLAYER

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The system does not recognise an iPod. | A connector cable is not correctly connected, or the iPod does not correctly operate. | Connect the connector cable again. If the system does not recognise the iPod after performing this procedure above, reset the iPod. |
| | The iPod that is to be connected is not compatible with the system. | Check the iPod model and firmware versions available for the system. |
| | The connected USB extension cable is not compatible with the system. | Replace the USB extension cable if the system still does not recognise the iPod after reconnecting the cable properly a number of times. |
| | The cable is rapidly connected to or disconnected from the USB connection port. | Slowly connect or disconnect the USB cable. |
| An iPod cannot be operated. | The iPod is connected to the in-vehicle audio system while headsets, etc. are connected to the iPod. | Remove all equipment from the iPod after disconnecting the iPod from the system, and then connect it to the system again. |
| | The iPod is not operating normally. | Disconnect the iPod from the in-vehicle audio system, and then connect it to the system again. |
| | The system plays back an album/file that includes a particular album art (where fitted). | Disconnect the iPod from the in-vehicle audio system, and then reset the iPod. Disable the album art (where fitted), and then connect the iPod to the system. |
| An iPod does not respond. | There are too many files in a category. | Decrease the number of files in a category (less than 65500 files). |
| | The shuffle function is turned on. | Turn off the shuffle function if many files are stored on the iPod. |
| Music cannot be played back. | A connector is not connected to the iPod. | Firmly connect the connector to the iPod. |
| Playback cuts out. | The sound cuts due to vibration resulting from an unstable location of the iPod. | Place the iPod on a stable location where it does not roll over. |
| Battery charge of an iPod takes longer. | Battery charge of the iPod may take longer while an iPod is playing back. | If the iPod needs to be charged, it is recommended to stop playing the music. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Battery charge of an iPod is unavailable. | The cable that is connected to the iPod may be damaged or improperly connected. | Check the cable currently in use. |
| Functions cannot be operated using an iPod that is connected to the in-vehicle audio system. | - | The operation of an iPod must be performed using the in-vehicle audio system after the iPod is connected to the system. |
| Sound skips. | Surrounding circumstances (noise, etc.) may cause the sound to skip. | This does not indicate a malfunction. |
| | A USB extension cable is used. | Do not use a USB extension cable. |

## USB MEMORY DEVICE

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The system does not recognise a USB device. | A USB extension cable is used. | Do not use a USB extension cable. |
| | A USB hub is used. | Do not use a USB hub. |
| | A USB device is rapidly connected to or disconnected from the USB connection port. | Slowly connect or disconnect the USB device. |

## BLUETOOTH® AUDIO

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Registration cannot be performed. | The Bluetooth® audio device is not compatible with the in-vehicle audio system. | Check the Bluetooth® audio device Owner's Manual. |
| | Bluetooth® is disabled on device. | Check that the Bluetooth® function is enabled on device. |
| | The PIN code is incorrect. | Check the PIN code for the Bluetooth® audio device that is to be registered. |
| | | Check that the PIN code for the Bluetooth® audio device is consistent with that for the in-vehicle audio system. |
| | Another Bluetooth® device is used in the vehicle. | Turn off the other Bluetooth® device until the registration is completed. |
| Music cannot be played back. | The Bluetooth® audio device is not compatible with the in-vehicle audio system. | Check the Bluetooth® audio device Owner's Manual. |
| | The system is not set to the Bluetooth® audio mode. | Push **<AUDIO>** and select the Bluetooth® audio mode. ☞ "Selecting the audio source" (page 47) |
| | A Bluetooth® adapter is turned off. | Turn on a Bluetooth® adapter when it is used for a Bluetooth® audio device. |
| Playback stops. | The Bluetooth® audio device is not compatible with the in-vehicle audio system. | Use a device compatible with the system. Ask a NISSAN dealer or qualified workshop for information regarding model compatibility. |
| | A mobile call is active. | This is not a malfunction. |
| | Sound may cut out when a Bluetooth® audio device is operated. | Push **<AUDIO>** and select the Bluetooth® audio mode, and then operate a function on the touch screen display of the in-vehicle system instead of conducting the operation on the Bluetooth® audio device. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Audio operation cannot be performed. | A Bluetooth® audio device that does not support audio operations is in use. | Use a device compatible with the system. Ask a NISSAN dealer or qualified workshop for information regarding model compatibility. |
| | An error occurs when connecting to a Bluetooth® audio profile. | Turn the power source of the Bluetooth® audio player off and on, and then resume connection with the system. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| A mobile phone cannot be registered. | The mobile phone is not compatible with the in-vehicle hands-free phone system. | Use a mobile phone compatible with the system. Ask a NISSAN dealer or qualified workshop for information regarding model compatibility. |
| | Registration of the mobile phone has been performed incorrectly. | Check the registration procedure, and then register the mobile phone again. |
| A mobile phone cannot be connected or is disconnected after the registration is completed. | The Bluetooth® setting of the in-vehicle hands-free phone system is turned off. | Turn on the Bluetooth® setting of the system. |
| | The Bluetooth® setting of the mobile phone is turned off. | Turn on the Bluetooth® setting of the mobile phone. |
| | The remaining battery level of the mobile phone is low. | Charge the battery of the mobile phone. |
| | The wireless Bluetooth® connection may be disrupted depending on the location of the mobile phone. | Do not place the mobile phone in an area surrounded by metal or far away from the in-vehicle hands-free phone system. Do not place the mobile phone close to the seats or your body. |
| | Registration of the mobile phone is not completed. | Perform registration of the mobile phone. |
| A call to a particular phone number fails. | If the system tries to make a call several times to the same phone number (for example: the party does not respond to the call, the party is out of the service area, or the call is abandoned before the party responds), the system may reject a request to make a call to the phone number. | Turn off the mobile phone and turn it on again to reset the connection. |
| The system does not recognise the connection of a mobile phone. The system does not receive or make a call. | The mobile phone is not compatible with the in-vehicle hands-free phone system. | Use a mobile phone compatible with the system. Ask a NISSAN dealer or qualified workshop for information regarding model compatibility. |
| | The mobile phone is not connected. | Check the registration procedure, and then register the mobile phone again. |
| | The phone operation is limited by the functions (such as dial lock, etc.) of the registered mobile phone. | Remove any settings that are limiting use of the mobile phone, and then perform registration again. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The other party cannot hear your voice.<br>The other party can hear your voice, but it cracks or cuts out. | Mute function is enabled. | Verify mute function is disabled. |
| | The mobile phone is not connected. | Check the registration procedure, and then register the mobile phone again. |
| | The fan speed of the heater/air conditioner is too fast. | Decrease the fan speed of the heater/air conditioner. |
| | The ambient noise level is excessive. (For example: heavy rain, construction sites, inside a tunnel, oncoming vehicles, etc.) | Close the windows to shut out ambient noise. |
| | The noise generated by driving the vehicle is too loud. | Reduce the vehicle speed. |
| | The incoming voice volume is too loud/soft. | Adjust the volume using **<VOL/ >/<VOLUME/ >/<VOL/PUSH >/ <VOL/PUSH POWER > or < >.** |
| | The outgoing voice volume is too loud/soft. | Adjust the volume from the volume adjustment screen. |
| The voice is cut out or noise is heard during a call. | The wireless Bluetooth® connection may be disrupted depending on the location of the mobile phone. | Do not place the mobile phone in an area surrounded by metal or far away from the in-vehicle hands-free phone system. Do not place a mobile phone close to the seats or your body. |
| When a mobile phone is operated to make a call, the hands-free function becomes unavailable. | Some models of a mobile phone do not switch to the hands-free mode when they are operated to make a call. | This is not a malfunction. Make another call using the hands-free function. |
| The other party's voice cannot be heard.<br>There is no ringtone. | The volume level is set to the minimum. | Adjust the volume level. |
| | A mobile phone is not connected. | Check the registration procedure, and then register the mobile phone again. |
| Each volume level (ringtone, incoming voice or outgoing voice) is different. | Each volume level is not adjusted properly. | Adjust each volume level properly. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The antenna display is different between the touch screen display and a mobile phone screen. Making or receiving a call is unavailable even though the antenna display shows that it is possible to do so. | The antenna display varies depending on the model of mobile phone. | This does not indicate a malfunction. The antenna display and remaining battery level shown on the touch screen display may be different from those shown on the mobile phone screen. Use them as a reference. |
| A voice cannot be heard clearly when using a mobile phone behind tall buildings. | Some structures such as tall buildings, etc. may cause irregular reflection of radio waves or completely shut out radio waves that are used for mobile phones. | Move to a place without tall buildings. |
| Noise is heard when using a mobile phone under/near areas of elevated railroads, high voltage electric power cables, traffic signals, neon billboards, etc. | Electromagnetic waves that are generated from radio devices may adversely affect the mobile phone. | This is not a malfunction. |
| Noise is heard in the sound from the audio system while using a mobile phone. | Radio waves that are generated from a mobile phone may adversely affect the sound from the audio system. | This is not a malfunction. |
| Sound skips or stutters. | The mobile phone may have turned on the wireless LAN (Wi-Fi). | Turn off the wireless LAN (Wi-Fi). |
| Phonebook cannot be downloaded. | An error occurred during the phone pairing process. | Please delete the Bluetooth® pairing information from both the mobile phone and vehicle system before registering it again. |
| | Phone does not support phonebook download function. | Use a mobile phone compatible with the system. Ask a NISSAN dealer or qualified workshop for information regarding model compatibility. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The system cannot connect to the NissanConnect Services Data Center. | A subscription for the NissanConnect Services has not been established. | Sign up for a subscription to the NissanConnect Services. For details about subscriptions visit the website, contact the support line or contact a NISSAN dealer.<br>☞ "NissanConnect Services (where fitted for Europe, Russia and Ukraine)" (page 85)<br>☞ "NissanConnect Services powered by SiriusXM™ (where fitted for Mexico)" (page 86) |
| | The communication line is busy. | Try again after a short period of time. |
| | The vehicle is in a location where it is difficult to receive radio waves. | When the vehicle moves to an area where radio waves can be transmitted sufficiently, communication will be restored. When the icon on the display shows that the vehicle is inside the communication area, the system can be used. |
| | TCU (Telematics Control Unit) is not turned on. | If the icon does not show that the vehicle is inside the communication area despite the fact that the vehicle is in that location visit the website, contact the support line or contact a NISSAN dealer.<br>☞ "NissanConnect Services (where fitted for Europe, Russia and Ukraine)" (page 85)<br>☞ "NissanConnect Services powered by SiriusXM™ (where fitted for Mexico)" (page 86) |
| | Radio wave reception is not sufficient for TCU (Telematics Control Unit) operation. | When the vehicle moves to an area where radio waves can be transmitted sufficiently, communication will be restored. When the icon on the display shows that the vehicle is inside the communication area, the system can be used. |
| Some of the items that are displayed on the menu screen cannot be selected. | The vehicle is being driven and some menu items are disabled. | Stop the vehicle in a safe location and apply the parking brake before operating the menu screen items. |
| Some parts of the screen are not displayed. | The vehicle is being driven and some menu items are disabled. | Operate the system after stopping the vehicle in a safe location and applying the parking brake. |
| The system does not announce information. | The volume level is set to the minimum. | Adjust the volume level by operating **<VOL>/ <VOLUME/ </<VOL/PUSH >/<VOL/PUSH POWER>** on the control panel or **<  >** on the steering wheel switch while the system is announcing information. |

| Symptom | Cause and Countermeasure |
|---|---|
| Cannot start Apple CarPlay though it is tethered to the vehicle. | The USB cable is not connected to the USB connection port. Properly connect the USB cable to the USB connection port.<br>☞ "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23) |
| | Models without Yandex.Auto: [Enable after USB Connection:] is set to [Never]. Change the setting to [Always] or [Ask].<br>☞ "Apple CarPlay settings" (page 98) |
| | Models with Yandex.Auto:<br>[Select Service] is set to [No service].<br>Change the setting to [Apple CarPlay].<br>☞ "Apple CarPlay settings" (page 98) |
| | Use an Apple Lightning cable (MFi certified) to connect your phone to the USB connection port and check that the cable is not broken. |
| | Apple CarPlay setting is not active on your iPhone. Turn on "CarPlay" on your iPhone. |
| | The device is not compatible with Apple CarPlay. Check the compatibility requirements. |
| Apple CarPlay performance decreases. For example, slow connectivity or slow application functionality.<br>or<br>An error message appears when trying to access features of Apple CarPlay. A blank screen appears when trying to access maps. | Confirm you have a compatible iPhone, a mobile connection and an active data plan. |
| | Use an Apple Lightning cable (MFi certified) to connect your phone to the USB connection port. |
| | Phone's performance or mobile connection. Disconnect and reconnect your phone. |
| | Phone's performance or mobile connection. Cycle phone power off/on to restart. |
| Cannot access Siri using **<** **>** (where fitted) on the steering wheel. | The USB cable may not be properly connected. Disconnect and reconnect the USB cable. |
| | Siri setting is not enabled on the phone. Turn on Siri on your phone. |
| | Models with Voice Recognition System:<br>Check that you are pushing and holding **<** **>** (where fitted) instead of just pushing the switch to initiate Siri operation. |
| | Depending on the countries, the voice operation function is not available and **<** **>** may not function. |

| Symptom | Cause and Countermeasure |
|---|---|
| Cannot start Android Auto though it is connected to the vehicle. | The USB cable is not connected to the USB connection port. Properly connect the USB cable to the USB connection port.<br>☞ "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23) |
| | Models without Yandex.Auto: [Enable after USB Connection:] is set to [Never]. Change the setting to [Always] or [Ask].<br>☞ "Android Auto settings" (page 102) |
| | Models with Yandex.Auto:<br>[Select Service] is set to [No service].<br>Change the setting to [Android Auto].<br>☞ "Android Auto settings" (page 102) |
| | To activate Android Auto, touch [ ] on the Launch Bar or touch [Apps]/[Smartphone Connection] on the information screen and then touch [Android Auto].<br>☞ "Selecting menu from Launch Bar" (page 24)<br>☞ "Information menu" (page 80) |
| | The connected device is not compatible with Android Auto. Check the compatibility requirements. |
| | Your Android phone may not be recognised if its battery is low. Charge your Android phone then try again. |
| Android Auto performance decreases. For example, slow connectivity or slow application functionality.<br>or<br>An error message appears when trying to access features of Android Auto. A blank screen appears when trying to access maps. | Confirm you have a compatible Android phone, a mobile connection and an active data plan. |
| | Use the Android phone OEM cable to connect your phone to the USB connection port. |
| | Phone's performance or mobile connection. Disconnect and reconnect your phone. |
| | Phone's performance or mobile connection. Close all apps and restart them. |
| | Phone's performance or mobile connection. Cycle phone power off/on to restart. |
| Cannot start voice operation using <> (where fitted) on the steering wheel. | The USB cable may not be properly connected. Disconnect and reconnect the USB cable. |
| | Voice operation cannot be performed while driving. Turn on appropriate settings on your Android phone. |
| | Models with Voice Recognition System:<br>Check that you are pushing and holding <> (where fitted) instead of just pushing the switch to initiate voice operation. |
| | Depending on the countries, the voice operation function is not available and <> may not function. |

| Symptom | Cause and Countermeasure |
|---|---|
| Cannot start Yandex.Auto though it is tethered to the vehicle. | The USB cable is not connected to the USB connection port. Properly connect the USB cable to the USB connection port.<br>☞ "USB (Universal Serial Bus) connection port and AUX (auxiliary) input jack (where fitted)" (page 23) |
| | [Select Service] is set to [No service].<br>Change the setting to [Yandex.Auto].<br>☞ "Yandex.Auto settings" (page 105) |
| | iPhone:<br>Use an Apple Lightning cable (MFi certified) to connect your phone to the USB connection port and check that the cable is not broken. |
| | The device is not compatible with Yandex.Auto. Check the compatibility requirements. |
| Yandex.Auto performance decreases. For example, slow connectivity or slow application functionality.<br>or<br>An error message appears when trying to access features of Yandex.Auto. A blank screen appears when trying to access maps. | Confirm you have a compatible smartphone, a cellular connection and an active data plan. |
| | iPhone:<br>Use an Apple Lightning cable (MFi certified) to connect your phone to the USB connection port. |
| | Phone's performance or cellular connection. Disconnect and reconnect your phone. |
| | Phone's performance or cellular connection. Cycle phone power off/on to restart. |
| Cannot access voice assistant "Alice" using **<**  **>** (where fitted) on the steering wheel. | The USB cable may not be properly connected. Disconnect and reconnect the USB cable. |
| | Siri setting is not enabled on the phone. Turn on voice assistant "Alice" on your phone. |
| | Models with Voice Recognition System:<br>Check that you are pushing and holding **<**  **>** (where fitted) instead of just pushing the switch to initiate voice assistant "Alice" operation. |

| Symptom | Cause and Countermeasure |
|---|---|
| Cannot access Siri Eyes Free using  (where fitted) on the steering wheel. | Check if a Bluetooth® connection is established between the iPhone and the system. |
| | Check if Siri is enabled on the device. On your phone, go to Siri setting. |
| | Check that Siri can be accessed from the device lock screen. This can be set in the settings menu of your phone. |
| | Depending on the countries, the voice operation is not available and  may not function. |
| Audio source does not change automatically to iPod or Bluetooth® Audio mode. | For best results, use the native music app. Performance of music control function while using Podcasts, Audiobook or other third party music apps may vary. |
| | For best results, play media already stored on your device. Streaming music or playback from cloud storage may degrade performance. |
| | Switch the source manually.<br>☞ "Selecting the audio source" (page 47) |
| Play, pause, next track, previous track or play timer does not work. | For best results, use the native music app. Performance of music control function while using Podcasts, Audiobook or other third party music apps may vary and is controlled by the device. |
| Cannot hear any music/audio being played back from a connected iPhone. | Check that the audio source is set to Bluetooth® Audio or iPod mode. A USB connection is required for iPod mode. |
| Models with navigation system:<br>Cannot hear map turn-by-turn direction guidance from a connected iPhone. | Check that the audio source is set to Bluetooth® Audio or iPod mode. A USB connection is required for iPod mode. |
| Cannot receive text message notifications on the vehicle audio system. | Check if notification setting is enabled on your phone. |
| Cannot reply to text message notifications using Siri Eyes Free. | After receiving an incoming text message, follow the on-screen guidance. Push and hold  (where fitted) on the steering wheel for Siri Eyes Free operation. After Siri Eyes Free starts, speak an appropriate command to reply to the message using Siri Eyes Free. |

## BASIC OPERATIONS

| Symptom | Possible cause | Possible solution |
|---|---|---|
| No image is displayed. | The brightness is at the lowest setting. | Adjust the brightness of the display. |
| | The display is turned off. | Push <> to turn on the display. |
| The volume of the voice guidance is too high or too low. | The volume is not set correctly, or the voice guidance setting is turned off. | Adjust the volume of the voice guidance or turn on the voice guidance setting. |
| No map is displayed on the screen. | A screen other than a map screen is displayed. | Touch [Map] on the Launch Bar or push **<MAP>**. |
| The screen is too dim. The movement is slow. | The temperature in the interior of the vehicle is low. | Wait until the interior of the vehicle has warmed up. |
| Some pixels in the display are darker or brighter than others. | This condition is an inherent characteristic of liquid crystal displays. | This is not a malfunction. |
| Some menu items cannot be selected. | Some menu items become unavailable while the vehicle is driven. | Park the vehicle in a safe location, and then operate the navigation system. |

## MAP SCREEN

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Names of roads and locations differ between 2D and 3D view. | This is because the quantity of the displayed information is reduced so that the screen does not become too cluttered. There is also a chance that names of the roads or locations may be displayed multiple times, and the names appearing on the screen may be different because of a processing procedure. | This is not a malfunction. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The location of the vehicle icon is misaligned from the actual position. | The vehicle was transported after the ignition switch or power switch was placed in the OFF position, for example, by a ferry or car transporter. | Drive the vehicle for a period of time on a road where Global Navigation Satellite System (GNSS) signals can be received. |
| | The position and direction of the vehicle icon may be incorrect depending on the driving environments and the levels of positioning accuracy of the navigation system. | This is not a malfunction. Drive the vehicle for a period of time to automatically correct the position and direction of the vehicle icon.<br>☞ "Current vehicle location" (page 144) |
| | Driving with tyre chains or tyres that have been replaced may result in an incorrect vehicle location display due to miscalculation by the speed sensor. | Drive the vehicle for a period of time (at approximately 30 km/h (19 MPH) for about 30 minutes) to automatically correct the vehicle icon position.<br>If this does not correct the vehicle icon position, it is recommended you contact a NISSAN dealer or qualified workshop. |
| | The map data has a mistake or is incomplete (the vehicle icon position is always misaligned in the same area). | Updated road information will be included in the next version of the map data.<br>☞ "How to update map data (where fitted)" (page 150) |
| When the vehicle is travelling on a new road, the vehicle icon is located on another road nearby. | Because the new road is not stored in the map data, the system automatically places the vehicle icon on the nearest road available. | Updated road information will be included in the next version of the map data.<br>☞ "How to update map data (where fitted)" (page 150) |
| The screen does not switch to the night screen even after turning on the headlights. | The daytime screen was set the last time the headlights were turned on. | Set the screen to the night screen mode using <☀/☽> when turning on the headlights. |
| The map does not scroll even when the vehicle is moving. | The current location map screen is not displayed. | Touch [Map] on the Launch Bar or push **<MAP>**. |
| The vehicle icon is not displayed. | The current location map screen is not displayed. | Touch [Map] on the Launch Bar or push **<MAP>**. |

## ROUTE CALCULATION AND VISUAL GUIDANCE

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Waypoints are not included in the auto reroute calculation. | Waypoints that have been already passed are not included in the auto reroute calculation. | To go to that waypoint again, edit the route. |
| Route information is not displayed. | Route calculation has not yet been performed. | Set the destination and perform route calculation. |
| | The vehicle is not on the suggested route. | Drive on the suggested route. |
| | Route guidance is turned off. | Turn on route guidance. |
| | Route information is not provided for certain types of roads. | This is not a malfunction. |
| The auto reroute calculation (or detour calculation) suggests the same route as the one previously suggested. | Route calculations took priority conditions into consideration, but the same route was calculated. | This is not a malfunction. |
| A waypoint cannot be added. | Twenty waypoints are already set on the route, including ones that the vehicle has already passed. | A maximum of 20 waypoints can be set on the route. To go to 21 or more waypoints, perform route calculations multiple times as necessary. |
| The suggested route is not displayed. | Roads near the destination cannot be calculated. | Reset the destination to a main or ordinary road, and recalculate the route. |
| | The starting point and destination are too close. | Set a more distant destination. |
| | The starting point and destination are too far away. | Divide the trip by selecting one or two intermediate destinations, and perform route calculations multiple times. |
| | There are time restricted roads (by the day of the week, by time) near the current vehicle location or destination. | Select [Do Not Use Restriction Info] in the [Time Restricted Roads] setting.<br>☞ "Route preference" (page 126) |
| A part of the route is not displayed. | The suggested route includes narrow streets. | This is not a malfunction. |
| The part of the route that the vehicle has already passed is deleted. | A route is managed by sections between waypoints. If the vehicle passed the first waypoint, the section between the starting point and the waypoint is deleted (it may not be deleted depending on the area). | This is not a malfunction. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| An indirect route is suggested. | If there are restrictions (such as one-way streets) on roads close to the starting point or destination, the system may suggest an indirect route. | Adjust the location of the starting point or destination. |
| | The system may suggest an indirect route because route calculation does not take into consideration some areas such as narrow streets. | Reset the destination to a main or ordinary road, and recalculate the route. |
| The landmark information does not correspond to the actual information. | This may be caused by insufficient or incorrect map data. | Please check you have the latest map data installed. ☞ "How to update map data (where fitted)" (page 150) |
| The suggested route does not exactly connect to the starting point, waypoints or destination. | There is no data for route calculation closer to these locations. | Set the starting point, waypoints and destination on a main road, and perform route calculation. |

## VOICE GUIDANCE

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Voice guidance is not available. | The vehicle has deviated from the suggested route. | Go back to the suggested route or request route calculation again. |
| | Voice guidance is turned off. | Turn on voice guidance. |
| | Route guidance is turned off. | Turn on route guidance. |
| The guidance content does not correspond to the actual road conditions. | The content of voice guidance may vary, depending on the types of intersections at which turns are made. | Follow all traffic rules and regulations. |

## TRAFFIC INFORMATION (where fitted)

| Symptom | Possible cause | Possible solution |
|---|---|---|
| Traffic information is not displayed. | The Premium Traffic setting is turned off. | Turn on the Premium Traffic setting.<br>☞ "Traffic information settings" (page 134) |
| | The vehicle is in an area where traffic information is not available. | Scroll to an area where traffic information is available. |
| | The map scale is set at a level where the icons cannot be displayed. | Check that the map scale is set at a level at which the icons can be displayed.<br>☞ "Traffic information on map" (page 133) |
| The suggested detour route does not avoid congested areas. | A faster route was not found, based on the road network and traffic information available. | The automatic detour search is not intended for avoiding traffic jams. It searches for the fastest route taking conditions such as traffic jams into consideration. Follow the suggested route.<br>☞ "Viewing traffic information (where fitted)" (page 132) |
| The route does not avoid a road section with traffic information stating that it is closed due to road construction. | The navigation system does not avoid roads under construction if the day and time of the actual roadwork differs from the one that was declared. | Observe the actual road conditions and follow the instructions on the road to make a detour when necessary. If the road is closed, use the detour function and set the detour distance to avoid the road section that is closed. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| The system does not operate or fails to interpret the command correctly. | The interior of the vehicle is too noisy. | Close the windows or have the other occupants be quiet. |
| | The fan speed of the heater/air conditioner is too fast. | Decrease the fan speed of the heater/air conditioner. |
| | The noise generated by driving the vehicle is too loud. | Reduce the vehicle speed. |
| | The voice command is spoken in a low voice. | Speak the command in a louder voice. |
| | The timing of speaking a command is too early. | Speak the command after confirming the following: a voice guidance is announced, a tone sounds, and an icon on the screen changes from grey to orange. |
| | The command is spoken too slowly. | Speak in a natural voice without pausing between words. |
| The system prompts to repeat a command. | Pronunciation is unclear. | Speak clearly. |
| | The command is spoken too late after the tone. | Speak the command within 5 seconds after confirming the following: a voice guidance is announced, a tone sounds, and an icon on the screen changes from grey to orange. |
| | An improper command is spoken. | Speak the command or a number that is displayed on the screen. |
| | | Speak a command that is shown in the command list. |
| The system does not correctly recognise a number spoken. | Too many numbers are spoken at once. | Place a pause between the appropriate digits for correct recognition by the system. When speaking a phone number, place a pause between area codes, dial codes, etc. |

| Symptom | Possible cause | Possible solution |
|---|---|---|
| USB memory device cannot be operated with voice commands. | Depending on the device, iPhone or iPod may be recognised as a USB memory device. | This is not malfunction. |
| | More than one audio device is connected to USB connection port (depending on the models). | Only one audio device can be operated with the Voice Recognition System even when multiple numbers of devices are connected. Select an audio source to operate with the Voice Recognition System. ☞ "System Voice settings" (page 159) |
| The USB/iPod operation screen is greyed out. | The audio device is not connected. | Connect an audio device to the system. |
| | An audio source to be operated with the Voice Recognition System has not been selected (depending on the models). | Select an audio source to be operated with the Voice Recognition System. ☞ "System Voice settings" (page 159) |
| An error message is displayed when trying to select a track and operate USB/iPod. | The track information is being processed for registration by the system. | Song information will be loaded into the system when a new audio device is registered for the first time or when the song information in the pre-registered device has been changed. Please wait for the loading to complete which may take a few minutes to up to an hour. |
| | A number of songs exceeding the amount the device can contain are stored in the connected audio device. | Decrease the number of songs stored in the audio device. |
| | No song is stored in the audio device. | Store songs in the connected audio device. Storing songs with information such as artist name, album name, song name, playlist, etc., will make voice recognition song search available. |
| The voice recognition function cannot be activated using **<** **>** (where fitted) on the steering wheel. | Depending on the countries, the voice operation function is not available and **<** **>** may not function. | This is not a malfunction |

MEMO

# 9 Index


**A**

Android Auto ... 100
- Compatibility ... 100
- Google Assistant ... 101
- Operation ... 101
- Settings ... 101, 102
- Troubleshooting ... 181

Apple CarPlay ... 95
- Compatibility ... 95
- Operation ... 95
- Settings ... 98
- Siri ... 96
- Troubleshooting ... 180

Audio system
- Auxiliary devices ... 61
- Bluetooth® ... 46
- Compact disc (CD) player ... 52
- Compact Disc (CD) player ... 37
- Compressed audio files (MP3/WMA/AAC) ... 42
- Digital Versatile Disc (DVD) player ... 38, 52
- iPod and Bluetooth® audio player ... 52
- Operation ... 46
- Precautions ... 36
- Radio ... 36, 48
- Settings ... 62
- Smartphone audio ... 61
- Troubleshooting ... 164
- USB (Universal Serial Bus) ... 41, 52

AUX (auxiliary) ... 23, 61

**B**

Bluetooth® ... 46, 66
- Calling ... 68, 69
- Connection ... 68
- Phone screen ... 67
- Texting ... 70
- Troubleshooting ... 174, 176

Buttons ... 14

**C**

Compact disc (CD) player ... 52
Compact Disc (CD) player ... 37
- Troubleshooting ... 168

Control panel ... 14
Current vehicle location ... 144
Customising ... 26

**D**

Destinations ... 121
- Setting ... 121

Digital Versatile Disc (DVD) player ... 38, 52
Disabled functions ... 26
Display ... 14
- Troubleshooting ... 162

**F**

Frequency approval numbers ... 6

**G**

GNSS ... 144

**H**

HD Radio technology
- Troubleshooting ... 166

Home menu ... 25

**I**

Information
- Menu ... 80
- Safety ... 108

iPod
- Troubleshooting ... 172

iPod and Bluetooth® audio player ... 52

**L**

Launch Bar ... 24, 108
Licences ... 11

**M**

Map
- 2D ... 110
- 3D ... 113
- Menu ... 121
- Moving ... 115
- Operation ... 109
- Road colour ... 115
- Scale ... 116
- Settings ... 118

- Traffic information ... 121
- Types ... 109

Map data ... 150

**N**

Navigation
- Screen ... 108
- Settings ... 143
- Troubleshooting ... 184

NissanConnect Services
- Troubleshooting ... 179

**O**

Operation ... 24

**P**

Phone
- Bluetooth® ... 66
- Calling ... 68, 69
- Connection ... 68
- Hands-Free Phone System ... 66
- Quick Dial ... 76
- Settings ... 74
- Texting ... 70

**Q**

Quick dial ... 76

**R**

Radio ... 36, 48
- Troubleshooting ... 164

Route calculation ... 148

Route guidance ... 124, 149
- Destination or waypoint ... 129
- Editing route ... 128
- Menu ... 124
- Recalculating route ... 128
- Route preference ... 126
- Settings ... 131
- Voice guidance ... 124

**S**

Safety information ... 4, 5, 108

Screen ... 14

Settings
- Audio system ... 62
- Connections ... 30
- Destinations ... 121
- Menu ... 28
- Navigation ... 143
- Phone ... 74
- Route guidance ... 131
- System ... 28
- Traffic information ... 134
- Voice Recognition ... 159
- Volume ... 76
- Wi-Fi ... 32

Shortcuts ... 26

Siri ... 106

Siri Eyes Free ... 106
- Troubleshooting ... 183

Smartphone audio ... 61

Starting the system ... 24

Storing location ... 134
- Avoid Area ... 136
- By moving map ... 135
- By searching ... 135
- Deleting ... 142
- Editing ... 138
- Routes ... 136

Switches ... 14

**T**

Texting ... 70

Trademarks ... 9

Traffic information ... 132
- Premium Traffic information ... 132
- Settings ... 134

Troubleshooting
- Android Auto ... 181
- Apple CarPlay ... 180
- Audio system ... 164
- Bluetooth® ... 174, 176
- Compact Disc (CD) player ... 168
- Display ... 162
- Hands-Free Phone System ... 176
- HD Radio technology ... 166
- iPod ... 172
- Navigation ... 184
- NissanConnect Services ... 179
- Radio (AM) ... 164
- Radio (DAB) ... 164
- Route calculation ... 186
- Siri Eyes Free ... 183
- Traffic information ... 189
- USB ... 173
- Vehicle icon ... 184
- Voice guidance ... 188
- Voice Recognition ... 190
- Wi-Fi Connection ... 163
- Wi-Fi Hotspot ... 163
- Yandex.Auto ... 182

**U**

USB (Universal Serial Bus) ..... 23, 41, 52
- Care ..... 63
- Troubleshooting ..... 173

**V**

Voice Recognition ..... 156
- Commands ..... 156
- Numbers ..... 158
- Settings ..... 159
- Troubleshooting ..... 190

**W**


Wi-Fi Connection
- Troubleshooting ..... 163

Wi-Fi Hotspot
- Troubleshooting ..... 163

Widgets ..... 26

**Y**

Yandex.Auto ..... 103
- Assistant “Alice” ..... 104
- Compatibility ..... 103
- Operation ..... 104
- Settings ..... 103, 105
- Troubleshooting ..... 182









Printing: May 2022 (01)
Publication No.: NM22EN-AIVIE0EUR
Printed in France
Nissan Automotive Europe SAS - France

AIVI-EN18